HYDRAULIC HOSE SCHEDULE - STANDARD UNIT

Hose No.	Qty.	Part Number	Description
GRP		1022904	MAIN HOSE KIT
1	1	F797TCJCJC161616-19	PUMP A TO MOTOR A
2	1	F797TCJCJ9161616-30	PUMP B TO MOTOR B
4	1	F387TCJCJC060606-14	PUMP SERVO GAGE M4 TO DESTROKE VALVE
5	1	F387TCJCJC060606-26	PUMP SERVO GAGE M5 TO DESTROKE VALVE
6	1	F387TCJCJC121212-19	PUMP CASE OUTLET TO TANK
7	1	F387TCJCJ7121212-71-AS-B-19-67	COOLER TO CHARGE PUMP INLET
8	1	F387TCJCJ7121212-52	MOTOR CASE DRAIN TO FILTER
9	1	F387TCJCJ5121212-44-AS-B-19-40.75	FILTER TO COOLER
10	1	F387TCJCJ9121212-27	COOLER TO TANK
101	1	F387TCJCJ1121212-113-AS-B-19-35	MOTOR VALVE A TO BRUSH MOTOR B
102	1	F387TCJCJ9121212-32	BRUSH SPEED VALVE 1 TO MOTOR VALVE
105	1	F387TCJCJ9060606-26	PUMP GAGE PORT TO SOLENOID VALVE 3
106	1	F387TCJCJ1060606-34	SOLENOID VALVE 1 TO MOTOR X1
107	1	F387TCJCJ7060606-35	MANIFOLD A1 TO PIVOT CYLINDER ROD END
108	1	F387TCJCJ5060606-77-AS-B-13-74.75	MANIFOLD T TO LIFT CYLINDER
109	1	F387TCJCJC060606-46	MANIFOLD B1 TO PIVOT CYLINDER
110	1	F387TCJCJ9060606-63	MANIFOLD T TO MOTOR VALVE
111	1	F387TCJCJC060606-68-AS-B-13-66.25	MANIFOLD A2 TO LIFT CYLINDER
112	1	F387TCJCJC060606-66-AS-B-13-25	AUX PUMP TO STEERING MOTOR IN
113	1	F387TCJCJ9060606-17-AS-B-13-15	MANIFOLD P TO STEERING MOTOR AUX
119	1	K811HTJCJ9161616-38	TANK TO PUMP
121	1	F387TCJCJ5121212-110-AS-B-19-39	MOTOR VALVE B TO BRUSH MOTOR A
122	1	F387TCJ5J5060606-24-0	MOTOR VALVE TO NEEDLE VALVE
123	1	F387TCJCJ9060606-67	MANIFOLD A2 TO NEEDLE VALVE
124	1	F387TCJCJ9060606-117-AS-B-13-113.75	STEERING MOTOR RT TO STEER CYLINDER
125	1	F387TCJCJC060606-106-AS-B-13-104.25	STEERING MOTOR LT TO STEER CYLINDER
130	1	F387TCJCJ9060606-50	STEERING MOTOR OUT TO MOTOR VALVE
134	1	F387TCJCJ7121212-60-AS-B-19-25	MOTOR VALVE TO FILTER
137	1	F387TCJCJC060606-20	SOLENOID VALVE 2 TO TANK
140	1	F387TCJCJC121212-36	AUX PUMP TO BRUSH SPEED VALVE 1
141	1	F387TCJCJ9121212-29	BRUSH SPEED VALVE 2 TO TANK

HYDRAULIC HOSE SCHEDULE - OPTIONS

Hose No.	Qty.	Part Number	Description
GRP		1023243	FNR PEDAL HOSE KIT
1	1	F387TCJCJC040404-94	PUMP X1 TO PEDAL 1
2	1	F387TCJCJC040404-95	PUMP X2 TO PEDAL 2
3	1	F387TCJCJC040604-85	PUMP GAGE PORT TO PEDAL P
4	1	F387TCJCJC060606-85	PEDAL T TO TANK

Hose No.	Qty.	Part Number	Description
GRP		1020525	SNOW PLOW HOSE KIT
2	1	F387TCJCJC060606-130	LIFT CYLINDER BACK END TO TANK
3	1	F387TCJCJC060606-128	SNOW PLOW VALVE A2 TO LIFT CYLINDER ROD END
4	1	F387TCJCJC060606-156	SNOW PLOW VALVE A1 TO LEFT PIVOT CYLINDER
5	1	F387TCJCJC060606-142	SNOW PLOW VALVE B1 TO RIGHT PIVOT CYLINDER
6	1	F387TCJCJ9060606-26	FLOW DIVIDER 2 TO MAIN MANIFOLD P
7	1	F387TCJCJ9060606-20	FLOW DIVIDER 4 TO SNOW PLOW MANIFOLD P
8	1	F387TCJ7JC060606-33	MAIN MANIFOLD T TO SNOW PLOW MANIFOLD T
113	1	F387TCJCJC060606-17	STEERING MOTOR AUX TO FLOW DIVIDER 3

Hose No.	Qty.	Part Number	Description
GRP		1020529	CURB BRUSH HOSE KIT
1	1	F387TCJCJC060606-22	HOSE, HYDRAULIC, FLOW DIVIDER EXCESS FLOW TO CURB BRUSH VALVE P
2	1	F387TCJCJS060806-32	HOSE, HYDRAULIC, CURB BRUSH VALVE T TO RELIEF VAVLE RETURN
3	1	F387TCJCJ9161616-35	HOSE, HYDRAULIC, TANK TO AUX PUMP INLET
4	1	F387TCJCJC080808-21	HOSE, HYDRAULIC, AUX PUMP REAR OUTLET TO RELIEF VALVE INLET
5	1	F387TCJCJC060606-45	HOSE, HYDRAULIC, RELIEF VALVE OUT TO TANK
6	1	F387TCJCJC060606-146	HOSE, HYDRAULIC, CURB BRUSH VALVE A2 TO LIFT CYCLINDER ROD END
7	1	F387TCJCJC060606-136	HOSE, HYDRAULIC, CURB BRUSH VALVE T TO LIFT CYLINDER BACK END
8	1	F387TCJCJC060606-184	HOSE, HYDRAULIC, CURB BRUSH VALVE A1 TO BRUSH MOTOR A
9	1	F387TCJCJC060606-184	HOSE, HYDRAULIC, CURB BRUSH VALVE B1 TO BRUSH MOTOR B

ALPHABETICAL PARTS INDEX

Description	Part No.	Figure No.	Item No.
1/2 Low Pressure Hose - Black (Per Foot)	6352	7-41	14
1/2 Low Pressure Hose - Black x 3.00"	REF	7-41	14A
1/2 Low Pressure Hose - Black x 36.00"	REF	7-41	14C
1/2 Low Pressure Hose - Black x 72.00"	REF	7-41	14B
12V Battery, 770 CCA, 950 CA, Group 34	PURCHASE LOCALLY	7-14	20
12V Starter, 2.2KW	1015794-15	7-14	11
14V/110A Alternator	1015794-16	7-14	4
90° Fitting, 08MP-08HB, Poly	70319	7-41	20
-A-			
A/C Thermostat	36745-19	7-31	6
AC Belt Idler	1015794-32	7-14	17
AC Belt Idler	1015794-32	7-30	10
AC Belt Tensioner	1015794-31	7-14	16
AC Belt Tensioner	1015794-31	7-30	11
AC Compressor	1015794-30	7-14	14
AC Main Mounting Bracket	1015794-33	7-14	15
AC Main Mounting Bracket	1015794-33	7-30	8
AC Support Bracket	1015794-34	7-14	18
AC Support Bracket	1015794-34	7-30	9
AC Support Strap	1015794-35	7-14	19
Access Port	1006804	7-9	5
Access Port	1006804	7-10	6
Accuseal Clamp, 2.00"	1015876	7-13	10
Adapter Elbow, 90°, -6 ORFS/-6 NPTF, .078 Orifice	FS2501-06-06-FG x 078	7-45	16
Adapter Elbow, 90°, -6 ORFS/-6 O-Ring	FS6801-06-06-NWO-FG	7-45	7
Adapter, Branch Tee, -12 ORFS/-12 ORFS/-12 O-Ring	FS6803-12-12-12-NWO-FG	7-17	2
Adapter, Branch Tee, -12 ORFS/-12 ORFS/-12 O-Ring	FS6803-12-12-12-NWO-FG	7-35	4
Adapter, Branch Tee, -6 ORFS/-6 ORFS/-6 O-Ring	FS6803-06-06-06-NWO-FG	7-43	3
Adapter, Branch Tee, -8 ORFS/-8 ORFS/-8 NPT	FS2601-08-08-08-FG	7-43	11
Adapter, Branch Tee, Swivel, -12 ORFS	FS6600-12-12-12-FG	7-16	5
Adapter, Bulkhead, Test Port to -4 IRFS	1019707	7-18	26
Adapter, Cap, ORFS, -16	FS0304-C-16	7-10	26
Adapter, Elbow, 45°, -6 ORFS/-6 O-Ring	FS6802-06-06-NWO-FG	7-46	4
Adapter, Elbow, 45°, -6 ORFS/-6 O-Ring	FS6802-06-06-NWO-FG	7-20	5

Alphabetical Parts Index

Description	Part No.	Figure No.	Item No.
Adapter, Elbow, 45°, -8 ORFS/-8 NPTF	FS2503-08-08-FG	7-43	12
Adapter, Elbow, 90°, -6 ORFS/-6 O-Ring	FS6801-06-06-NWO-FG	7-46	5
Adapter, Elbow, 90°, -06 ORFS/-06 O-Ring	FS6801-06-06-NWO-FG	7-37	2
Adapter, Elbow, 90°, -12 ORFS/-10 ORFS	FS6801-12-10-NWO-FG	7-35	8
Adapter, Elbow, 90°, -12 ORFS/-10 O-Ring	FS6801-12-10-NWO-FG	7-8	46
Adapter, Elbow, 90°, -12 ORFS/-10 O-Ring	FS6801-12-10-NWO-FG	7-19	4
Adapter, Elbow, 90°, -12 ORFS/-12 O-Ring	FS6801-12-12-NWO-FG	7-5	5
Adapter, Elbow, 90°, -12 ORFS/-12 O-Ring	FS6801-12-12-NWO-FG	7-10	10
Adapter, Elbow, 90°, -12 ORFS/-12 O-Ring	FS6801-12-12-NWO-FG	7-17	5
Adapter, Elbow, 90°, -12 ORFS/-12 O-Ring	FS6801--12-12-NWO-FS	7-44	5
Adapter, Elbow, 90°, -12 ORFS/-16 O-Ring	FS6801-12-16-NWO-FG	7-15	6
Adapter, Elbow, 90°, -12 ORFS/-16 O-Ring	FS6801-12-16-NWO-FG	7-16	14
Adapter, Elbow, 90°, -12 ORFS/-16 O-Ring	FS6801-12-16-NWO-FG	7-37	6
Adapter, Elbow, 90°, -16 ORFS/-12 O-Ring	FS6801--16-12-NWO-FS	7-44	3
Adapter, Elbow, 90°, -16 ORFS/-16 O-Ring	FS6801-16-16-NWO-FG	7-5	4
Adapter, Elbow, 90°, -16 ORFS/-16 O-Ring	FS6801-16-16-NWO-FG	7-15	7
Adapter, Elbow, 90°, -16 ORFS/-16 O-Ring	FS6801-16-16-NWO-FG	7-17	6
Adapter, Elbow, 90°, -16 ORFS/-16 O-Ring	FS6801-16-16-NWO-FG	7-37	7
Adapter, Elbow, 90°, -6 JIC/-4 O-Ring	6804-6-4 NWO	7-9	8
Adapter, Elbow, 90°, -6 ORFS/-6 ORFS	FS6500-06-06-FG	7-35	7
Adapter, Elbow, 90°, -6 ORFS/-6 O-Ring	FS6801-06-06-NWO-FG	7-10	18
Adapter, Elbow, 90°, -6 ORFS/-6 O-Ring	FS6801-06-06-NWO-FG	7-15	2
Adapter, Elbow, 90°, -6 ORFS/-6 O-Ring	FS6801-06-06-NWO-FG	7-18	4
Adapter, Elbow, 90°, -6 ORFS/-6 O-Ring	FS6801-06-06-NWO-FG	7-20	6
Adapter, Elbow, 90°, -6 ORFS/-6 O-Ring	FS6801-06-06-NWO-FG	7-28	35
Adapter, Elbow, 90°, -6 ORFS/-6 O-Ring	FS6801-06-06-NWO-FG	7-43	5
Adapter, Elbow, 90°, -6 ORFS/-6 O-Ring, .030 Orifice	FS6801-06-06-NWO-FG X 030	7-5	6
Adapter, Elbow, 90°, -6 ORFS/-8 O-Ring	FS6801-06-08-NWO-FG	7-6	44
Adapter, Elbow, 90°, -6 ORFS/-8 O-Ring	FS6801-06-08-NWO-FG	7-15	11
Adapter, Elbow, 90°, -6 ORFS/-8 O-Ring	FS6801-06-08-NWO-FG	7-19	8
Adapter, Elbow, 90°, -6 ORFS/-8 O-Ring	FS6801-06-08-NWO-FG	7-37	14
Adapter, Elbow, 90°, -6 ORFS/-8 O-Ring	FS6801-06-08-NWO-FG	7-43	8
Adapter, Elbow, 90°, -6 ORFS--6 O-Ring	FS6801-06-06-NWO-FG	7-7	16
Adapter, Elbow, 90°, -8 ORFS/-10 O-Ring	FS6801--08-10-NWO-FS	7-44	4
Adapter, Elbow, 90°, Swivel, -12 ORFS/-12 ORFS	FS6500-12-12-FG	7-8	48
Adapter, Elbow, 90°, Swivel, -12 ORFS/-12 ORFS	FS6500-12-12-FG	7-10	12
Adapter, Elbow, 90°, Swivel, -12 ORFS/-12 O-Ring	FS6500-12-12-FG	7-19	10

Alphabetical Parts Index

Description	Part No.	Figure No.	Item No.
Adapter, Elbow, 90°, Swivel, -6 ORFS/-6 O-Ring	FS6500-06-06-FG	7-19	5
Adapter, Plug, -6 O-Ring	6408-6-O	7-10	16
Adapter, Plug, O-Ring, -4	6408-4-O	7-9	7
Adapter, Reducer, Straight, -12 FFORX/-6 ORFS	FS2406-12-06	7-17	3
Adapter, Reducer, Straight, -12 FFORX/-6 ORFS	FS2406-12-06	7-19	3
Adapter, Reducer, Straight, -12 FFORX/-6 ORFS	FS2406-12-06	7-35	5
Adapter, Reducer, Straight, -12 FFORX/-8 ORFS	FS2406-12-08	7-35	3
Adapter, Run Tee, -12 ORFS/-12 O-Ring/12 ORFS	FS6804-12-12-12-NWO-FG	7-35	2
Adapter, Run Tee, -12 ORFS/-12 O-Ring/-12 ORFS	FS6804-12-12-12-NWO-FG	7-10	11
Adapter, Run Tee, -12 ORFS/-12 O-Ring/-12 ORFS	FS6804-12-12-12-NWO-FG	7-18	17
Adapter, Run Tee, -12 ORFS/-12 O-Ring/-12 ORFS	FS6804-12-12-12-NWO-FG	7-19	2
Adapter, Run Tee, -12 ORFs/-12 O-Ring/-16 ORFS	FS6804-12-12-16-NWO-FG	7-10	22
Adapter, Run Tee, -4 ORFS/-4 O-Ring/-4 ORFS	FS6804-04-04-04-NWO-FG	7-37	9
Adapter, Run Tee, -6 ORFS/-6 ORFS/-6 ORFS	FS6602-06-06-06-FG	7-46	3
Adapter, Run Tee, -6 ORFS/-6 O-Ring/-6 ORFS	FS6804-06-06-06-NWO-FG	7-20	2
Adapter, Run Tee, -6 ORFS/-6 O-Ring/-6 ORFS	FS6804-06-06-06-NWO-FG	7-37	8
Adapter, Run Tee, -6 ORFS/-6 O-Ring/-6 ORFS	FS6804-06-06-06-NWO-FG	7-46	2
Adapter, Run Tee, Swivel, -16 ORFS/-16 ORFS/-16 ORFS	FS6602-16-16-16-FG	7-44	6
Adapter, Run Tee, Swivel, -6 ORFS	FS6602-06-06-06-FG	7-10	19
Adapter, Run Tee, Swivel, -6 ORFS/-6 ORFS/-4 ORFS	FS-6602-06-06-04-FG	7-18	5
Adapter, Run Tee, Swivel, -6 ORFS/-6 ORFS/-6 ORFS	FS6602-06-06-06-FG	7-19	6
Adapter, Run Tee, Swivel, -6 ORFS/-6 ORFS/-6 ORFS	FS6602-06-06-06-FG	7-35	6
Adapter, Run Tee, Swivel, -6 ORFS/-6 ORFS/-6 ORFS	FS6602-06-06-06-FG	7-44	7
Adapter, Straight, -12 ORFS/-10 O-Ring	FS6400-12-10-O	7-8	47
Adapter, Straight, -12 ORFS/-10 O-Ring	FS6400-12-10-O	7-15	12
Adapter, Straight, -12 ORFS/-10 O-Ring	FS6400-12-10-O	7-37	15
Adapter, Straight, -12 ORFS/-10 O-Rings	FS6400-12-10-O	7-18	21
Adapter, Straight, -12 ORFS/-12 O-Ring	FS6400-12-12-O	7-10	17
Adapter, Straight, -12 ORFS/-12 O-Ring	FS6400-12-12-O	7-15	4
Adapter, Straight, -12 ORFS/-12 O-Ring	FS6400-12-12-O	7-19	11
Adapter, Straight, -12 ORFS/-12 O-Ring	FS6400-12-12-O	7-37	4
Adapter, Straight, -12 ORFS/-12 O-Rings	FS6400-12-12-O	7-18	18
Adapter, Straight, -12 ORFS/-16 O-Ring	FS6400-12-16-O	7-16	4
Adapter, Straight, -12 O-Ring/-8 NPTF	6401-12-8-O	7-43	10
Adapter, Straight, -16 ORFS/-16 O-Ring	FS6400-16-16-O	7-10	25
Adapter, Straight, -16 ORFS/-16 O-Ring	FS6400-16-16-O	7-15	5
Adapter, Straight, -16 ORFS/-16 O-Ring	FS6400-16-16-O	7-17	8

Alphabetical Parts Index

Description	Part No.	Figure No.	Item No.
Adapter, Straight, -16 ORFS/-16 O-Ring	FS6400-16-16-O	7-37	5
Adapter, Straight, -16 ORFS/-16 O-Ring	FS6400-16-16-O	7-44	2
Adapter, Straight, -20 ORFS/-20 O-Ring	FS6400-20-20-O	7-10	28
Adapter, Straight, -4 ORFS/-4 O-Ring	FS6400-04-04-O	7-36	5
Adapter, Straight, -4/Swivel ORFS/-4 O-Ring	4_G65L-S	7-37	10
Adapter, Straight, -6 ORFS/-12 O-Ring	FS6400-06-12-O	7-43	9
Adapter, Straight, -6 ORFS/-4 O-Ring	FS6400-06-04-O	7-36	4
Adapter, Straight, -6 ORFS/-6 O-Ring	FS6400-06-06-O	7-15	3
Adapter, Straight, -6 ORFS/-6 O-Ring	FS6400-06-06-O	7-19	9
Adapter, Straight, -6 ORFS/-6 O-Ring	FS6400-06-06-O	7-20	4
Adapter, Straight, -6 ORFS/-6 O-Ring	FS6400-06-06-O	7-26	12
Adapter, Straight, -6 ORFS/-6 O-Ring	FS6400-06-06-O	7-28	34
Adapter, Straight, -6 ORFS/-6 O-Ring	FS6400-06-06-O	7-37	3
Adapter, Straight, -6 ORFS/-6 O-Ring	FS6400-06-06-O	7-43	4
Adapter, Straight, -6 ORFS/-6 O-Ring	FS6400-06-06-O	7-46	13
Adapter, Straight, -6 ORFS/-6 O-Ring, .078 Orifice	FS6400-06-06-O X 078	7-7	17
Adapter, Straight, -6 ORFS/-6 O-Ring, .078 Orifice	FS6400-06-06-O X 078	7-20	3
Adapter, Straight, -6 ORFS/-6 O-Rings	FS6400-06-06-O	7-18	13
Adapter, Tilt Steering	1021624	7-26	ASSY
Adapter, Union, -16 O-Ring/-16 O-Ring	6407-16-16 NWO	7-10	23
Adjustment Pin	29130	7-42	30
Adjustment Plate Weldment	28943	7-42	8
Air & Water Radiator	1015794-20	7-12	1
Air Conditioner Compressor	1015794-30	7-30	7
Air Conditioner Dryer	36745-07	7-30	13
Air Conditioner/Heat Hose Kit	1016157	7-30	REF
Air Conditioner/Heater Filter Spacer	1016314	7-30	3
Air Conditioner/Heater Kit	1020046	7-30	1
Air Conditioner/Heater Mount Weldment	1015616	7-30	2
Air Filter Assembly	1015794-58	7-13	6
Air Intake Pipe Weldment	1015788	7-13	2
Air Intake, Extended	1023083	7-49	1
Alarm, Back Up	33963	7-21	34
Amber Lightbar, LED, 16"	1018573	7-48	1
Antenna, AM/FM, Flexible	1002021	7-40	3
Anti-Skid, Cab, Center	1015035-05	7-22	14
Arm, Wiper, 14"	1021648	7-21	21

Alphabetical Parts Index

Description	Part No.	Figure No.	Item No.
Arm, Wiper, 14"	1021646	7-34	4
Assembly, 2 Speed Solenoid w/ORFS Adapters	1020495	7-18	ASSY
Assembly, Axle, Front Fenders	1024307	7-47	ASSY
Assembly, Brake Pedal	1023497	7-25	ASSY
Assembly, Brake Pedal	1023497	7-36	ASSY
Assembly, Brush Drive Valve w/ORFS Adapters	1021513	7-19	ASSY
Assembly, Brush Motor w/ORFS Adapters	1020376	7-8	ASSY
Assembly, Brush Speed Potentiometer	1023229SRV	7-28	21
Assembly, Brush Speed Solenoid w/ORFS Adapters	1022095	7-18	ASSY
Assembly, Cab Door	1023440	7-24	ASSY
Assembly, Casted Hub, Idler Comer	1011707	7-6	ASSY
Assembly, Curb Brush Controls	1020531	7-43	ASSY
Assembly, Curb Brush Valve w/ORFS Adapters	1020532	7-43	ASSY
Assembly, Destroke Solenoid w/ORFS Adapters	1020496	7-18	ASSY
Assembly, Flow Divider & Relief Valve w/ORFS Adapters	1020533	7-43	ASSY
Assembly, Flow Divider w/ORFS Adapters	1024785	7-46	ASSY
Assembly, Foot Pedal w/ORFS Adapters	1023496	7-36	ASSY
Assembly, Fuel Tank, 30 GAL	1021896	7-9	ASSY
Assembly, Hydraulic Tank w/ORFS Adapters	1021145	7-10	ASSY
Assembly, Lift Cylinder w/ORFS Adapters	1020377	7-7	ASSY
Assembly, Lift Cylinder w/ORFS Adapters	1020527	7-45	ASSY
Assembly, Manifold w/ORFS Adapters	1023126	7-20	ASSY
Assembly, Mirror Cluster, LH	1021678	7-21	2
Assembly, Mirror Cluster, RH	1021679	7-21	1
Assembly, Motor w/ORFS Adapters	1020372	7-1	7
Assembly, Motor w/ORFS Adapters	1020372	7-5	ASSY
Assembly, Needle Valve w/Adapters	1020371	7-28	ASSY
Assembly, Oil Cooler w/Adapters	1020497	7-16	ASSY
Assembly, Pivot Cylinder w/ORFS Adapters	1020378	7-7	ASSY
Assembly, Plow Shoe	38224-05	7-45	3
Assembly, Pump Drive Plate	1015794-52	7-15	22
Assembly, Pump Drive Plate	1015794-52	7-37	20
Assembly, Pump w/ORFS Adapters	1020530	7-44	ASSY
Assembly, Pumps w/Adapters	1020374	7-15	ASSY
Assembly, Pumps w/Adapters	1023528	7-37	ASSY
Assembly, Return Filter w/Adapters	1020370	7-10	ASSY
Assembly, Seat, Black w/Armrest	360010B	7-27	1

Description	Part No.	Figure No.	Item No.
Assembly, Steering Axle	1009423	7-1	6
Assembly, Steering Axle	1009423	7-6	ASSY
Assembly, Steering Axle	1009423	7-47	1
Assembly, Steering Motor w/Adapters	1021699	7-26	10
Assembly, Swing Cylinder w/ORFS Adapters	1020528	7-45	ASSY
Assembly, Tilt Steering	1021625	7-26	ASSY
Assembly, Tire & Wheel	1009432	7-50	4
Assembly, Tire & Wheel, 15x6	1009432	7-1	ASSY
Assembly, Valve w/ORFS Adapters, Snow Plow	1020526	7-46	ASSY
Assembly, Vandalism Cover, Spare Tire	1017980SRV	7-50	1
Assembly, Water Tank, 150 GAL	1012308SRV	7-41	ASSY
Aux Pump to Steering Motor In	F387TCJCJC060606-66-AS-B-13-25	7-19	13
Axle Mounting Plate	1016659	7-1	5
-B-			
Baffle, Lower Radiator	1016327	7-21	36
Baffle, Lower Radiator, Formed	1015915	7-21	35
Baffle, Radiator, Rubber	1015819	7-11	25
Ball Joint - Left	36757	7-6	34
Ball Joint - Right	36756	7-6	32
Ball Joint, Steering Cylinder End	36755	7-6	24
Ball Valve, 1/2 (Brass)	32874	7-30	6
Bar, Intake Support, Extended	1023082	7-49	2
Base, Louver	REF	7-31	10
Battery Hold Down Pad	410050	7-14	22
Battery Hold Down Strap	150042SRV	7-14	21
Beacon Light, Amber, Strobe, LED	1013231	7-21	31
Bearing 30214	1006327-10	7-4	6
Bearing 32012X	1006327-13	7-4	3
Bearing Cone	610210	7-6	20
Bearing Cone	36828	7-7	10
Bearing Cone, Wheel Hub, Outer	340180	7-6	17
Bearing Cup	610200	7-6	19
Bearing Cup, Wheel Hub, Outer	340170	7-6	18
Bearing Flange, 4 Bolt, 1.50	312030	7-42	4
Bearing Flange, 4 Bolt, 1.50 w/Set Screw	312030	7-8	30
Bevel Crown Z=38	1006327-24	7-3	1

Alphabetical Parts Index

Description	Part No.	Figure No.	Item No.
Bevel Pinion Z=9	1006327-25	7-3	2
Blade, Wiper, 16"	12755028	7-21	22
Blade, Wiper, 16"	1021649	7-34	5
Blower Plate	36745-26	7-31	19
Blowing Unit, Broom A/C	1021528	7-31	21
Bolt, Striker, 2.75" Long	1020242	7-24	13
Boot	1021697-04	7-26	6
Boot, Master Cylinder	1010648	7-25	2
Boot, Master Cylinder	1010648	7-36	12
Brace, Mirror	856986	7-21	5
Bracket, Beacon Light	1015786	7-21	32
Bracket, Brake Lever	21217	7-28	44
Bracket, Clap Mount	1018739	7-32	9
Bracket, Control Cable	1009333	7-15	9
Bracket, Door Latch	1021687	7-24	18
Bracket, Mount, Manual Box	1021788	7-26	16
Bracket, Relay Mounting	36086	7-29	11
Brake Bleeder M10x1	1006327-08	7-4	19
Brake Disc	1006327-01	7-4	1
Brake Fulcrum Pin	1006327-49	7-3	25
Brake Lever	1006327-53	7-3	30
Brake Lever Pin	1006327-51	7-3	28
Brake Line, .188 x 107	33953-107	7-25	18
Brake Line, .188 x 15	33953-15	7-25	16
Brake Line, .188 x 50	33953-50	7-25	17
Brake Pedal	28650SRV	7-25	9
Brake Pedal	28650SRV	7-36	15
Brake piston	1006327-02	7-4	8
Brake Ring	1006327-06	7-4	16
Brake Shoe Pair	1006327-56	7-3	33
Bridge Rectifier	1016125	7-29	9
Broom Air Conditioner Condenser	1013712-01	7-30	12
Brush Core Assembly	28766	7-7	-
Brush Core Assembly	28766	7-7	-
Brush Cover	1021079	7-8	1
Brush Drive Hub Assembly	39138	7-8	29
Brush Frame	1017474	7-8	18

Description	Part No.	Figure No.	Item No.
Brush Frame Assembly and Drive Components	REF	7-7	1
Brush Motor Mount Weldment	28928	7-42	3
Brush Motor Plate	28925	7-42	2
Brush Pivot Pin	1015845	7-8	19
Brush Pivot Pin Weldment	1015845	7-7	17
Brush Pivot Weldment	1015652	7-7	12
Brush Speed Valve 1 to Motor Valve	F387TCJCJ9121212-32	7-19	12
Brush Swing Arm	1017477	7-8	26
Brush Valve, Lever	1010266	7-19	21
Bulkhead Pipe w/Nut & Gasket	36731	7-41	23
Bumper Mount Weldment	28941SRV	7-42	11
Bumper, 1.50 OD x .75	38392	7-24	15
Bushing, Oilite, 1.003 ID x 1.253 OD x .75 LG	35406	7-6	7
Bushing, Oilite, 1.252 ID x 1.565 ID x 1.50 LG	71054	7-6	35
-C-			
Cab Door	1023428	7-24	1
Cab Insulation, Floor Mat - LH	1015083-05	7-22	13
Cab Insulation, Floor Mat - RH	1015083-01	7-22	9
Cab Insulation, Headliner	1015083-04	7-22	12
Cab Insulation, No AC - LH	1015083-03	7-22	11
Cab Insulation, Rear	1015083-02	7-22	10
Cab, Insulation, Floor Mat - LH	1023191-02	7-38	2
Cab, Insulation, Floor Mat - RH	1023191-01	7-38	1
Cab, Insulation, Headliner	1015083-04	7-38	4
Cab, Insulation, Rear	1015083-02	7-38	3
Cable, Battery (-), 26", Eye/Post	800076	7-14	25
Cable, Battery (+), 16", Eye/Post	800072	7-14	23
Cable, Battery (+), 21", Eye/Eye	1012037	7-14	26
Cable, Battery (+), 24", Eye/Eye	1016367	7-14	27
Cable, Brake	1010036	7-28	48
Cable, Push, Pull, 1/4-28 w/Threaded Caps	1016290	7-15	17
Cable, Push, Pull, 1/4-28 w/Threaded Caps	1016290	7-37	21
Cable, Push/Pull	36749-04	7-31	9
Cam Lock Fitting, 3/4" F to 1/2" M Pipe	1007326	7-41	5
Cam Lock Fitting, 3/4" M to 1/2" F Pipe	1007325	7-41	6
Camera Display, Color	1004617	7-39	2

Alphabetical Parts Index

Description	Part No.	Figure No.	Item No.
Camera System Cable, 4-Pin, 16’	1022961	7-39	3
Cap	1006327-21	7-4	21
Cap M10x1 DIN908	1006327-15	7-4	7
Cap M22x1,5 Din 909	1006327-68	7-2	8
Cap, Fuel, Lockable	140030FL	7-9	2
Cap, Hydraulic, Lockable	140030HL	7-10	2
Cap, Steering Wheel	300010	7-26	2
Cap, Tank		7-33	4
Cap, Tank		7-34	9
Carriage Bolt, 1/2-13 x 1.50, GR5	106-8-13-24-5	7-45	22
Catalyzer Assembly	1015794-14	7-13	9
Center Bumper Mount Weldment	28946	7-42	14
Central Housing	1006327-61	7-2	1
Check Valve, 08HB, 5 PSI, Poly	36883	7-41	13
Check Valve, Condensate Drain	1023211	7-31	34
Circular LED Light	1012563	7-11	22
Clamp, Insulated Band, 1.25 ID	34798	7-29	8
Clamp, T-Bolt, 4.31-4.59 Range	953521243	7-32	5
Clevis Pin, .375 x 1.25, 1.015 Grip	81214	7-42	33
Clevis Pin, 1.00 x 2.50	1011476	7-7	14
Clevis Pin, 1.00 x 2.50 HDM	1011476	7-42	36
Clevis Pin, 1.00 x 2.50 HDM	1011476	7-45	17
Clevis Pin, 1.00 x 3.25	240030	7-7	20
Clevis Pin, 1.00 x 3.25 w/ Second Hole	1016641	7-45	8
Clevis, 1/4-28 UNF x .375 ID	989817	7-15	18
Clevis, 1/4-28 UNF x .375 ID	989817	7-37	22
Clevis, 5/16-24 UNF w/Pin	6427	7-28	43
Close Pipe Nipple, .500, PVC	36810	7-41	22
Coil	1009619-03	7-18	1
Coil	1021111-02	7-18	14
Coil Bracket (Left)	38653-06	7-31	24
Coil Bracket (Right)	38653-07	7-31	23
Coil, 12VDC	1011734-02	7-20	-
Column, Tilt Steering, Male Spline w/Boot	1021697	7-26	4
Condenser Mounting Bracket	1013775	7-30	19
Control Box	1023492	7-38	5
Control Box	1016637	7-42	41

Alphabetical Parts Index

Description	Part No.	Figure No.	Item No.
Control Box	1016637	7-45	38
Control Panel, Curb Brush/Snow Plow	1021739	7-42	50
Control Panel, Curb Brush/Snow Plow	1021739	7-45	47
Control, Rotary Cable	36749-03	7-31	8
Coolant Hose	1015794-13	7-12	4
Coolant Hose	1015794-09	7-12	11
Coolant Sight Glass	1015794-53	7-12	3
Cooler, Hydraulic Oil, 45,000 BTU	1015757	7-16	1
Cotter Pin	95458329	7-7	21
Cotter Pin, .125 x 1.50	80332	7-6	11
Cotter Pin, .177	36544	7-8	7
Cotter Pin, .177, 7 GA	870307	7-45	9
Cotter Pin, .188 x 1.50	80336	7-45	13
Cotter Pin, .188 x 2.00	80338	7-7	15
Cotter Pin, .188 x 2.00	80336	7-8	21
Cotter Pin, 1/85" x 1-1/4"	80331	7-7	5
Cotter Pin, ø.094 x .250 x .500	37108	7-42	32
Cotter Pin, ø.177, 7 GA	36544	7-42	31
Cotter Pin, ø.188 x 1.50	405-3-24	7-42	34
Cover, Air Filter	38653-02	7-31	4
Cover, Door Latch	980678	7-24	11
Cover, Plate, Cab Floor	1011711	7-22	21
Cover, Recirculation	36745-29	7-31	28
Cover, Servo, M46 Pump	851492	7-5	2
Cover, Wiring Access	1015587	7-29	1
CRG Bolt, 3/8-16 x 1.50, GR5	106-6-16-24-5F	7-8	8
CSBHS, 1/4-20 x .875, SS	81277	7-21	19
CSBHS, 1/4-20 x .875, SS	81277	7-34	6
CSBHS, 1/4-20 x .875, SS	81106	7-36	27
CSHH, 1/2-13 x 1.25, GR5, FT	100-8-13-20-5F	7-8	3
CSHH, 1/2-13 x 1.25, GR5, FT	100-8-13-20-5F	7-42	25
CSHH, 1/2-13 x 1.50, GR5	100-8-13-24-5	7-6	37
CSHH, 1/2-13 x 1.50, GR5	100-8-13-24-5	7-41	26
CSHH, 1/2-13 x 1.50, GR5	100-8-13-24-5	7-42	29
CSHH, 1/2-13 x 1.75, GR5	100-8-13-28-5	7-32	11
CSHH, 1/2-13 x 1.75, GR5, FT	100-8-13-28-5F	7-45	36
CSHH, 1/2-13 x 2.00, GR5	100-8-13-32-5	7-8	32

Alphabetical Parts Index

Description	Part No.	Figure No.	Item No.
CSHH, 1/2-13 x 2.00, GR5	100-8-13-32-5	7-42	21
CSHH, 1/2-13 x 2.25, GR5	100-8-13-36-5	7-21	10
CSHH, 1/2-13 x 2.25, GR5	100-8-13-36-5	7-42	38
CSHH, 1/2-13 x 3.00, GR5	100-8-13-48-5	7-8	34
CSHH, 1/2-13 x 3.75, GR5	100-8-13-60-5	7-25	10
CSHH, 1/2-13 x 3.75, GR5	100-8-13-60-5	7-36	19
CSHH, 1/2-13 x 3.75, GR5	100-8-13-60-5	7-42	37
CSHH, 1/2-13 x 6.50, GR5	100-8-13-104-5	7-42	27
CSHH, 1/2-20 x 2.00, GR5	100-8-20-32-5	7-8	43
CSHH, 1/4-20 x .75, GR5	100-4-20-12-5	7-42	46
CSHH, 1/4-20 x .75, GR5	100-4-20-12-5	7-45	43
CSHH, 1/4-20 x .75, GR5, FT	100-4-20-12-5F	7-11	19
CSHH, 1/4-20 x .75, GR5, FT	100-4-20-12-5F	7-22	27
CSHH, 1/4-20 x .75, GR5, FT	100-4-20-12-5F	7-24	24
CSHH, 1/4-20 x .75, GR5, FT	100-4-20-12-5F	7-29	4
CSHH, 1/4-20 x .75, GR5, FT	100-4-20-12-5F	7-30	24
CSHH, 1/4-20 x .75, GR5, FT	100-4-20-12-5F	7-32	18
CSHH, 1/4-20 x .75, GR5, FT	100-4-20-12-5F	7-33	5
CSHH, 1/4-20 x .75, GR5, FT	100-4-20-12-5F	7-34	10
CSHH, 1/4-20 x .75, GR5, FT	100-4-20-12-5F	7-41	38
CSHH, 1/4-20 x .75, GR5, FT	100-4-20-12-5F	7-43	20
CSHH, 1/4-20 x .75, GR5, FT	100-4-20-12-5F	7-46	9
CSHH, 1/4-20 x 1.00, GR5	100-4-20-16-5	7-20	19
CSHH, 1/4-20 x 1.00, GR5	100-4-20-16-5	7-49	3
CSHH, 1/4-20 x 1.00, GR5, FT	100-4-20-16-5F	7-22	6
CSHH, 1/4-20 x 1.00, GR5, FT	100-4-20-16-5F	7-24	21
CSHH, 1/4-20 x 1.00, GR5, FT	100-4-20-16-5F	7-47	9
CSHH, 1/4-20 x 1.00, GR5, FT	100-4-20-16-5F	7-48	3
CSHH, 1/4-20- x 1.00, GR5, FT	100-4-20-16-5F	7-31	15
CSHH, 1/4-20 x 1.25, GR5	100-4-20-20-5	7-48	4
CSHH, 1/4-20 x 1.25, GR5, FT	100-4-20-20-5F	7-11	16
CSHH, 1/4-20 x 1.625, GR5	100-4-20-26-5	7-18	22
CSHH, 1/4-20 x 16, GR5	100-4-20-16-5	7-11	12
CSHH, 1/4-20 x 2.00, GR5	100-4-20-32-5	7-18	25
CSHH, 1/4-20 x 2.50, GR5	100-4-20-40-5	7-43	13
CSHH, 1/4-28 x .75, GR5, FT	100-4-28-12-5F	7-40	9
CSHH, 1-8 x 7.00, GR5	100-16-8-112-5	7-8	23

Alphabetical Parts Index

Description	Part No.	Figure No.	Item No.
CSHH, 1-8 x 8.00, GR5	100-16-8-128-5	7-6	4
CSHH, 3/4-10 x 3.50, GR5	100-12-10-56-5	7-45	26
CSHH, 3/4-10 x 4.00, GR5	100-12-10-64-5	7-23	10
CSHH, 3/4-10 x 4.00, GR5	100-12-10-64-5	7-45	27
CSHH, 3/4-10 x 5.00, GR5	100-12-10-80-5	7-6	25
CSHH, 3/8-16 x 1.00, GR5, FT	100-6-16-16-5F	7-6	41
CSHH, 3/8-16 x 1.00, GR5, FT	100-6-16-16-5F	7-8	38
CSHH, 3/8-16 x 1.00, GR5, FT	100-6-16-16-5F	7-10	13
CSHH, 3/8-16 x 1.00, GR5, FT	100-6-16-16-5F	7-11	28
CSHH, 3/8-16 x 1.00, GR5, FT	100-6-16-16-5F	7-16	7
CSHH, 3/8-16 x 1.00, GR5, FT	100-6-16-16-5F	7-22	23
CSHH, 3/8-16 x 1.00, GR5, FT	100-6-16-16-5F	7-26	7
CSHH, 3/8-16 x 1.00, GR5, FT	100-6-16-16-5F	7-27	8
CSHH, 3/8-16 x 1.00. GR5, FT	100-6-16-16-5F	7-12	25
CSHH, 3/8-16 x 1.25, GR5	100-6-16-20-5	7-42	19
CSHH, 3/8-16 x 1.25, GR5, FT	100-6-16-20-5F	7-8	28
CSHH, 3/8-16 x 1.50, GR5	100-6-16-24-5	7-8	12
CSHH, 3/8-16 x 1.50, GR5	100-6-16-24-5	7-9	6
CSHH, 3/8-16 x 1.50, GR5	100-6-16-24-5	7-10	7
CSHH, 3/8-16 x 1.50, GR5	100-6-16-24-5	7-19	26
CSHH, 3/8-16 x 2.00, GR5	100-6-16-32-5	7-42	16
CSHH, 3/8-16 x 3.00, GR5	100-6-16-48-5	7-8	16
CSHH, 3/8-16 x 3.00, GR5	100-6-16-48-5	7-25	5
CSHH, 3/8-16 x 3.00, GR5	100-6-16-48-5	7-36	16
CSHH, 3/8-16 x 5.00, GR5	100-6-16-80-5	7-41	29
CSHH, 3/8-16 x 5.00, GR5	100-6-16-80-5	7-45	32
CSHH, 3/8-16 x 6.50, GR8	100-6-16-104-8	7-50	6
CSHH, 3/8-16 x 9.00, GR5	100-6-16-144-5	7-14	28
CSHH, 3/8-24 x 1.00, GR5, FT	100-6-24-16-5F	7-47	6
CSHH, 5/16-18 x .50, GR5, FT	100-5-18-8-5F	7-20	17
CSHH, 5/16-18 x .75, GR5, FT	100-5-18-12-5F	7-11	7
CSHH, 5/16-18 x .75, GR5, FT	100-5-18-12-5F	7-21	37
CSHH, 5/16-18 x .75, GR5, FT	100-5-18-12-5F	7-26	19
CSHH, 5/16-18 x .75, GR5, FT	100-5-18-12-5F	7-28	45
CSHH, 5/16-18 x .75, GR5, FT	100-5-18-12-5F	7-43	17
CSHH, 5/16-18 x .75, GR5, FT	100-5-18-12-5F	7-46	6
CSHH, 5/16-18 x 1.00, GR5	100-5-18-16-5	7-11	17

Alphabetical Parts Index

Description	Part No.	Figure No.	Item No.
CSHH, 5/16-18 x 1.00, GR5	100-5-18-16-5	7-27	4
CSHH, 5/16-18 x 1.00, GR5	100-5-18-16-5	7-30	23
CSHH, 5/16-18 x 1.00, GR5	100-5-18-16-5	7-32	14
CSHH, 5/16-18 x 1.00, GR5	100-5-18-16-5	7-41	39
CSHH, 5/16-18 x 1.50, GR5	100-5-18-24-5	7-19	18
CSHH, 5/16-18 x 2.00, GR5	100-5-18-32-5	7-21	14
CSHH, 5/16-18 x 2.50, GR5, FT	100-5-18-40-5F	7-28	46
CSHH, 5/16-18 x 3.00, GR5	100-5-18-48-5	7-30	16
CSHH, 5/8-11 x 4.00, GR5	100-10-11-64-5	7-45	35
CSHH, 5/8-11 x 6.00, GR5	100-10-11-96-5	7-45	30
CSHH, 5/8-11 x 6.50, GR5	100-10-11-104-8	7-1	2
CSHH, Heavy, 1-8 x 3.00, GR8	101-16-8-48-8	7-21	25
CSHH, M12x1.75 x 35, C8.8, FT	100-M12-1.75-35-8.8F	7-12	28
CSHH, M14x2 x 35, C8.8	100-M14-2-35-8.8	7-1	8
CSHH, M5x0.8 x 10mm, C8.8, FT	100-M5-0.8-10-8.8-F	7-24	9
CSHH, M6x1.0 x 12mm, C8.8	100-M06-1.00-12-8.5	7-26	13
CSSBH, 3/8-16 x 1.25	117-6-16-20	7-11	5
CSSH, 1/2-13 x 1.50, FT	102-8-13-24-F	7-15	15
CSSH, 1/2-13 x 1.50, FT	102-8-13-24-F	7-37	18
CSSH, 1/4-20 x 1.00, FT	102-4-20-16-F	7-36	2
CSSH, 3/8-16 x 1.50, FT	102-6-16-24-F	7-15	13
CSSH, 3/8-16 x 1.50, FT	102-6-16-24-F	7-37	16
Cup Holder	982689	7-28	32
Curb Brush Mount Spacer	1016712	7-42	15
Cylinder, Hydraulic, 2.00 x 10.75 x 1.00 Rod	36754	7-6	23
Cylinder, Hydraulic, Snow Plow	38224-26	7-45	15
Cylindrical Pin Ø10x30	1006327-72	7-2	12
-D-			
Decal - Danger, Roll-Over Hazard	1015036-02	7-21	29
Decal - Danger, Run-Away Vehicle	39141-24	7-28	50
Decal - Notice, Operator's Manual	988634	7-26	18
Decal - Oper, 2 -Speed	1021704-08	7-28	24
Decal - Oper, Brush Control	1021704-06	7-28	18
Decal - Oper, Brush Crown Pressure	1021704-09	7-28	37
Decal - Oper, Brush Drive	1021704-04	7-28	30
Decal - Oper, Brush Speed	1021704-10	7-28	22

Description	Part No.	Figure No.	Item No.
Decal - Oper, Cab Filter System	1019367	7-32	24
Decal - Oper, Fan	39141-22	7-28	9
Decal - Oper, Fuse Panel	1021704-05	7-29	2
Decal - Oper, Fuse Panel	1021704-14	7-29	3
Decal - Oper, High Gear	1021704-16	7-28	6
Decal - Oper, Lights/Horn	1013789-01	7-28	13
Decal - Oper, Park Brake	1013789-07	7-28	4
Decal - Oper, Pressure Monitor	1019376	7-32	25
Decal - Oper, Turn Signal	1013789-06	7-28	26
Decal - Oper, Wiper/Washer	39141-16	7-28	12
Decal - Park Brake	39141-17	7-28	49
Decal, Adjustment Screws	1015036-07	7-7	24
Decal, Caution, Alarm	39141-19	7-22	18
Decal, Caution, Hydraulic Oil	1021704-03	7-10	33
Decal, Control Box, Snow Plow	1016684	7-45	42
Decal, Curb Brush	1016686	7-42	45
Decal, Deco, RB50	1015035-04	7-22	15
Decal, Deco, Rosco, 8.50"	1013790-08	7-22	16
Decal, Door Release	1021704-13	7-24	26
Decal, Info, Arrow, Down	39135-09	7-36	25
Decal, Info, Arrow, Up	39135-08	7-36	26
Decal, Info, Master Cylinder	1010608	7-25	19
Decal, Info, Master Cylinder	1010608	7-36	23
Decal, Info, No Step	1000623-01	7-47	12
Decal, Kick Glass	1013789-05	7-23	9
Decal, No Unattended	1005474	7-22	17
Decal, Notice, Hydraulic Dye	1013275	7-10	32
Decal, Notice, Press Brake	1023508	7-36	22
Decal, Oper, Brush Controls	1023509	7-38	8
Decal, Oper, FNR, Brush Rotation	1020781	7-35	9
Decal, Oper, Water Tank	39141-18	7-41	44
Decal, Pinch/Entanglement	1008622	7-7	23
Decal, Temporary, Remove Pre-Cleaner	1023734	7-49	6
Decal, Test Port, Charge Pressure	1021704-17	7-18	27
Decal, Warning, Equipment	1021704-01	7-24	27
Decal, Warning, ROPS	1021704-04	7-22	19
Decal, Warning, Slip/Fall	1021704-02	7-7	25

Alphabetical Parts Index

Description	Part No.	Figure No.	Item No.
Decal, Wipers	39141-16	7-34	14
Defrost Fan Assembly, 12V	35425	7-22	1
Diaphragm Water Pump w/Pressure Switch	1004598SRV	7-41	19
Differential Housing	1006327-42	7-3	21
Dipstick	1015794-27	7-14	9
Disc Package	1006327-43	7-3	22
Door Handle - Push Button	982415	7-24	8
Door Sill, Cab	1015622	7-22	5
Door, Engine Compartment	1019872	7-11	2
Drive Axle, Comer 068	1016955	7-1	1
Drive Axle, Comer 068	1016655	7-2	REF
Drive Axle, Comer 068	1016655	7-3	REF
Drive Axle, Comer 068	1016655	7-4	REF
Drive Group, Comer	1009431	7-1	REF
Drive Hub	28570	7-8	41
Drive Shaft	1006327-65	7-2	5
Dust Cap	620200	7-6	16
-E, F-			
ECU	1015794-56	7-14	32
Elastic Washer D. 18	1006327-74	7-4	25
Elbow Adapter, 90°, -6 ORFS / -6 O-Ring	FS6801-06-06-NWO-FG	7-42	13
Elbow Adapter, 90°, -6 ORFS / -8 O-Ring	FS6801-06-08-NWO-FG	7-42	7
Elbow, Rubber, 90°, 4.00 ID	36919	7-32	6
Electric Fuel Pump	1015794-17	7-14	5
Engine Assembly, Hatz 4H50TIC w/AC	1015794	7-30	REF
Engine Cover	1021577	7-11	1
Engine Mount Isolator	1015794-36	7-12	18
Evaporator Coil Assembly	38653-05	7-31	25
Exhaust Pipe	1015867	7-13	13
Exhaust Pipe Support	1015790	7-13	11
Extension, Door Latch	1023131	7-32	17
Extension, Door Stop	1019992	7-32	22
Eye bot, 5/8-11 x 1.75 x 1.38 ID	38967	7-45	24
Fan	1015794-22	7-14	1
Fan (Pusher)	1015757-02	7-16	2
Fastener, Fractional Turn	36745-36	7-31	27

Description	Part No.	Figure No.	Item No.
Fender Weldment	1008025	7-47	3
Filler Neck	140030FN	7-10	3
Filter Element, Cab Air	1017782	7-31	3
Filter Element, Hydraulic, 9 Micron	290030	7-10	9
Filter Head, Hydraulic HMK04	1017402	7-10	8
Filter System, Air Quality Unit	1018732-06	7-32	1
Fitting, Master Cylinder Adapter	38277	7-25	4
Fitting, Master Cylinder Adapter	38277	7-36	11
Fitting, Push Lok, -6 LOC/-6 RFJX	6LOC-6RFJX	7-9	9
Fitting, Straight, 02MP-03IFF, Brass	39059	7-25	15
Fitting, Tee 02FM, Brass	33557	7-25	14
Flange with Brake Drum	1006327-34	7-3	12
Flasher, LED	1010202	7-29	7
Flow Divider, 4 GPM, 5000 PSI	1022694	7-46	12
Flow Divider, Fixed, w/Pressure Relief	982959	7-43	6
Flush Mount Hole Plug, .500	35136-4	7-42	44
Flush Mount Hole Plug, .500	35136-4	7-45	41
Friction Washer	1006327-52	7-3	29
Friction Washer	1006327-54	7-3	31
Front Bracket	28718SRV	7-45	5
Fuel Filter	1015794-06	7-14	10
Fuel Tank, 30 GAL	1021897	7-9	1
Fuse Block, 18 Gang, ATC	685060	7-29	14
Fuse Holder	1015794-28	7-14	REF
Fuse Holder, Inline, ATC	37118	7-29	13
Fuse, 10A, ATC	36340	7-12	20
Fuse, 10A, ATC	36340	7-29	15
Fuse, 10A, ATC	36340	7-33	REF
Fuse, 15A ATC	36341	7-32	29
Fuse, 15A, ATC	36341	7-12	21
Fuse, 15A, ATC	36341	7-29	16
Fuse, 1A, ATC	1015794-55	7-12	22
Fuse, 20A, ATC	36342	7-29	17
Fuse, 30A, ATC	36218	7-12	19
Fuse, 40A, ATC	115911	7-12	23
Fuse, 5A ATC	36746	7-32	28

Alphabetical Parts Index

Description	Part No.	Figure No.	Item No.
-G-			
Galvanized Pipe Cap, .500	91152	7-41	9
Galvanized Pipe Street Elbow, 90°, .500	38843	7-41	10
Galvanized Pipe Tee, 08FP	99845	7-41	4
Gas Spring, Steering Column	1009492-01	7-26	5
Gasket, Servo Cover, M46 Pump	851494	7-5	3
Gauge, Sight Lever/Temp, Hydraulic Oil	500070	7-10	20
Glass, Common	1015593	7-23	6
Glass, Door, Lower	1023437	7-24	7
Glass, Door, Upper	1023438	7-24	6
Glass, Front	1023436	7-23	8
Glass, Lower	1021666	7-23	4
Grease Fitting, 1/8 NPT	33684	7-6	8
Grease Fitting, 1/8 NPT, 90°	29B-02	7-6	22
Greaser M10x1	1006327-59	7-3	36
Grip	36735	7-19	22
Grip, .25 x 1.00 x 4.00	36735	7-28	29
Grommet	35465-06	7-31	20
Grommet	38525-34	7-31	30
Grommet	38606-15	7-31	31
Grommet	38606-16	7-31	32
Grommet, .19 ID x .63 OD x .125	1021720	7-24	20
Grommet, Insulation, .75 ID	35465-04	7-34	13
Grommet, Insulation, .75 ID x 1.00 OD x .063	35465-07	7-40	4
Grommet, Rubber, .25 ID, .125 Panel, .438 Hole	1019362	7-32	27
Grommet. Insulation, 3/4" ID	35465-07	7-33	2
Group - Axles	1009422	7-1	GRP
Group - Brush Assembly	1015623	7-8	GRP
Group - Engine Cover	1017187	7-11	GRP
Group - Motor Drive	1009431	7-5	GRP
Group - Park Brake	1015130	7-28	GRP
Group - SMV Sign	17898	7-11	GRP
Group, Spring Seat	1015620	7-27	GRP
Guard, Dust	1010979	7-6	40
Gutter Brush	39000	7-42	1

Description	Part No.	Figure No.	Item No.
-H-			
Harness, Air Filtration System	1018736	7-32	30
Harness, Beacon	1016701	7-21	33
Harness, Broom Controls	1023493	7-38	ASSY
Harness, Controls, Curb Brush	1018050	7-42	52
Harness, Controls, Snow Plow	1017667	7-45	49
Harness, Valves, Curb Brush	1016123	7-42	51
Harness, Valves, Snow Plow	1016080	7-45	48
Harness, Windshield Washer Pumps	1016079	7-33	8
Hatz 4H50TIC Engine Manual	1015794-57	7-14	REF
Hatz Engine Assembly, T4F, No AC/Heat	1021576	7-14	GRP
Hatz Engine Assembly, T4F, with AC/Heat	1021575	7-14	GRP
HD Brush Spray Pipe	1007328	7-41	7
Heater Coil	36749-02	7-31	22
Hinge, 18"	1020511	7-11	6
Hitch Pin, ø.944 x 7.50 w/Clip	72840	7-8	22
Holder, Filter	36745-30	7-31	29
Horn, Low Pitch	20190773	7-21	23
Hose Assembly - Cooler To Charge Pump Inlet	F387TCJCJ9121212-71-AS-B-19-67	7-16	13
Hose Assembly - Cooler To Tank	F387TCJCJ9121212-27	7-16	12
Hose Assembly - Filter To Cooler	F387TC06L9121212-44-AS-B-19-40.75	7-16	11
Hose Assembly, Aux Pump Rear Outlet to Relief Valve Inlet	F387TCJCJC080808-21	7-44	9
Hose Assembly, Aux Pump to Brush Speed Valve 1	F387TCJCJC121212-36	7-18	19
Hose Assembly, Brush Speed Valve 2 to Tank	F387TCJCJ9121212-29	7-10	29
Hose Assembly, Brush Speed Valve 2 to Tank	F387TCJCJ9121212-29	7-18	20
Hose Assembly, Curb Brush Valve A1 to Brush Motor A	F387TCJCJC060606-184	7-43	25
Hose Assembly, Curb Brush Valve B1 to Brush Motor B	F387TCJCJC060606-184	7-43	26
Hose Assembly, Curb Brush Valve T to Lift Cylinder Back End	F387TCJCJC060606-136	7-43	24
Hose Assembly, Curb Brush Valve T to Relief Valve Return	F387TCJCJS060806-32	7-43	22
Hose Assembly, Curb Brush Valve, A2 to Lift Cylinder Rod End	F387TCJCJC060606-146	7-43	23
Hose Assembly, Flow Divider 2 to Main Manifold P	F387TCJCJ9060606-26	7-46	20
Hose Assembly, Flow Divider 4 to Snow Plow Manifold P	F387TCJCJ9060606-20	7-46	19
Hose Assembly, Flow Divider Excess Flow to Curb Brush Valve P	F387TCJCJC060606-22	7-43	21
Hose Assembly, Hydraulic Tank to Aux Pump Inlet	F387TCJCJ9161616-35	7-44	8
Hose Assembly, Lift Cylinder back End to Hydraulic Tank	F387TCJCJC060606-130	7-46	15
Hose Assembly, Main Manifold T to Snow Plow Manifold T	F387TCJCJ7060606-33	7-46	14
Hose Assembly, Manifold A1 to Pivot Cylinder Rod End	F387TCJCJ7060606-35	7-20	9

Alphabetical Parts Index

Description	Part No.	Figure No.	Item No.
Hose Assembly, Manifold A2 to Lift Cylinder	F387TCJCJC060606-68-AS-B-13-66.25	7-20	10
Hose Assembly, Manifold A2 to Needle Valve	F387TCJCJ9060606-67	7-20	7
Hose Assembly, Manifold A2 to Needle Valve	F387TCJCJ9060606-67	7-28	39
Hose Assembly, Manifold B1 to Pivot Cylinder	F387TCJCJC060606-46	7-20	8
Hose Assembly, Manifold P to Steering Motor Aux	F387TCJCJC060606-17-AS-B-13-15.25	7-20	12
Hose Assembly, Manifold T to Lift Cylinder	F387TCJCJ5060606-77-AS-B-13-74.75	7-20	11
Hose Assembly, Manifold T to Motor Valve	F387TCJCJ9060606-63	7-20	13
Hose Assembly, Motor Case Drain to Filter	F387TC0637121212-52	7-17	4
Hose Assembly, Motor Valve to Filter	F387TC0637121212-60-AS-B-19-25	7-17	1
Hose Assembly, Motor Valve to Needle Valve	F387TCJ5J5060606-24-0	7-28	38
Hose Assembly, Pump A to Motor !	F797TC0606161616-19	7-17	7
Hose Assembly, Pump B to Motor B	F797TC0639161616-30	7-17	9
Hose Assembly, Pump Case Outlet to Tank	F387TCJCJC121212-19	7-10	31
Hose Assembly, Pump Gage Port to Solenoid Valve 3	F387TCJCJ9060606-26	7-18	8
Hose Assembly, Pump Servo Gage M4 to Destroke Valve	F387TCJCJC060606-14	7-18	11
Hose Assembly, Pump Servo Gage M5 to Destroke Valve	F387TCJCJC060606-26	7-18	12
Hose Assembly, Pump X1 to Pedal 1	F387TCJCJC040404-94	7-36	6
Hose Assembly, Pump X2 to Pedal 2	F387TCJCJC040404-95	7-36	7
Hose Assembly, SMS Test w/-4 Female ORFS (x2)	1019709	7-18	28
Hose Assembly, Snow Plow Valve A1 to Left Pivot Cylinder	F387TCJCJC060606-156	7-46	18
Hose Assembly, Snow Plow Valve A2 to Lift Cylinder Rod End	F387TCJCJC060606-128	7-46	16
Hose Assembly, Snow Plow Valve B1 to Right Pivot Cylinder	F387TCJCJC060606-142	7-46	17
Hose Assembly, Solenoid Valve 1 to Motor X1	F387TCJCJ1060606-34	7-18	6
Hose Assembly, Solenoid Valve to Tank	F387TCJCJC060606-20	7-18	7
Hose Assembly, Steering Motor Aux to Flow Divider 3	F387TCJCJC060606-17	7-46	21
Hose Assembly, Steering Motor LT to Steer Cylinder	F387TCJCJC060606-106-AS-B-13-130.25	7-20	15
Hose Assembly, Steering Motor RT to Steer Cylinder	F387TCJCJC060606-117-AS-B-13-115.25	7-20	14
Hose Assembly, Tank to Pump	K811HTJCJ9161616-38	7-10	30
Hose Clamp, #08 (.50-.91)	33163	7-41	12
Hose Clamp, #10 (.56-1.06)	33164	7-41	17
Hose Clamp, ø10-16mm	1015794-16	7-12	5
Hose Clamp, ø12.8	1015794-39	7-12	15
Hose Clamp, ø12-22mm	1015794-41	7-12	12
Hose Clamp, ø25-40mm	1015794-42	7-12	7
Hose Clamp, ø40-60mm	1015794-47	7-12	9
Hose Kite, Hydraulic, Snow Plow Option	1020525	7-46	KIT
Hose, Windshield Washer, ø.188 ID (Per Foot)	35550	7-33	REF

Alphabetical Parts Index

Description	Part No.	Figure No.	Item No.
Housing, Lower Cover	1023470-03	7-31	26
Hub Assembly, 6 Bolt, 205MM BC	1009281SRV	7-6	12
Hub, Idler Casting, Comer Axle	1011706	7-6	13
Hydraulic Cylinder Lock	28948	7-45	10
Hydraulic Cylinder, 2.00 x 8.00 x 1.00 Rod	610110	7-42	12
Hydraulic Cylinder, 2.00 x 8.00 x 1.00 Rod	610110	7-45	6
Hydraulic Cylinder, 2.50 x 16.00 x 1.25	1020385	7-7	13
Hydraulic Cylinder, 2.50 x 16.00 x 1.125	1020384	7-7	18
Hydraulic Cylinder, 2.50 x 6.00 x 1.125	31884A	7-7	16
Hydraulic MOT Connection	1006327-57	7-3	34
Hydraulic MOT Mount	1006327-58	7-3	35
Hydraulic Motor, LSHT, 8.0 DISP	38122	7-42	6
Hydraulic Tank, 25 GAL	1023238	7-10	1
-I, J, K, L-			
Idle Shaft Pin	1005200-115	7-8	31
Idler Hub	28828	7-8	27
Insulated Band Clamp, 3/4"	871111602	7-41	15
Insulation Grommet, .375 ID x 1.00 Groove	35465-09	7-41	25
Insulation Grommet, .75 ID	35465-07	7-41	16
Intake Support Bracket	13857	7-11	11
Joystick, FNR w/Brush Control	1019658	7-28	17
Key	35560	7-11	4
Key, Door Latch	982415-01	7-24	-
Kit, Air Conditioner/Heater, Sealed	1023470	7-31	KIT
Kit, Cab Air Filtration	1018732	7-32	KIT
Kit, Cab Insulation, No AC/Heat	1015083	7-22	KIT
Kit, Cylinder Seal	36754-03	7-6	-
Kit, Hydraulic Hose, Foot Pedal	1023243	7-36	KIT
Kit, Insulation, Foot Pedal	1023191	7-38	KIT
Kit, Strainer & Gasket	140030GK	7-10	4
Knob, .25 Shaft	35049	7-28	20
Knob, Black	851156	7-24	12
Knob, Fan Switch	37645-21	7-31	14
Latch, Door, T-Handle	1021659	7-24	19
LED Single Face Pedestal Lamp, Yellow	1005941	7-21	17
Length Adjustment Tube Weldment	28937	7-42	9

Alphabetical Parts Index

Description	Part No.	Figure No.	Item No.
Lever Latch	980460	7-11	3
Lever Latch	980460	7-50	2
Lever, Brush Valve	1010266	7-28	28
Lever, Park Brake, 12" Handle	34299	7-28	40
Lever, Throttle Control	1010262-02	7-15	20
Lift Cylinder Stop	1022642	7-7	19
Light, Blue, Dash, .50 Hole	31986	7-28	5
Light, Dome	38840	7-22	4
Light, Indicator, Green	1016102	7-28	2
Light, Indicator, Red	1009253-07	7-28	3
Light, LED Circular	1012563	7-21	16
Lock w/Offset Cam	25812	7-11	24
Lock Washer	1006327-22	7-4	22
Locknut M55x2	1006327-23	7-4	23
Loom Clip, ø.50	1015546	7-21	30
Louver, 2.50: Round	36745-17	7-31	2
Louver, 3” Round	36745-16	7-31	11
Lug Nut, M18X1.5	1009294	7-50	3
Lynch Pin, 1/4	989272-21	7-45	21
-M, N-			
Magnetic Drain Plug	1015794-26	7-14	13
Main Air Filter Element	1015794-03	7-13	7
Main Housing	1023470-01	7-31	1
Manifold, Hydraulic, 3 Valve w/Internal Check Valves	1011734	7-20	1
Manifold, Hydraulic, 3-Valve w/Internal Checks	1011734	7-43	2
Manifold, Hydraulic, 3-Valve w/Internal Checks	1011734	7-46	1
Manual-PAK Case	985234	7-26	17
Master Cylinder	1009383	7-25	1
Master Cylinder	1009383	7-36	10
Mirror - ø7.50, Convex	100857	7-21	4
Mirror Head	852570	7-21	3
Mirror, Inside Rearview	720260	7-22	2
Monitor, Pressure, Air Filtration Unit	1018732-08	7-32	4
Motor Mount Weldment	28931	7-42	5
Motor Valve A to Brush Motor B	F387TCJCJ1121212-113-AS-B-19-35	7-19	16
Motor Valve B to Brush Motor A	F387TCJCJ5121212-110-AS-B-19-39	7-19	17

Description	Part No.	Figure No.	Item No.
Motor Valve to Needle Valve	F387TCJ5J5060606-24-0	7-19	14
Motor, Hydraulic Brush Drive	1011086	7-8	44
Motor, Hydraulic, M46 Variable, 2.8/1.45 CIR	35330	7-5	1
Motor, Hydraulic, Power Steering, 8.9 CIR	1021698	7-26	11
Motor, Windshield Wiper	151170	7-21	18
Motor, Windshield Wiper	151170	7-34	1
Mount, Brake Pedal	1023181	7-25	8
Mount, Brake Pedal	1023181	7-36	14
Mount, Brake Switch	21218	7-28	41
Mount, Foot Pedal, FNR	1023183	7-36	3
Mount, Light, Mirror	856987	7-21	6
Mount, Lightbar, LED, 16"	1018574	7-48	2
Mount, Release, Cab Door	1021721	7-24	23
Mount, Rubber	36072	7-23	13
Mount, Spare Tire	1011743	7-50	5
Mount, Valve Block Assembly	1008089SRV	7-20	16
Mount, Valve Block Assembly	1008089SRV	7-46	6
Mount, Weldment, Radio/Speaker	1008092	7-40	2
Mounting Bracket, Air Filtration	1018740	7-32	8
Mounting Bracket, Curb Brush Valve	1016688	7-43	1
Muffler Clamp, 2.00”	71172	7-13	12
Nozzle Assembly, 08 Pipe, Straight	1008851	7-41	8
Nozzle Kit, Windshield Washer	852810	7-33	1
Nozzle Kit, Windshield Washer	852810	7-34	3
Nut AUTOBLOK M10	1006327-76	7-3	13
Nut M18x1.5 MF	1006327-73	7-4	24
Nut, Hex, .813-20	300020	7-26	3
Nut, Hex, 1/2-13, GR5	200-8-13-5	7-8	6
Nut, Hex, 1/2-13, GR5	200-8-13-5	7-21	13
Nut, Hex, 1/2-13, GR5	200-8-13-5	7-42	23
Nut, Hex, 1/4-20, GR5	200-4-20-5	7-11	20
Nut, Hex, 1/4-20, GR5	200-4-20-5	7-22	28
Nut, Hex, 1/4-20, GR5	200-4-20-5	7-31	18
Nut, Hex, 1/4-20, GR5	200-4-20-5	7-32	21
Nut, Hex, 1/4-20, GR5	200-4-20-5	7-40	11
Nut, Hex, 1/4-20, GR5	200-4-20-5	7-42	49
Nut, Hex, 1/4-20, GR5	200-4-20-5	7-43	16

Alphabetical Parts Index

Description	Part No.	Figure No.	Item No.
Nut, Hex, 1/4-20, GR5	200-4-20-5	7-45	46
Nut, Hex, 3/8-16, GR5	200-6-16-5	7-8	11
Nut, Hex, 3/8-16, GR5	200-6-16-5	7-11	31
Nut, Hex, 3/8-16, GR5	200-6-16-5	7-16	10
Nut, Hex, 3/8-16, GR5	200-6-16-5	7-22	26
Nut, Hex, 3/8-16, GR5	200-6-16-5	7-42	20
Nut, Hex, 3/8-16, GR8	200-6-16-8	7-50	9
Nut, Hex, 5/16-18, GR5	200-5-18-5	7-21	7
Nut, Hex, 5/16-18, GR5	200-5-18-5	7-27	7
Nut, Hex, 5/16-18, GR5	200-5-18-5	7-30	18
Nut, Hex, 5/16-18, GR5	200-5-16-5	7-41	42
Nut, Hex, Jam, 1/2-13, GR5	202-8-13-5	7-8	33
Nut, Hex, Machine, #10-24	209-#10-24	7-40	8
Nut, Jam, 1-16, LH	21114	7-6	33
Nut, Jam, 1-16, RH	21113	7-6	31
Nut, Lock, Flexloc, 1/2-13	217-8-13	7-41	28
Nut, Lock, Flexloc, 1/4-20	217-4-20	7-41	34
Nut, Lock, Flexloc, 1/4-20, Full, LT	217-4-20	7-11	15
Nut, Lock, Flexloc, 3/8-16	217-6-16	7-41	31
Nut, Lock, Flexloc, 3/8-16	217-6-16	7-45	34
Nut, Lock, Nylon, #10-32, GR5	205-#10-32-5	7-41	37
Nut, Lock, Nylon, #6-32, GR5	205-#6-32-5	7-30	22
Nut, Lock, Nylon, 7/16-14, GR5	205-7-14-5	7-24	14
Nut, Lock, Stover, 1/2, GR5	204-8-13-5	7-6	39
Nut, Lock, Stover, 1/2-13, GR5	204-8-13-5	7-8	35
Nut, Lock, Stover, 1/2-13, GR5	204-8-13-5	7-25	12
Nut, Lock, Stover, 1/2-13, GR5	204-8-13-5	7-36	21
Nut, Lock, Stover, 1/2-13, GR5	204-8-13-5	7-42	28
Nut, Lock, Stover, 1/2-13, GR5	204-8-13-5	7-45	23
Nut, Lock, Stover, 1/4-20, GR5	204-4-20-5	7-8	15
Nut, Lock, Stover, 1/4-20, GR5	204-4-20-5	7-24	25
Nut, Lock, Stover, 1/4-20, GR5	204-4-20-5	7-47	11
Nut, Lock, Stover, 1/4-20, GR5	204-4-20-5	7-48	6
Nut, Lock, Stover, 1/4-20, GR5	204-4-20-5	7-49	5
Nut, Lock, Stover, 1-8, GR5	204-16-8-5	7-6	5
Nut, Lock, Stover, 1-8, GR5	204-1-8-5	7-8	25
Nut, Lock, Stover, 1-8, GR8	204-16-8-8	7-21	27