John Clouse IMD HW5

Table of Contents

Initialize	1
Problem 1: Compute the effects of perturbations on the velocity to the B Plane	
Problem 1 conclusion	2
Problem 2: Find the dV needed to hit the desired target	3
Problem 2 conclusion	4

Initialize

```
clearvars -except hw_pub function_list
rSOI=[546507.344255845;
    527978.380486028;
    531109.066836708];
vSOI=[4.9220589268733;
    5.36316523097915;
    5.22166308425181];
mu = 398600.4415;
```

Problem 1: Compute the effects of perturbations on the velocity to the B Plane

```
% The B-Plane as-is
[ b, B_hat, B_plane ] = Bplane_rv( rSOI, vSOI, mu );
BT = dot(b*B_hat, B_plane(:,2));
BR = dot(b*B_hat, B_plane(:,3));

% Set up the velocities and storage
dv_range = 10:-1:1;
blah = 1e-1;
% blah = 1e-4;
% dv_range = 9*blah;
while min(dv_range) > 5e-16
    dv_range = [dv_range (9:-1:1)*blah];
    blah = blah*1e-1;
end

dv_range = dv_range(dv_range > 5e-16);


dBT_dvx = zeros(1,length(dv_range));
```

```
dBT_dvy = zeros(1,length(dv_range));
dBR dvx = zeros(1,length(dv range));
dBR_dvy = zeros(1,length(dv_range));
% Iterate on the velocity perturbations
for ii = 1:length(dv range)
    % X first
    [b_x, B_{\text{hat}_x}, B_{\text{plane}_x}] = \dots
        Bplane_rv( rSOI, vSOI + [dv_range(ii);0;0], mu );
    BT_x = dot(b_x*B_hat_x, B_plane_x(:,2));
    BR_x = dot(b_x*B_hat_x, B_plane_x(:,3));
    dBT_dvx(ii) = (BT_x - BT)/dv_range(ii);
    dBR_dvx(ii) = (BR_x - BR)/dv_range(ii);
    [ b_y, B_hat_y, B_plane_y ] = ...
        Bplane_rv( rSOI, vSOI + [0;dv_range(ii);0], mu );
    BT_y = dot(b_y*B_hat_y, B_plane_y(:,2));
    BR_y = dot(b_y*B_hat_y, B_plane_y(:,3));
    dBT_dvy(ii) = (BT_y - BT)/dv_range(ii);
    dBR_dvy(ii) = (BR_y - BR)/dv_range(ii);
end
```

Problem 1 conclusion

Numerical errors are pretty significant toward smaller perturbations, due to the very small dV being in the denominator. The nonlinearities are noticable both in very small and very large perturbations. I would say the linear cutoff point is in the tens of meters per second. My later computations will use 1 m/s as the velocity at which to calculate the partials.

```
figure('Position', hw_pub.figPosn)
subplot(2,2,1)
% loglog(dv_range,dBT_dvx)
semilogx(dv_range,dBT_dvx)
ylabel('\deltaB_T/\delta\DeltaV_x (s)')
xlabel('\DeltaV_x (km/s)')
subplot(2,2,2)
semilogx(dv_range,dBR_dvx)
ylabel('\deltaB_R/\delta\DeltaV_x (s)')
xlabel('\DeltaV_x (km/s)')
subplot(2,2,3)
semilogx(dv_range,dBT_dvy)
ylabel('\deltaB_T/\delta\DeltaV_y (s)')
xlabel('\DeltaV_y (km/s)')
subplot(2,2,4)
semilogx(dv range,dBR dvy)
ylabel('\deltaB_R/\delta\DeltaV_y (s)')
xlabel('\DeltaV_y (km/s)')
```



Problem 2: Find the dV needed to hit the desired target

```
BT_target = 13135.7982982557; %km
BR_target = 5022.26511510685; %km
vel = vSOI;
% Numerically calculate at dV = 1 m/s
calc_vel = 1e-3; %km/s
tol = 1e-10;
BT_curr = BT;
BR_curr = BR;
d_BT = BT_target - BT_curr;
d_BR = BR_target - BR_curr;
% Keep iterating until we hit the tolerance
while abs(d_BT) > tol && abs(d_BR) > tol
    dB = [d_BT; d_BR];
    % X first
    [ b_x, B_hat_x, B_plane_x ] = ...
        Bplane_rv( rSOI, vel + [calc_vel;0;0], mu );
```

```
BT_x = dot(b_x*B_hat_x, B_plane_x(:,2));
    BR x = dot(b x*B hat x, B plane x(:,3));
   dBT \ dvx = (BT \ x - BT \ curr)/calc \ vel;
   dBR_dvx = (BR_x - BR_curr)/calc_vel;
    % Y
    [ b_y, B_hat_y, B_plane_y ] = ...
        Bplane_rv( rSOI, vel + [0;calc_vel;0], mu );
   BT_y = dot(b_y*B_hat_y, B_plane_y(:,2));
   BR_y = dot(b_y*B_hat_y, B_plane_y(:,3));
   dBT_dvy = (BT_y - BT_curr)/calc_vel;
   dBR \ dvy = (BR \ y - BR \ curr)/calc \ vel;
   dV = [dBT_dvx dBT_dvy; dBR_dvx dBR_dvy]\dB;
   vel = vel+[dV;0];
    % Calculate resultant b-plane target
    [ b, B_hat, B_plane ] = ...
        Bplane_rv( rSOI, vel, mu );
   BT curr = dot(b*B hat, B plane(:,2));
   BR_curr = dot(b*B_hat, B_plane(:,3));
   d BT = BT target - BT curr;
   d_BR = BR_target - BR_curr;
end
```

Problem 2 conclusion

Published with MATLAB® R2013b

```
function [ b, B_hat, B_plane ] = Bplane_rv( r, v, mu )
%Bplane_rv Compute B Plane from r, v, mu wrt target planet
    Detailed explanation goes here
fcnPrintQueue(mfilename('fullpath')) % Add this code to code app
r_mag = norm(r);
v_mag = norm(v);
energy = v_mag*v_mag/2 - mu/r_mag;
v_{inf_2} = energy*2;
h_hat = cross(r,v)/norm(cross(r,v));
e_{vec} = ((v_{mag}*v_{mag}-mu/r_{mag})*r-dot(r,v)*v)/mu;
a = -mu/v_inf_2;
e = norm(e_vec);
b = -a*sqrt(e*e-1);
phi s = acos(1/e);
k = [0;0;1];
S_hat = e_vec/e*cos(phi_s) ...
    + cross(h_hat,e_vec)/norm(cross(h_hat,e_vec))*sin(phi_s);
T_hat = cross(S_hat,k)/norm(cross(S_hat,k));
R_hat = cross(S_hat, T_hat);
B_plane = [S_hat T_hat R_hat];
B_hat = cross(S_hat,h_hat);
end
```

Published with MATLAB® R2013b

```
function fcnPrintQueue( filename )
global function_list;
if exist('function_list', 'var')
    file_in_list = 0;
    for idx = 1:length(function_list)
        if strcmp(function_list(idx), filename);
            file_in_list = 1;
            break
        end
    end
    if ~file_in_list
        function_list, filename];
    end
end
end
end
end
end
```

Published with MATLAB® R2013b