SEWAGE TREATMENT PLANT

www.MINEPORTAL.in

(All Mining Solution Site)

- ☐ Online Test Series For
- DGMS COAL & METAL FIRST/SECOND CLASS
- GATE MINING
- Other Mining Exams
- Free Study Material
- Online Order Mining Books
- Like Us www.facebook.com/mineportal.in
- Whatsapp/Call 8804777500

Sewage treatment

Sewage treatment is the process of removing contaminants from waste water, primarily from household sewage. It includes physical, chemical, and biological processes to remove these contaminants and produce environmentally safe treated wastewater.

A by-product of sewage treatment is usually a semi-solid waste or slurry, called sewage sludge, that has to undergo further treatment before being suitable for disposal or land application.

Sewage is a mixture of domestic and industrial wastes. It is more than 99% water, but the remainder contains some ions, suspended solids and harmful bacteria that must be removed before the water is released into the sea.

The treatment of wastewater is divided into four phases:

- 1. Pre treatment.
- 2. primary treatment.
- 3. secondary treatment.
- 4. Tertiary treatment.

1.Pretreatment:

Large solids (i.e. those with a diameter of more than 2cm) and grit (heavy solids) are removed by screening. These are disposed of in landfills. Pretreatment removes all materials that can be easily collected from the raw sewage before they damage or clog the pumps and sewage lines of primary treatment clarifiers. Objects commonly removed during pretreatment include trash, tree limbs, leaves, branches, and other large objects. The influent in sewage water passes through a bar screen to remove all large objects like cans, rags, sticks, plastic packets etc. carried in the sewage stream. This is most commonly done with an automated mechanically raked bar screen in modern plants serving large populations, while in smaller or less modern plants, a manually

cleaned screen may be used. .

The raking action of a mechanical bar screen is typically paced according to the accumulation on the bar screens and/or flow rate. The solids are collected and later disposed in a landfill, or incinerated. Bar screens or mesh screens of varying sizes may be used to optimize solids removal. If gross solids are not removed, they become entrained in pipes and moving parts of the treatment plant, and can cause substantial damage and inefficiency in the process.

2.Primary treatment:

The water is left to stand so that solids can sink to the bottom and oil and grease can rise to the surface. The solids are scraped off the bottom and the scum is washed off with water jets. These two substances are combined to form sludge.

In the primary sedimentation stage, sewage flows through large tanks, commonly called "pre-settling basins", "primary sedimentation tanks" or "primary clarifiers". The tanks are used to settle sludge while grease and oils rise to the surface and are skimmed off. Primary settling tanks are usually equipped with mechanically driven scrapers that continually drive the collected sludge towards a hopper in the base of the tank where it is pumped to sludge treatment facilities. Grease and oil from the floating material can sometimes be recovered for saponification(soap making).

3.Secondary treatment

The sludge is further treated in 'sludge digesters': large heated tanks in which its chemical decomposition is catalysed by microorganisms. The sludge is largely converted to 'biogas', a mixture of CH4 and CO2, which is used to generate electricity for the plant. Secondary treatment is a treatment process for wastewater (or sewage) to achieve a certain degree of effluent quality by using a sewage treatment plant with physical phase separation to remove settleable solids and a biological process to remove dissolved and suspended organic compounds. After this kind of treatment, the wastewater may be called as secondarytreated wastewater.

Secondary treatment is the portion of a sewage treatment sequence removing dissolved and colloidal compounds measured as biochemical oxygen demand (BOD). Secondary treatment is traditionally applied to the liquid portion of sewage after primary treatment has removed settleable solids and floating material. Secondary treatment is typically performed by indigenous, aquatic microorganisms in a managed aerobic habitat. Bacteria and protozoa consume biodegradable soluble organic contaminants (e.g. sugars, fats, and organic short-chain carbon molecules from human waste, food waste, soaps and detergent) while reproducing to form cells of biological solids. Biological oxidation processes are sensitive to temperature and, between 0 °C and 40 °C, the rate of biological reactions increase with temperature. Most surface aerated vessels operate at between 4 °C and 32 °C.

- Secondary treatment systems are classified as fixed-film or suspended-growth systems.
- Fixed-film or attached growth systems include trickling filters, biotowers, and rotating biological contactors, where the biomass grows on media and the sewage passes over its surface. The fixed-film principle has further developed into Moving Bed Biofilm Reactors (MBBR) and Integrated Fixed-Film Activated Sludge (IFAS) processes. An MBBR system typically requires a smaller footprint than suspended-growth systems.

 Suspended-growth systems include activated sludge, where the biomass is mixed with the sewage and can be operated in a smaller space than trickling filters that treat the same amount of water. However, fixed-film systems are more able to cope with drastic changes in the amount of biological material and can provide higher removal rates for organic material and suspended solids than suspended growth systems.

4.Tertiary treatment

The purpose of tertiary treatment (also called "advanced treatment") is to provide a final treatment stage to further improve the effluent quality before it is discharged to the receiving environment (sea, river, lake, wet lands, ground, etc.). Tertiary treatment may include biological nutrient removal (alternatively, this can be classified as secondary treatment), disinfection and removal of micropollutants, such as environmental persistent pharmaceutical pollutants.

PRETREATMENT AIR SCUM **OVERFLOW TRASH SECONDARY PRIMARY AERATION** @ DRY SLUDGE FINISHING SLUDGE DRYER DIGESTION **METHANE** www.mineportal.in

MINE PROCESS WATER TREATMENT

- Extract minerals from water streams
- Re-use process water
- Treat mine <u>sludge</u>

Sludge treatment and disposal

The sludges accumulated in a wastewater treatment process must be treated and disposed off in a safe and effective manner. The purpose of digestion is to reduce the amount of organic matter and the number of disease-causing microorganisms present in the solids. The most common treatment options include anaerobic digestion, aerobic digestion and composting. Incineration is also used, albeit to a much lesser degree

- Sludge treatment depends on the amount of solids generated and other site-specific conditions.
 Composting is most often applied to small-scale plants with aerobic digestion for mid-sized operations, and anaerobic digestion for the larger-scale operations.
- The sludge is sometimes passed through a so-called pre-thickener which de-waters the sludge. Types of pre-thickeners include centrifugal sludge thickeners rotary drum sludge thickeners and belt filter presses. Dewatered sludge may be incinerated or transported offsite for disposal in a landfill or use as an agricultural soil amendment.

Environment aspects

- Many processes in a wastewater treatment plant are designed to mimic the natural treatment processes that occur in the environment, whether that environment is a natural water body or the ground. If not overloaded, bacteria in the environment will consume organic contaminants, although this will reduce the levels of oxygen in the water and may significantly change the overall ecology of the receiving water.
- Native bacterial populations feed on the organic contaminants, and the numbers of disease-causing microorganisms are reduced by natural environmental conditions such as predation or exposure to ultraviolet radiation. Consequently, in cases where the receiving environment provides a high level of dilution, a high degree of wastewater treatment may not be required.

Effects on biology

- Sewage treatment plants can have multiple effects on nutrient levels in the water that the treated sewage flows into. These nutrients can have large effects on the biological life in the water in contact with the effluent. Stabilization ponds (or sewage treatment ponds) can include any of the following:
- Oxidation ponds, which are aerobic bodies of water usually 1– 2 meters in depth that receive effluent from sedimentation tanks or other forms of primary treatment.
- Dominated by algae.
- Polishing ponds are similar to oxidation ponds but receive effluent from an oxidation pond or from a plant with an extended mechanical treatment.
- Dominated by zooplankton.

- Facultative lagoons, raw sewage lagoons, or sewage lagoons are ponds where sewage is added with no primary treatment other than coarse screening. These ponds provide effective treatment when the surface remains aerobic; although anaerobic conditions may develop near the layer of settled sludge on the bottom of the pond.
- Anaerobic lagoons are heavily loaded ponds.
- Dominated by bacteria
- Sludge lagoons are aerobic ponds, usually 2 to 5 meters in depth, that receive anaerobically digested primary sludge, or activated secondary sludge under water.
- Upper layers are dominated by algae

References:

- Tchobanoglous, George; Burton, Franklin L.; Stensel, H. David; Metcalf & Eddy, Inc. (2003). Wastewater Engineering: Treatment and Reuse (4th ed.). McGraw-Hill.
- Metcalf & Eddy, Inc. (1972). Wastewater Engineering. New York: McGraw-Hill.
- Burrian, Steven J., et al. (1999). "The Historical Development of Wet-Weather Flow Management." US Environmental Protection Agency (EPA). National Risk Management Research Laboratory, Cincinnati, OH. Document No.
- Burton, Jr., G. Allen; Pitt, Robert E. (2001). "Chapter 2. Receiving Water Uses, Impairments, and Sources of Stormwater Pollutants". <u>Stormwater</u> <u>Effects Handbook: A Toolbox for Watershed Managers, Scientists, and</u> <u>Engineers</u>. New York: CRC/Lewis Publishers.
- Abbett, Robert W. (1956). American Civil Engineering Practice. **II**. New York: John Wiley & Sons.