


Parts of the Parabolic Microphone



- A - Microphone
- B - Parabolic dish
- C - ON/OFF switch
- D - Sound focus
- E - Viewfinder
- F - View focus
- G - Record and play button
- H - Headphone jack

How to use a Parabolic Microphone

1



- Clip the parabolic dish into the slots around the microphone by gently squeezing the clips.
- There is a hole in the dish that lines up with the viewfinder.

2

Plug the headphones into the headphone jack and put them on.

3

- Point the microphone at what you want to listen to.
- Look in the viewfinder to see and aim.
- Turn the view focus knob until you see clearly.



4

- Press and hold the ON/OFF switch to start listening.
- To stop listening, release the ON/OFF switch.



5

- You can turn the sound focus knob to reduce unwanted sounds.
- Try using this if other sounds make it hard to hear what you want.



6

- Use the RECORD and PLAY buttons to record 12 seconds of sound to playback in the headphones.



7

When you are finished using the parabolic microphone:

- Unplug the headphones
- Unclip the parabolic dish from the microphone
- Pack everything away into the bag it came in