Lego Robotic Arm

Connecting the motor cables

Before we start controlling the robot, we need to make sure that the cables are connected to the hub. Follow these steps to connect the motor cables:

1. Your lego hub has 6 ports, labelled from A to F



2. First, connect the large motor cable to **port B** on the Lego Hub

3. Then, connect the gripper motor to **port C** and the elbow motor to **port E**