
LED INDICATION




| M8 CONNECTOR ON X2 TRANSPONDER | | |
|--------------------------------|---|--|
| Flashing red per second | X2 Transponder is charging | |
| Flashing red quickly | No valid subscription or no active subscription | |
| Green flashing | Number of flashes indicates days left before charging again | |
| Not flashing | Battery is empty or in Power Save mode | |
| Solid green | Battery fully charged | |

X2 RACEKEY

| (●) CHARGING STATUS | | |
|---------------------|---|--|
| Red | X2 Transponder is charging | |
| Green | X2 Transponder is fully charged | |
| Both LEDs flashing | If both LEDs are flashing red, battery is broken. | |

| SUBSCRIPTION STATUS | |
|---------------------|---|
| Red | No valid subscription or no active subscription |
| Green | Activated and valid subscription |



NOTE: the LED lights on the X2 RaceKey show a different status in the X2 Charger Case than when used on an X2 Transponder.


| TECHNICAL SPECIFICATIONS | |
|-----------------------------------|--|
| Dimensions: | 50.8 x 37.3 x 14.7 cm (L x W x H) (20x14.7x5.8 inch) |
| Weight with 30 transponders: | Approx. 9 kg (19.8lb) |
| Weight empty: | Approx. 4.5 kg (9.9lb) |
| Power consumption: | Max. 60W |
| Operating temperature range: | -10 - 40° C (14 - 104 °F) |
| Operating voltage range (adapter) | 100 - 240 VAC- |
| Frequency | 50 - 60 Hz |



This device complies with part 15 of the FCC rules, the EMC directive 2004/108/EC and RTTE directive 1999/5/EC and this equipment has been tested and found to comply with the limits for RoHS compliant materials. This device complies with A copy of the declaration of conformity can be obtained at: MYLAPS B.V. - Zuiderhoutlaan 4 - 2012 PJ Haarlem - The Netherlands

X2 CHARGER CASE - VI.O. - OCTOBER 2017 - @ MYLAPS RIGHTS RESERVED





WHAT'S IN THE BOX?

Depending on the order the X2 Charger Case either comes with or without X2 Transponders.



- X2 Charger Case
- Quick Start Guide
- USB cable (for future use)

OPTIONAL:


- 30 X2 Transponders with subscription.
- 30 X2 RaceKeys
- > 50 X2 transponder holders
- Power cable

1 USB Connector.

For future functionality such as firmware update and subscription synchronization

2 Power connector.

Use the power cable and adapter to power the X2 Charger Case



IN CASE YOU ENCOUNTER ANY ISSUES, PLEASE CONTACT YOUR LOCAL OFFICE

MYLAPS EMEA Office Haarlem, The Netherlands

- **+31 (0)23 760 0100**

MYLAPS Americas Office Atlanta, USA

- **** +1 678 816 4000


HOW TO USE THE X2 CHARGER CASE

- The X2 Charger Case charges up to 30 X2 Transponder at the same time
- ► The X2 Transponders will fully charge within 4 hours and then last a minimum of 5 days
- All X2 Transponders in this case have an active subscription and are ready for use

To charge the X2 Transponder connect the X2 RaceKey to the X2 Transponder and place both in the X2 Charger Case, while putting pressure on the X2 RaceKey. Once connected the LED's of X2 RaceKey will go on and remain on as long as the X2 Charger Case is connected to power.



LED INDICATION



MYLAPS Japan Office

Tokyo, Japan

**** +81 3 6418 8209

MYLAPS APAC Office

Sydney, Australia • +61 2 9533 1100

MYLAPS Asia Office

Selangor, Malaysia

4 +60 3 5613 1235