
HOW TO AUTOCAD TO PDF EOR LASER!

FRESH 18 JANUARY 2022


You will need to convert your AutoCAD file to an Illustrator file or PDF to interface with the lasers. The lasers are very picky about the settings.

In AutoCAD, use the Red and Darker blue in the index colors. Change your line width to 0.000".






From the menu button, choose Export > PDF



Change the "Page Setup" from "Current" to "Override", then click the page override button that appears below it.



Choose a paper size that is 18"x24". Then, uncheck "Fit to paper" and change scale to 1:1. Click OK, then save your file.

