

12 L519\_0815jlc

## **PURASAN PARTS LIST**

			1 0 1 1 2 2 1 1 1 1 1		0		
	<u>Item</u>	Part#	<b>Description</b>	38	F203	Washer 5/16" x 3/4"	
	1	32-102AW	Mixer Motor 2 1/2" Dia. 12 V DC	39	F233	Spring Roll Pin	
	1	33-102AW	Mixer Motor 2 1/2" Dia. 24 VDC	50	41-187	Shaft Boot	
	(1)		t seals and bushing for mixer motor)	53	41-152	Base Plate	
	2	31-121	Hose Fitting (2)	54	F232	6-32 x 7/16" Flat head mach. screw (2	
	-	shown)	90 <sup>90</sup> hose fitting (PLA401)	55	F231	Spacer 6" x 5/32"	
	3	31-120	Discharge Elbow 90°				
	6	31-134	Cover Hold down Bolt, 10-32 x 1" (16)			SER (41-100AW)	
			(not shown)	40	41-130A	Dispenser Body.	
	7	31-103	Motor Shaft Bushing (2) (see 62)	41	41-177	Adapter 1/2"NPT x 1/2" barb	
	8	31-106	Motor Hold down Bolt, 10-32x1", S/S (4)	43	41-156W	Tablet holder assembly.	
	9	31-109	Mixer Impeller	44	41-135A	Purasan Tablets (sold saparately)	
	10	31-110-1	Impeller Bolt, 12-24 x 5/8", S/S (2)	45	41-179	Float extension pipe	
	11	31-110-2	Impeller Lock Washer, #12, S/S (2)	46	41-178W	Float sensor	
	12	31-114	Cover Hold down Nut, 10-32 (18)	47	RWS5A	"O" Ring	
	13	31-115PS	Treatment Tank	48	41-131M	Dispenser Cap (machined)	
	14 15	31-122 41-102	Intake Plug Tank Divider	85	41-505	Cable for Float sensor	
	16	31-112	Cover Gasket	337A/T	ED 17.1 (00	1251111 1211 221252111 2411	
	17	31-112	Macerator Set Screw		,	1351W, 12V - 221352W, 24V)	
	18	31-108	Macerator Impeller	65	221356W	Inlet hose adapter	
	19	41-101W	Treatment Cover (includes 62,56, 25,26)	66	PX50W	Double Check Valve assembly Water Solenoid 12V	
	22		Macerator Motor for 12 V DC unit	67	221351		
	22		Macerator Motor for 24 V DC	67 68	221352	Water Solenoid 24V 1/2" Hose	
			t seal and bushing for Macerator motor	69	221335 41-157		
	25	31-104CW	Crossover Plug with O-ring	09	41-13/	Metering washer	
	26	31-105	O-Ring	ΛID	DI IMP for tab	let dispenser (162000WA)	
	51	M31	#14 Brass Flat Washer (4)		166024A **		
	52	M30	1/4"-20 Brass Nut (4)	70			
	56	31-325A	Adapter Tank Lid	71	162000W	Intake Pump Assembly,air pump	
	57	221335	Hose	72	162415A	Plug with barbed fitting	
	58	41-170	Tank check valve		DIAPUMPR	K Diaphragm Pump Repair Kit	
	59	31-304C	Hose clamp				
	62	ESTRK	EST/PST Repair Kit includes following	CON	TROLS		
		(Not Shown)	31-102 Motor Shaft Seal(2)	80	SPCCHNT	Purasan Control	
			31-102-1 Macerator Seal Washer	81	41-502	Wall Panel circuit board	
			31-102-2 Macerator Retaining Ring	82	221514	ME: wall panel cover, white	
			31-102-3 Mixer Seal Washer			_	
			31-102-4 Mixer Retaining Ring	83	221525	ME; wall panel gasket	
			31-103 Motor Shaft Bushing(2)	84	31-618	Cable for SPC wall panel	
			31-105 O-Ring	86	FUSE10	ATO fuse 10A	
			31-106 10-32x 7/8" Screws (4)				
	31-112 Cover Gasket			OTHER (Not shown)			
			LD ASSEMBLY(41-137W)		41-135A	Purasan Tablets (Refill)	
	24	41-151A	Adapter $\frac{1}{4}$ "x $\frac{1}{2}$ " elbow with check valve		42-1000A	Treatment Unit Complete 12V	
	27	41-145	Pull Solenoid		43-1000A	Treatment Unit Complete 24V	
	28	41-137	Drain Manifold assy.(with check valve)			•	
	29	41-151B	Adapter <sup>1</sup> / <sub>4</sub> " x <sup>1</sup> / <sub>4</sub> " elbow with check valve				
	30	41-141	Adapter <sup>1</sup> / <sub>4</sub> " NPT x <sup>1</sup> / <sub>2</sub> " barbed	* 121	IDCita ana	a suitant and suith a 24VDC Manageton	
	31	PLA3	1/4" Barbed x 1/4" NPT Adapter			equipped with a 24VDC Macerator	
1 /				ts are equipped with a 32VDC			
	33	41-138C	<sup>1</sup> / <sub>4</sub> " x <sup>3</sup> / <sub>4</sub> " U cup seal	iviact	Tator Motor.		
	34	41-138 B	Plunger Wesher for plunger	** A	** All models use a 24VDC Motor		
	35 36	41-138A F204	Washer for plunger 6-32 x 3/8" Flat head mach. screw(4)	Α	ii iiiodeis use i	A ZT Y DC IVIOWI	
	30 37	LWS	Spring Spring				
	J 1	LWD	phing				

L519\_0815jlc 13