

12 L518 0919 jlc

## **PURASAN PARTS LIST**

<b>.</b>	<b>35</b>	5 1 1	TE 4 TO	I EM DIGDE	NOTE: 44 400 AVI
	Part #	Description Min Man 2 1/2" Division 12 M DG			NSER 41-100AW
1	32-102AW	Mixer Motor 2 1/2" Dia. 12 V DC	40	41-130A	Dispenser Body.
1	33-102AW	Mixer Motor 2 1/2" Dia. 24 VDC	41	41-177	Adapter 1/2"NPT x 1/2" barb
2		haft seals and bushing for mixer motor)	43	41-153	Dispenser Basket
2	31-121	Hose Fitting (2)	44	41-135A	Purasan Tablets (sold saparately)
2		90% hose fitting (PLA401)	45	41-179	Float extension pipe
3	31-120	Discharge Elbow 90°	46	41-178W	Float sensor
6	31-134 31-103	Cover Hold down Bolt, 10-32 x 1" (18)	47 48	RWS5A	"O" Ring
7 8	31-103	Motor Shaft Bushing (2) (see 62) Motor Hold down Bolt, 10-32x1", S/S (4)	85	41-131M 41-505	Dispenser Cap (machined) Cable for Float sensor
9	31-100	Mixer Impeller	03	41-303	Cable for Float sellsor
10	31-109	Impeller Bolt, 12-24 x 5/8", S/S (2)	337AT		22125187 (1287)
11	31-110-2	Impeller Lock Washer, #12, S/S (2)	WAI		221351W (12V) 221352W 24V)
12	31-114	Cover Hold down Nut, 10-32 (18)	64	221358W	Inlet hose adapter - 90°
13	31-115PS	Treatment Tank	65	221356W	Inlet hose adapter - straight
14	31-122	Intake Plug	66	PX50W	Double Check Valve assembly
15	41-102	Tank Divider	67	221351	Water Solenoid 12V
16	31-112	Cover Gasket	67	221352	Water Solenoid 24V
17	31-108	Macerator Set Screw	68	221335	1/2" Hose
18	31-107	Macerator Impeller	69	41-157	Metering washer
19	41-101W	Treatment Cover (includes 56, 25,26)	0,5		Tributing waster
22	33-101AW*	Macerator Motor for 12 V DC unit	AIR	PUMP for ta	ıblet dispenser 162000WA (12V)
22	34-101AW*	Macerator Motor for 24 V DC			162100WA (24V)
	(Includes 31	-304CW and 31-105)	70	166012A	12 Volt Motor
25	31-104CW	Crossover Plug with O-ring	70		
26	31-105	O-Ring		166024A	24 Volt Motor
51	M31	#14 Brass Flat Washer (4)	71	162000W	Intake Pump Assembly,air pump
52	M30	1/4"-20 Brass Nut (4)	72	162415A	Plug with barbed fitting
56	31-325A	Adapter Tank Lid		DIAPUMPE	RK Diaphragm Pump Repair Kit
57	221335	Hose			
50	41 170	T1111			
58	41-170	Tank check valve	CON	TROLS	
59	31-304C	Hose clamp			Purasan Control
59	31-304C	Hose clamp	80	SPCCHNT	Purasan Control Wall Panel circuit board
59	31-304C	Hose clamp  LD ASSY 42-137W (12V)	80 81	SPCCHNT 41-502	Wall Panel circuit board
59 <b>DR</b> A	31-304C	Hose clamp  LD ASSY 42-137W (12V) 43-137W (24V)	80 81 82	SPCCHNT 41-502 221514	Wall Panel circuit board ME: wall panel cover,white
59 DRA 24	31-304C <b>MIN MANIFO</b> 41-151A	Hose clamp <b>LD ASSY</b> 42-137W (12V)  43-137W (24V)  Adapter <sup>1</sup> / <sub>4</sub> " x <sup>1</sup> / <sub>2</sub> " elbow with check valve	80 81 82 83	SPCCHNT 41-502 221514 221525	Wall Panel circuit board ME: wall panel cover,white ME; wall panel gasket
59 <b>DR</b> A	31-304C AIN MANIFO 41-151A 42-145	Hose clamp  LD ASSY 42-137W (12V) 43-137W (24V)  Adapter 1/4" x 1/2" elbow with check valve 12 Volt Pull Solenoid	80 81 82 83 84	SPCCHNT 41-502 221514 221525 31-618	Wall Panel circuit board ME: wall panel cover,white ME; wall panel gasket Cable for SPC wall panel
59 DRA 24 27	31-304C AIN MANIFO 41-151A 42-145 43-145	Hose clamp  LD ASSY 42-137W (12V) 43-137W (24V)  Adapter <sup>1</sup> / <sub>4</sub> " x <sup>1</sup> / <sub>2</sub> " elbow with check valve 12 Volt Pull Solenoid 24 Volt Pull Solenoid	80 81 82 83	SPCCHNT 41-502 221514 221525	Wall Panel circuit board ME: wall panel cover,white ME; wall panel gasket
59 DRA 24 27 28	31-304C AIN MANIFO 41-151A 42-145 43-145 41-137	Hose clamp  LD ASSY 42-137W (12V) 43-137W (24V)  Adapter 1/4" x 1/2" elbow with check valve 12 Volt Pull Solenoid 24 Volt Pull Solenoid Drain Manifold assy.(with check valve)	80 81 82 83 84	SPCCHNT 41-502 221514 221525 31-618 EFC10	Wall Panel circuit board ME: wall panel cover,white ME; wall panel gasket Cable for SPC wall panel ATO fuse 10A EST/PST Repair Kit includes following
59 DRA 24 27 28 29	31-304C AIN MANIFO 41-151A 42-145 43-145 41-137 41-151B	Hose clamp  LD ASSY 42-137W (12V) 43-137W (24V)  Adapter <sup>1</sup> / <sub>4</sub> " x <sup>1</sup> / <sub>2</sub> " elbow with check valve 12 Volt Pull Solenoid 24 Volt Pull Solenoid Drain Manifold assy.(with check valve) Adapter <sup>1</sup> / <sub>4</sub> " x <sup>1</sup> / <sub>4</sub> " elbow with check valve	80 81 82 83 84 86	SPCCHNT 41-502 221514 221525 31-618 EFC10 ESTRK Part No.	Wall Panel circuit board ME: wall panel cover,white ME; wall panel gasket Cable for SPC wall panel ATO fuse 10A  EST/PST Repair Kit includes following Description
59 DRA 24 27 28 29 30	31-304C AIN MANIFO 41-151A 42-145 43-145 41-137 41-151B 41-141	Hose clamp  LD ASSY 42-137W (12V) 43-137W (24V)  Adapter <sup>1/4</sup> , " x <sup>1/2</sup> ," elbow with check valve 12 Volt Pull Solenoid 24 Volt Pull Solenoid Drain Manifold assy.(with check valve) Adapter <sup>1/4</sup> , " x <sup>1/4</sup> ," elbow with check valve Adapter <sup>1/4</sup> , " NPT x <sup>1/2</sup> ," barbed	80 81 82 83 84 86	SPCCHNT 41-502 221514 221525 31-618 EFC10 ESTRK Part No. 31-102	Wall Panel circuit board ME: wall panel cover,white ME; wall panel gasket Cable for SPC wall panel ATO fuse 10A  EST/PST Repair Kit includes following Description Motor Shaft Seal (2)
59  DRA 24 27  28 29 30 31	31-304C AIN MANIFO 41-151A 42-145 43-145 41-137 41-151B 41-141 PLA3	Hose clamp  LD ASSY 42-137W (12V) 43-137W (24V)  Adapter \(^{1}\alpha\)' x \(^{1}\alpha\)'' elbow with check valve 12 Volt Pull Solenoid 24 Volt Pull Solenoid Drain Manifold assy.(with check valve) Adapter \(^{1}\alpha\)' x \(^{1}\alpha\)'' elbow with check valve Adapter \(^{1}\alpha\)' NPT x \(^{1}\alpha\)'' barbed \(^{1}\alpha\)'' Barbed x \(^{1}\alpha\)'' NPT Adapter	80 81 82 83 84 86	SPCCHNT 41-502 221514 221525 31-618 EFC10 ESTRK Part No. 31-102 31-102-1	Wall Panel circuit board ME: wall panel cover,white ME; wall panel gasket Cable for SPC wall panel ATO fuse 10A  EST/PST Repair Kit includes following Description Motor Shaft Seal (2) Macerator Seal Washer
59  DRA  24 27  28 29 30 31 32	31-304C AIN MANIFO 41-151A 42-145 43-145 41-137 41-151B 41-141 PLA3 41-139	Hose clamp  LD ASSY 42-137W (12V) 43-137W (24V)  Adapter \(^1/_4\) \(^1/_2\) elbow with check valve 12 Volt Pull Solenoid 24 Volt Pull Solenoid Drain Manifold assy. (with check valve) Adapter \(^1/_4\) \(^1/_4\) elbow with check valve Adapter \(^1/_4\) \(^1/_4\) elbow with check valve Adapter \(^1/_4\) \(^1/_4\) NPT \(^1/_2\) barbed \(^1/_4\) Barbed \(^1/_4\) NPT Adapter Cap, manifold	80 81 82 83 84 86	SPCCHNT 41-502 221514 221525 31-618 EFC10 ESTRK Part No. 31-102 31-102-1 31-102-2	Wall Panel circuit board ME: wall panel cover,white ME; wall panel gasket Cable for SPC wall panel ATO fuse 10A  EST/PST Repair Kit includes following Description Motor Shaft Seal (2) Macerator Seal Washer Macerator Retaining Ring
59  DRA 24 27  28 29 30 31 32 33	31-304C AIN MANIFO 41-151A 42-145 43-145 41-137 41-151B 41-141 PLA3 41-139 41-138C	Hose clamp  LD ASSY 42-137W (12V) 43-137W (24V)  Adapter 1/4" x 1/2" elbow with check valve 12 Volt Pull Solenoid 24 Volt Pull Solenoid Drain Manifold assy.(with check valve) Adapter 1/4" x 1/4" elbow with check valve Adapter 1/4" NPT x 1/2" barbed 1/4" Barbed x 1/4" NPT Adapter Cap, manifold 1/4" x 3/4" U cup seal	80 81 82 83 84 86	SPCCHNT 41-502 221514 221525 31-618 EFC10 ESTRK Part No. 31-102 31-102-1 31-102-2 31-102-3	Wall Panel circuit board ME: wall panel cover,white ME; wall panel gasket Cable for SPC wall panel ATO fuse 10A  EST/PST Repair Kit includes following Description Motor Shaft Seal (2) Macerator Seal Washer Macerator Retaining Ring Mixer Seal Washer
59  DRA  24 27  28 29 30 31 32	31-304C AIN MANIFO 41-151A 42-145 43-145 41-137 41-151B 41-141 PLA3 41-139	Hose clamp  LD ASSY 42-137W (12V) 43-137W (24V)  Adapter \(^1/_4\)" x \(^1/_2\)" elbow with check valve 12 Volt Pull Solenoid 24 Volt Pull Solenoid Drain Manifold assy.(with check valve) Adapter \(^1/_4\)" x \(^1/_4\)" elbow with check valve Adapter \(^1/_4\)" NPT x \(^1/_2\)" barbed \(^1/_4\)" Barbed x \(^1/_4\)" NPT Adapter Cap, manifold \(^1/_4\)" x \(^3/_4\)" U cup seal Plunger	80 81 82 83 84 86	SPCCHNT 41-502 221514 221525 31-618 EFC10 ESTRK Part No. 31-102 31-102-1 31-102-2 31-102-3 31-102-4	Wall Panel circuit board ME: wall panel cover,white ME; wall panel gasket Cable for SPC wall panel ATO fuse 10A  EST/PST Repair Kit includes following Description Motor Shaft Seal (2) Macerator Seal Washer Macerator Retaining Ring Mixer Seal Washer Mixer Retaining Ring
59  DRA 24 27  28 29 30 31 32 33 34	31-304C AIN MANIFO 41-151A 42-145 43-145 41-137 41-151B 41-141 PLA3 41-139 41-138C 41-138 B	Hose clamp  LD ASSY 42-137W (12V) 43-137W (24V)  Adapter \(^1/_4\)" x \(^1/_2\)" elbow with check valve 12 Volt Pull Solenoid 24 Volt Pull Solenoid Drain Manifold assy.(with check valve)  Adapter \(^1/_4\)" x \(^1/_4\)" elbow with check valve  Adapter \(^1/_4\)" NPT x \(^1/_2\)" barbed \(^1/_4\)" Barbed x \(^1/_4\)" NPT Adapter  Cap, manifold \(^1/_4\)" x \(^3/_4\)" U cup seal  Plunger  Washer for plunger	80 81 82 83 84 86	SPCCHNT 41-502 221514 221525 31-618 EFC10 ESTRK Part No. 31-102 31-102-1 31-102-2 31-102-3 31-102-4 31-103	Wall Panel circuit board ME: wall panel cover, white ME; wall panel gasket Cable for SPC wall panel ATO fuse 10A  EST/PST Repair Kit includes following Description Motor Shaft Seal (2) Macerator Seal Washer Macerator Retaining Ring Mixer Seal Washer Mixer Retaining Ring Motor Shaft Bushing (2)
59  DRA 24 27  28 29 30 31 32 33 34 35	31-304C AIN MANIFO 41-151A 42-145 43-145 41-137 41-151B 41-141 PLA3 41-139 41-138C 41-138 B 41-138A	Hose clamp  LD ASSY 42-137W (12V) 43-137W (24V)  Adapter \(^1/_4\)" x \(^1/_2\)" elbow with check valve 12 Volt Pull Solenoid 24 Volt Pull Solenoid Drain Manifold assy.(with check valve) Adapter \(^1/_4\)" x \(^1/_4\)" elbow with check valve Adapter \(^1/_4\)" NPT x \(^1/_2\)" barbed \(^1/_4\)" Barbed x \(^1/_4\)" NPT Adapter Cap, manifold \(^1/_4\)" x \(^3/_4\)" U cup seal Plunger	80 81 82 83 84 86	SPCCHNT 41-502 221514 221525 31-618 EFC10 ESTRK Part No. 31-102 31-102-1 31-102-2 31-102-3 31-102-4 31-103 31-105	Wall Panel circuit board ME: wall panel cover,white ME; wall panel gasket Cable for SPC wall panel ATO fuse 10A  EST/PST Repair Kit includes following Description Motor Shaft Seal (2) Macerator Seal Washer Macerator Retaining Ring Mixer Seal Washer Mixer Retaining Ring Motor Shaft Bushing (2) O-Ring
59  DRA  24 27  28 29 30 31 32 33 34 35 36	31-304C AIN MANIFO 41-151A 42-145 43-145 41-137 41-151B 41-141 PLA3 41-138 41-138 B 41-138A F204	LD ASSY 42-137W (12V) 43-137W (24V)  Adapter <sup>1</sup> / <sub>4</sub> " x <sup>1</sup> / <sub>2</sub> " elbow with check valve 12 Volt Pull Solenoid 24 Volt Pull Solenoid Drain Manifold assy.(with check valve) Adapter <sup>1</sup> / <sub>4</sub> " x <sup>1</sup> / <sub>4</sub> " elbow with check valve Adapter <sup>1</sup> / <sub>4</sub> " NPT x <sup>1</sup> / <sub>2</sub> " barbed <sup>1</sup> / <sub>4</sub> " Barbed x <sup>1</sup> / <sub>4</sub> " NPT Adapter Cap, manifold <sup>1</sup> / <sub>4</sub> " x <sup>3</sup> / <sub>4</sub> " U cup seal Plunger Washer for plunger 6-32 x 3/8"" Flat head mach. screw(4)	80 81 82 83 84 86	SPCCHNT 41-502 221514 221525 31-618 EFC10 ESTRK Part No. 31-102 31-102-1 31-102-2 31-102-3 31-102-4 31-103 31-105 F351	Wall Panel circuit board ME: wall panel cover,white ME; wall panel gasket Cable for SPC wall panel ATO fuse 10A  EST/PST Repair Kit includes following Description Motor Shaft Seal (2) Macerator Seal Washer Macerator Retaining Ring Mixer Seal Washer Mixer Retaining Ring Motor Shaft Bushing (2) O-Ring 10-32x7/8" w/ O-ring (4)
59  DRA  24 27  28 29 30 31 32 33 34 35 36 37 38 39	31-304C  AIN MANIFO  41-151A 42-145 43-145 41-137 41-151B 41-141 PLA3 41-138C 41-138 B 41-138A F204 LWS F203 F233	LD ASSY 42-137W (12V) 43-137W (24V)  Adapter <sup>1</sup> / <sub>4</sub> " x <sup>1</sup> / <sub>2</sub> " elbow with check valve 12 Volt Pull Solenoid 24 Volt Pull Solenoid Drain Manifold assy.(with check valve) Adapter <sup>1</sup> / <sub>4</sub> " x <sup>1</sup> / <sub>4</sub> " elbow with check valve Adapter <sup>1</sup> / <sub>4</sub> " NPT x <sup>1</sup> / <sub>2</sub> " barbed <sup>1</sup> / <sub>4</sub> " Barbed x <sup>1</sup> / <sub>4</sub> " NPT Adapter Cap, manifold <sup>1</sup> / <sub>4</sub> " x <sup>3</sup> / <sub>4</sub> " U cup seal Plunger Washer for plunger 6-32 x 3/8"" Flat head mach. screw(4) Spring Washer 5/16" x 3/4" Spring Roll Pin	80 81 82 83 84 86	SPCCHNT 41-502 221514 221525 31-618 EFC10 ESTRK Part No. 31-102 31-102-1 31-102-2 31-102-3 31-102-4 31-103 31-105 F351 31-112	Wall Panel circuit board ME: wall panel cover,white ME; wall panel gasket Cable for SPC wall panel ATO fuse 10A  EST/PST Repair Kit includes following Description Motor Shaft Seal (2) Macerator Seal Washer Macerator Retaining Ring Mixer Seal Washer Mixer Retaining Ring Motor Shaft Bushing (2) O-Ring 10-32x7/8" w/ O-ring (4) Cover Gasket
59  DRA  24 27  28 29 30 31 32 33 34 35 36 37 38 39 50	31-304C  AIN MANIFO  41-151A 42-145 43-145 41-137 41-151B 41-141 PLA3 41-138C 41-138 B 41-138A F204 LWS F203 F233 41-187	LD ASSY 42-137W (12V) 43-137W (24V)  Adapter <sup>1/4</sup> , "x <sup>1/2</sup> ," elbow with check valve 12 Volt Pull Solenoid 24 Volt Pull Solenoid Drain Manifold assy.(with check valve) Adapter <sup>1/4</sup> , "x <sup>1/4</sup> ," elbow with check valve Adapter <sup>1/4</sup> , "NPT x <sup>1/2</sup> ," barbed <sup>1/4</sup> , "Barbed x <sup>1/4</sup> ," NPT Adapter Cap, manifold <sup>1/4</sup> , "x <sup>3/4</sup> ," U cup seal Plunger Washer for plunger 6-32 x 3/8"" Flat head mach. screw(4) Spring Washer 5/16" x 3/4" Spring Roll Pin Shaft Boot	80 81 82 83 84 86	SPCCHNT 41-502 221514 221525 31-618 EFC10  ESTRK Part No. 31-102-1 31-102-2 31-102-3 31-102-4 31-103 31-105 F351 31-112 31-113-2	Wall Panel circuit board ME: wall panel cover,white ME; wall panel gasket Cable for SPC wall panel ATO fuse 10A  EST/PST Repair Kit includes following Description Motor Shaft Seal (2) Macerator Seal Washer Macerator Retaining Ring Mixer Seal Washer Mixer Retaining Ring Motor Shaft Bushing (2) O-Ring 10-32x7/8" w/ O-ring (4) Cover Gasket Terminal Block Bolt (4)
59  DRA  24 27  28 29 30 31 32 33 34 35 36 37 38 39 50 53	31-304C  AIN MANIFO  41-151A 42-145 43-145 41-137 41-151B 41-141 PLA3 41-138C 41-138 B 41-138A F204 LWS F203 F203 F233 41-187 41-152	LD ASSY 42-137W (12V) 43-137W (24V)  Adapter 1/4" x 1/2" elbow with check valve 12 Volt Pull Solenoid 24 Volt Pull Solenoid Drain Manifold assy. (with check valve) Adapter 1/4" x 1/4" elbow with check valve Adapter 1/4" NPT x 1/2" barbed 1/4" Barbed x 1/4" NPT Adapter Cap, manifold 1/4" x 3/4" U cup seal Plunger Washer for plunger 6-32 x 3/8"" Flat head mach. screw(4) Spring Washer 5/16" x 3/4" Spring Roll Pin Shaft Boot Base Plate	80 81 82 83 84 86	SPCCHNT 41-502 221514 221525 31-618 EFC10  ESTRK Part No. 31-102-1 31-102-2 31-102-3 31-102-4 31-103 31-105 F351 31-112 31-113-2 31-114	Wall Panel circuit board ME: wall panel cover,white ME; wall panel gasket Cable for SPC wall panel ATO fuse 10A  EST/PST Repair Kit includes following Description Motor Shaft Seal (2) Macerator Seal Washer Macerator Retaining Ring Mixer Seal Washer Mixer Retaining Ring Motor Shaft Bushing (2) O-Ring 10-32x7/8" w/ O-ring (4) Cover Gasket Terminal Block Bolt (4) Cover Hold Down Nut, 10-32 (4)
59  DRA  24 27  28 29 30 31 32 33 34 35 36 37 38 39 50 53 54	31-304C  AIN MANIFO  41-151A 42-145 43-145 41-137 41-151B 41-141 PLA3 41-138C 41-138 B 41-138A F204 LWS F203 F203 F233 41-187 41-152 F232	LD ASSY 42-137W (12V) 43-137W (24V)  Adapter <sup>1/4</sup> , " x <sup>1/2</sup> ," elbow with check valve 12 Volt Pull Solenoid 24 Volt Pull Solenoid Drain Manifold assy.(with check valve) Adapter <sup>1/4</sup> , " x <sup>1/4</sup> ," elbow with check valve Adapter <sup>1/4</sup> , " NPT x <sup>1/2</sup> ," barbed <sup>1/4</sup> ," Barbed x <sup>1/4</sup> ," NPT Adapter Cap, manifold <sup>1/4</sup> , " x <sup>3/4</sup> ," U cup seal Plunger Washer for plunger 6-32 x 3/8"" Flat head mach. screw(4) Spring Washer 5/16" x 3/4" Spring Roll Pin Shaft Boot Base Plate 6-32 x 7/16" Flat head mach. screw (2)	80 81 82 83 84 86	SPCCHNT 41-502 221514 221525 31-618 EFC10  ESTRK Part No. 31-102-1 31-102-2 31-102-3 31-102-4 31-103 31-105 F351 31-112 31-113-2	Wall Panel circuit board ME: wall panel cover,white ME; wall panel gasket Cable for SPC wall panel ATO fuse 10A  EST/PST Repair Kit includes following Description Motor Shaft Seal (2) Macerator Seal Washer Macerator Retaining Ring Mixer Seal Washer Mixer Retaining Ring Motor Shaft Bushing (2) O-Ring 10-32x7/8" w/ O-ring (4) Cover Gasket Terminal Block Bolt (4)
59  DRA  24 27  28 29 30 31 32 33 34 35 36 37 38 39 50 53	31-304C  AIN MANIFO  41-151A 42-145 43-145 41-137 41-151B 41-141 PLA3 41-138C 41-138 B 41-138A F204 LWS F203 F203 F233 41-187 41-152	LD ASSY 42-137W (12V) 43-137W (24V)  Adapter 1/4" x 1/2" elbow with check valve 12 Volt Pull Solenoid 24 Volt Pull Solenoid Drain Manifold assy. (with check valve) Adapter 1/4" x 1/4" elbow with check valve Adapter 1/4" NPT x 1/2" barbed 1/4" Barbed x 1/4" NPT Adapter Cap, manifold 1/4" x 3/4" U cup seal Plunger Washer for plunger 6-32 x 3/8"" Flat head mach. screw(4) Spring Washer 5/16" x 3/4" Spring Roll Pin Shaft Boot Base Plate	80 81 82 83 84 86 62	SPCCHNT 41-502 221514 221525 31-618 EFC10  ESTRK Part No. 31-102-1 31-102-2 31-102-3 31-102-4 31-103 31-105 F351 31-112 31-113-2 31-114	Wall Panel circuit board ME: wall panel cover,white ME; wall panel gasket Cable for SPC wall panel ATO fuse 10A  EST/PST Repair Kit includes following Description Motor Shaft Seal (2) Macerator Seal Washer Macerator Retaining Ring Mixer Seal Washer Mixer Retaining Ring Motor Shaft Bushing (2) O-Ring 10-32x7/8" w/ O-ring (4) Cover Gasket Terminal Block Bolt (4) Cover Hold Down Nut, 10-32 (4) Super Lube
59  DRA  24 27  28 29 30 31 32 33 34 35 36 37 38 39 50 53 54	31-304C  AIN MANIFO  41-151A 42-145 43-145 41-137 41-151B 41-141 PLA3 41-138C 41-138 B 41-138A F204 LWS F203 F203 F233 41-187 41-152 F232	LD ASSY 42-137W (12V) 43-137W (24V)  Adapter <sup>1/4</sup> , " x <sup>1/2</sup> ," elbow with check valve 12 Volt Pull Solenoid 24 Volt Pull Solenoid Drain Manifold assy.(with check valve) Adapter <sup>1/4</sup> , " x <sup>1/4</sup> ," elbow with check valve Adapter <sup>1/4</sup> , " NPT x <sup>1/2</sup> ," barbed <sup>1/4</sup> ," Barbed x <sup>1/4</sup> ," NPT Adapter Cap, manifold <sup>1/4</sup> , " x <sup>3/4</sup> ," U cup seal Plunger Washer for plunger 6-32 x 3/8"" Flat head mach. screw(4) Spring Washer 5/16" x 3/4" Spring Roll Pin Shaft Boot Base Plate 6-32 x 7/16" Flat head mach. screw (2)	80 81 82 83 84 86 62	SPCCHNT 41-502 221514 221525 31-618 EFC10 ESTRK Part No. 31-102 31-102-1 31-102-2 31-102-3 31-102-4 31-103 31-105 F351 31-112 31-113-2 31-114 SL1CC	Wall Panel circuit board ME: wall panel cover,white ME; wall panel gasket Cable for SPC wall panel ATO fuse 10A  EST/PST Repair Kit includes following Description Motor Shaft Seal (2) Macerator Seal Washer Macerator Retaining Ring Mixer Seal Washer Mixer Retaining Ring Motor Shaft Bushing (2) O-Ring 10-32x7/8" w/ O-ring (4) Cover Gasket Terminal Block Bolt (4) Cover Hold Down Nut, 10-32 (4) Super Lube
59  DRA  24 27  28 29 30 31 32 33 34 35 36 37 38 39 50 53 54 55	31-304C  AIN MANIFO  41-151A 42-145 43-145 41-137 41-151B 41-141 PLA3 41-138C 41-138 B 41-138A F204 LWS F203 F233 41-187 41-152 F232 F231	LD ASSY 42-137W (12V) 43-137W (24V)  Adapter 1/4" x 1/2" elbow with check valve 12 Volt Pull Solenoid 24 Volt Pull Solenoid Drain Manifold assy. (with check valve) Adapter 1/4" x 1/4" elbow with check valve Adapter 1/4" NPT x 1/2" barbed 1/4" Barbed x 1/4" NPT Adapter Cap, manifold 1/4" x 3/4" U cup seal Plunger Washer for plunger 6-32 x 3/8"" Flat head mach. screw(4) Spring Washer 5/16" x 3/4" Spring Roll Pin Shaft Boot Base Plate 6-32 x 7/16" Flat head mach. screw (2) Spacer 6" x 5/32"	80 81 82 83 84 86 62	SPCCHNT 41-502 221514 221525 31-618 EFC10 ESTRK Part No. 31-102 31-102-1 31-102-2 31-102-3 31-102-4 31-103 31-105 F351 31-112 31-113-2 31-114 SL1CC HER (Not shows	Wall Panel circuit board ME: wall panel cover,white ME; wall panel gasket Cable for SPC wall panel ATO fuse 10A  EST/PST Repair Kit includes following Description Motor Shaft Seal (2) Macerator Seal Washer Macerator Retaining Ring Mixer Seal Washer Mixer Retaining Ring Motor Shaft Bushing (2) O-Ring 10-32x7/8" w/ O-ring (4) Cover Gasket Terminal Block Bolt (4) Cover Hold Down Nut, 10-32 (4) Super Lube
59  DRA  24 27  28 29 30 31 32 33 34 35 36 37 38 39 50 53 54 55	31-304C  AIN MANIFO  41-151A 42-145 43-145 41-137 41-151B 41-141 PLA3 41-138C 41-138 B 41-138A F204 LWS F203 F233 41-187 41-152 F232 F231	LD ASSY 42-137W (12V) 43-137W (24V)  Adapter \(^1/_4\)" x \(^1/_2\)" elbow with check valve 12 Volt Pull Solenoid 24 Volt Pull Solenoid Drain Manifold assy. (with check valve) Adapter \(^1/_4\)" x \(^1/_4\)" elbow with check valve Adapter \(^1/_4\)" NPT x \(^1/_2\)" barbed \(^1/_4\)" Barbed x \(^1/_4\)" NPT Adapter Cap, manifold \(^1/_4\)" x \(^3/_4\)" U cup seal Plunger Washer for plunger 6-32 x \(^3/8\)"" Flat head mach. screw(4) Spring Washer 5/16" x \(^3/4\)" Spring Roll Pin Shaft Boot Base Plate 6-32 x \(^7/16\)" Flat head mach. screw (2) Spacer 6" x \(^5/32\)" equipped with a 24VDC Macerator	80 81 82 83 84 86 62	SPCCHNT 41-502 221514 221525 31-618 EFC10 ESTRK Part No. 31-102 31-102-1 31-102-2 31-102-3 31-102-4 31-103 31-105 F351 31-112 31-114 SL1CC HER (Not show	Wall Panel circuit board ME: wall panel cover,white ME; wall panel gasket Cable for SPC wall panel ATO fuse 10A  EST/PST Repair Kit includes following Description Motor Shaft Seal (2) Macerator Seal Washer Macerator Retaining Ring Mixer Seal Washer Mixer Retaining Ring Motor Shaft Bushing (2) O-Ring 10-32x7/8" w/ O-ring (4) Cover Gasket Terminal Block Bolt (4) Cover Hold Down Nut, 10-32 (4) Super Lube  DWN) Purasan Tablets (Refill)
59  DRA  24 27  28 29 30 31 32 33 34 35 36 37 38 39 50 53 54 55  * 12V Motor	31-304C  AIN MANIFO  41-151A 42-145 43-145 41-137 41-151B 41-141 PLA3 41-138C 41-138 B 41-138A F204 LWS F203 F233 41-187 41-152 F232 F231	LD ASSY 42-137W (12V) 43-137W (24V)  Adapter 1/4" x 1/2" elbow with check valve 12 Volt Pull Solenoid 24 Volt Pull Solenoid Drain Manifold assy. (with check valve) Adapter 1/4" x 1/4" elbow with check valve Adapter 1/4" NPT x 1/2" barbed 1/4" Barbed x 1/4" NPT Adapter Cap, manifold 1/4" x 3/4" U cup seal Plunger Washer for plunger 6-32 x 3/8"" Flat head mach. screw(4) Spring Washer 5/16" x 3/4" Spring Roll Pin Shaft Boot Base Plate 6-32 x 7/16" Flat head mach. screw (2) Spacer 6" x 5/32"	80 81 82 83 84 86 62	SPCCHNT 41-502 221514 221525 31-618 EFC10 ESTRK Part No. 31-102 31-102-1 31-102-2 31-102-3 31-102-4 31-103 31-105 F351 31-112 31-113-2 31-114 SL1CC HER (Not show the	Wall Panel circuit board ME: wall panel cover,white ME; wall panel gasket Cable for SPC wall panel ATO fuse 10A  EST/PST Repair Kit includes following Description Motor Shaft Seal (2) Macerator Seal Washer Macerator Retaining Ring Mixer Seal Washer Mixer Retaining Ring Motor Shaft Bushing (2) O-Ring 10-32x7/8" w/ O-ring (4) Cover Gasket Terminal Block Bolt (4) Cover Hold Down Nut, 10-32 (4) Super Lube  DWN) Purasan Tablets (Refill) Treatment Unit Complete 12V