

Bonding order

- 1/ ESD protection wires: bond first pad 8, then 91*, then 196**
 - * After 91, bonding possible on pads 86 to 90 (Change request 26 July 2022)
 - ** Just before 196, bonding possible on pads 197
- 2/ GND wires (including IREF see table)
- 3/ Other wires

Pulltest pads: 153 to 162

ChipID pads: 43, 44

