

Encoders: 180 counts/revolution

Encoder Order: FR FL RR RL

Encoder Direction: Forward motion = positive

Lidar 0-angle is forward, rotation is counterclockwise from -135 to 135 degrees



