A1. Shutdown

A2. Close the valve.

B1. Restart

B2. Open the valve.

Section C. Limits

Part	Limit (bar)
Valve	12
Pump	8