

Channel Voice Message L'elenco completo

- 000 : Note Off
- 2. 001 : Note On
- 3. 010: Polyphonic Key Pressure
- 4. 011 : Control Change
- 5. 100 : Program Change
- 6. 101: Channel Pressure (tremolo)
- 7. 110: Pitch Bend Change (vibrato)