

Troubleshooting Guide

Problem

Battery not charging

Solution

Check charger cable.

Replace battery if charging cycles exceed 500.

Problem

High temperature alarm

Solution

Verify ventilation.

Reduce ambient temperature.

Restart device.

Problem

Network disconnected

Solution

Reconnect Ethernet cable.

Restart router.

Verify IP configuration.

Problem

Pump vibration detected

Solution

Stop operation.

Contact authorized engineer immediately.

Problem

Touchscreen not responding

Solution

Restart controller.

Update firmware.

Replace touchscreen if problem persists.