

Standard Operating Procedure

Preventive Maintenance

Frequency

Every Six Months

Checklist

Inspect pump.

Inspect batteries.

Inspect controller.

Update software.

Verify alarms.

Run diagnostics.

Engineer Responsibilities

Record maintenance log.

Replace worn components.

Update firmware.

Generate maintenance report.

Escalation

If pump vibration exceeds threshold,
stop device and contact Level 2 Support.