
Content Indexing	PDF Number of pages
01.Index	1
02.Change List	2
03.Block Diagram	3
04.Power tree-RK805-1	4
05.System Power-PMIC RK805-1	5
06.RK3328 Power	6
07.RK3328 OSC/PLL/OTP/SARADC	7
08.RK3328 DDR Controler	8
09.RK3328 eMMC Controler/TF/SPI	9
10.RK3328 USB2 PHY/USB3 PHY	10
11.RK3328 SDIO/UART/I2C/I2S/IR	11
12.RK3328 HDMI PHY	12
13.RK3328 AV Interface	13
14.RK3328 FEPHY	14
15.RAM DDR4 2x16bit	15
16.DC_IN/RECOWER	16
17.TF/SD Card/AT18	17
18.Flash-eMMC	18
19.USB Port	19
20.HDMI OUT Port	20
21.AV OUT Port	21
22.10/100M-Embed PHY	22
23.WIFI+BT_1T1R	23
24.Connector	24

Note:


- Component parameter description
 1. DNP stands for component not mounted temporarily
 2. If Value or option is DNP, which means the area is reserved without being mounted




Version	Date	Author	Change Note	Approved
V00	20170925	LZZ	First edictor	
				2
				www.t-firefly.com
				itle: <title></td></tr><tr><td></td><td></td><td></td><td>Fi</td><td>ile: <11(16> REV:<Rev</td></tr><tr><td></td><td></td><td></td><td>Cr</td><td>reate Date: Thursday, March 09, 2017 Page Num: 2</td></tr><tr><td></td><td>n pdfFactory Pro tr</td><td></td><td></td><td>odify Date: Monday, September 25, 2017 Page Total: 24</td></tr></tbody></table></title>





PDF created with pdfFactory Pro trial version www.pdffactory.com





PDF created with pdfFactory Pro trial version www.pdffactory.com

























PDF created with pdfFactory Pro trial version www.pdffactory.com














PDF created with pdfFactory Pro trial version www.pdffactory.com

