



Load Controller

Installation Guide

CONNECTING 'Load Controller and XPS Unit' to Circuit

1. Identify the installation location for the units.
2. A 60 Amp Breaker or higher must be used in conjunction with the 60 Amp Breaker located inside the Load Controller.
3. Connect the L1, L2 and L3 wires from the Xeco Unit to the 'Contactor Switch located in the Load Controller.
4. Connect 6-gauge THHN wire from the 60 Amp Breaker located in the Load Controller to the 60 Amp or Higher Breaker in the Sub-Panel or equipment.
5. Take the additional 'Serial Number' Barcodes and apply to the Circuit Identifier list and note the Panel Name.