

Design: Calculation on the coordinates

Data Preparation

- 1. Extract test data from TA's directory: % tar -xvf ~iclabTA01/Lab02.tar
- 2. The extracted Lab02/ directory contains:
 - a. Practice
 - b. Exercise


Design Description

Please design a circuit that supports three modes on a coordinate:

- (1) Trapezoid rendering.
- (2) Circle and line relationships.
- (3) Area computing.

Trapezoid rendering (Mode 0)

When the "in_valid" is at high level, pattern will send out the four sets of coordinates for the trapezoid in the order of (xul, yu), (xur, yu), (xdl, yd), (xdr, yd). After a period of circuit operations, the "out_valid" will be set to a high level, and the pattern will begin verifying the valid output coordinates (xo, yo) at every negative edge of the clock until "out_valid" is lowered. All valid output coordinates requirements are as follows:



In this design, you are required to output the coordinates covered by the trapezoid.

The output coordinate regulations:

- (1) If the bottom left coordinate or bottom right coordinate of a square is covered by the trapezoid, please output the coordinates of the bottom left corner of that square.
- (2) If the trapezoid exactly covers the bottom left coordinate of the square, please output the coordinates of the bottom left corner of that square.
- (3) The output order is from left to right, from bottom to up.

Here is an example:

Assume you receive four sets of coordinates in order from the pattern as follows:

$$(xul, yu) = (02,0C), (xur, yu) = (09,0C), (xdl, yd) = (00,00), (xdr, yd) = (10,00).$$


The valid output is: (00,00) (01,00) ... (10,00), (00,01) (01,01) ... (0F,01), (00,02) (01,02) ... (0E,02)

$$(00,03)$$
 $(01,03)$... $(0E,03)$, $(00,04)$ $(01,04)$... $(0D,04)$, $(00,05)$ $(01,05)$... $(0D,05)$,

$$(01,06)$$
 $(02,06)$... $(0C,06)$, $(01,07)$ $(02,07)$... $(0B,07)$, $(01,08)$ $(02,08)$... $(0B,08)$,

$$(01,09)$$
 $(02,09)$... $(0A,09)$, $(01,0A)$ $(02,0A)$... $(0A,0A)$, $(01,0B)$ $(02,0B)$... $(09,0B)$,

(02,0C) (03,0C) ... (09,0C).



Circle and line relationships (Mode 1) Integration

The relationships between circles and lines can be categorized into three types:

(1) Tangent, (2) Intersecting, (3) non-intersecting

When in valid is at high level, pattern will send out the four sets of coordinates in the **following order**:


First, you will obtain the two points (a1, a2) and (b1, b2) on the line.

Next will be the center of the circle (c1, c2), and finally, a point on the circle (d1, d2).


Please find out the relationships between circle and line:

■ To shorten the synthesis time for everyone, the input coordinates here will be limited to 6 bits.

	Description
Relation	Bestription
{xo, yo} = {00,00}	non-intersecting: (a1,a2) (c1,c2) (d1,d2) (b1,b2)
{xo, yo} = {00,01}	Intersecting: (c1,c2) (d1,d2) (b1,b2)



Area computing (Mode 2)



When in_valid is at high level, pattern will send out the four sets of coordinates in the **following order**:

$$(a1, a2) \Longrightarrow (b1, b2) \Longrightarrow (c1, c2) \Longrightarrow (d1, d2)$$

Please find out the area of the quadrilateral:

If the final answer has a decimal point, please round down!


System Integration |

Signals name	Direction	Bit Width	Definition
clk	input	1	Clock.
rst_n	input	1	Asynchronous active-low reset.
mode	input	2	Mode 0: Do trapezoid rendering. Mode 1: Derive the relationships between circle and line. Mode 2: Derive the area.
in_valid	input	Multimedia	High when input signals are valid.
xi	input	8	Input of the X coordinate, in two's complement form.
yi	input	8	Input of the Y coordinate, in two's complement form.
out_valid	output	1 EEC	High when output is valid.
хо	output	8	Mode 0: Output of the trapezoid X coordinate, in two's complement form. Mode 1: Set to 0. Mode 2: Area [15:8]
yo	output	8	Mode 0: Output of the trapezoid Y coordinate, in two's complement form. Mode 1: Relationships outcome. Mode 2: Area [7:0]

Specifications

- 1. Top module name: CC (Filename: CC.v)
- 2. It is an asynchronous reset and active-low architecture. If you use synchronous reset (reset after clock starting) in your design, you may fail to reset signals.
- 3. The clock period of the design is fixed to 12ns.
- 4. The next group of inputs will come in 2~5 cycles after your out valid pull down.
- 5. The synthesis result of data type cannot include any LATCH.
- 6. After synthesis, you can check CC area and CC timing in the folder "Report".
- 7. The slack in the timing report should be non-negative and the result should be MET.
- 8. The gate level simulation cannot include any timing violation.
- 9. The latency of your design in each pattern should not be larger than 100 cycles. The latency is the clock cycles between the falling edge of the in valid and the rising edge of the out valid.
- 10. Any words with "error", "latch" or "congratulation" can't be used as variable name.
- 11. The out valid cannot overlap in valid.

Block Diagram



Note

System Integration

1. Grading policy:

RTL and gate-level simulation correctness: 70% Performance (Area * Execution Cycle): 30%

- 2. Please submit your design through Lab02/09 SUBMIT/01 SUBMIT
 - 1st demo deadline: 2023/10/02(Mon.) 12:00:00
 - 2nd demo deadline: 2023/10/04(Wed.) 12:00:00
 - If uploaded files violate the naming rule, you will get 5 deduct points.
- 3. Template folders and reference commands:

01_RTL/ (RTL simulation) ./01_run_vcs_rtl
02_SYN/ (Synthesis) ./01_run_dc_shell


(Check the design if there's latch or not in *syn.log*) (Check the design's timing in /Report/ CC.*timing*)

03_GATE / (Gate-level simulation) ./01_run_vcs_gate

Sample Waveform

Trapezoid rendering:


■ Input signal:






• Circle and line relationships:


■ Input signal:



■ Output signal:



- Area computing:
 - Input signal:



Appendix

1. To find out the distance from a point $P(x_0, y_0)$ to line L: ax + by + c = 0, you may need the following equation:

d(P,L) =
$$\frac{|ax_0 + by_0 + c|}{\sqrt{a^2 + b^2}}$$

2. You may use the Surveyor's formula to compute area

The Surveyor's Formula. If the vertices of a simple polygon, listed counterclockwise around the perimeter, are $(x_0, y_0), (x_1, y_1), \dots, (x_{n-1}, y_{n-1})$, the area of the polygon is

$$A = \frac{1}{2} \left\{ \begin{vmatrix} x_0 & x_1 \\ y_0 & y_1 \end{vmatrix} + \begin{vmatrix} x_1 & x_2 \\ y_1 & y_2 \end{vmatrix} + \cdots + \begin{vmatrix} x_{n-2} & x_{n-1} \\ y_{n-2} & y_{n-1} \end{vmatrix} + \begin{vmatrix} x_{n-1} & x_0 \\ y_{n-1} & y_0 \end{vmatrix} \right\}.$$

Note that each oriented edge of the polygon corresponds to a 2×2 determinant in the surveyor's formula.