## **ATHENA**®

## **VPD**OME



1 Fill the shelving with freshly plugged trays of clones and close the magnetic doors. This is Day 1.

NOTE: If not filling the VPDome™ with 16 trays of clones, optimal environmental conditions will not be achieved inside the VPDome™. A small humidifier placed inside the cover can be used to make up that difference.



## **ATHENA**®

## **VPD**OME



**NOTE:** If the clone trays were pre soaked sufficiently, the clones should be fed again on Days 5, 7, 9, and 11 maintaining a 30-35% dryback.



2 On Day 2, the VPDome™ can be left closed all day to develop the proper humidity levels.





**NOTE:** Before folding the doors into thirds, spray and wipe with a solution of Athena® Reset at 7.8 mL per liter of water to prevent growth of pathogens.



**NOTE:** Colder environments outside the VPDome<sup>TM</sup> may create much higher levels of condensation so burping twice a day would be needed.



3 Day 3 and forward, burping is done for 5 to 20 minutes to ventilate the VPDome™ by leaving the magnetic doors half open with only the lower magnetic strips attached.