

UNDERSTANDING STORMWATER SAMPLING

As required by the Industrial Stormwater General Permit

SAMPLING BASICS



Sample stormwater from each designated location on your site at least once per quarter.



Have an accredited laboratory analyze your samples.



Submit an online **Discharge** Monitoring Report (DMR) to the Washington State Department of Ecology (Ecology) with your results.

BEFORE SAMPLING. YOU SHOULD KNOW...

Your permit requirements

- Which parameters apply to your facility (check section S5 of the permit)
- Number and location of of your facility's designated sampling locations

Where to send your samples

· Which laboratory your company uses

If you don't have one, find a local laboratory that is accredited for the analyses needed. Download the list of labs accredited by the WA Dept of Ecology (PDF): link.pwi.org/walabs

• Make sure your laboratory knows your samples are for the Industrial Stormwater General Permit

This will help ensure they follow sample preservation, analysis and data reporting requirements. Refer to "Issues you may want to cover with the lab" on page 8 of Ecology's Stormwater Sampling Manual (PDF): link.pwi.org/samplingmanual

SUPPLIES: sampling kit, rain gear, and PPE



Required parameters for ALL permits:

- Turbidity
- pН
- Total zinc
- Total copper
- Visible oil sheen



Additional parameters may be required, so be sure to check your permit requirements!

PROCESS OVERVIEW

Plan a sampling event



Sample your stormwater



Report your results

UNDERSTANDING STORMWATER SAMPLING

CONTINUED



PLANNING A SAMPLING EVENT

Gather sampling supplies

- Sampling bottles will be supplied by your lab. The number and type provided is based on your required parameters and number of outfalls.
- Ensure sampling personnel have appropriate personal protective equipment (PPE), wet weather gear, and a sampling kit.
- Confirm your lab is able to meet holding times and ask for expected turn-around time to get your analysis results.
 Make sure you will be able to submit your DMR on time!

Watch weather forecasts



- You should sample during the first 12 hours of stormwater runoff.
- You can sample any storm(s) during the first, second, and third guarters.
- You are required to collect a fourth quarter sample during the **first fall rain event**.



Sampling is not required outside of your normal business hours. However, if your business operates 24 hours a day, you must be prepared to sample at any time!

2 SAMPLING YOUR STORMWATER

For help on how to collect your samples, check out these resources:



Stormwater Sampling Manual: A guide for the Industrial Stormwater General Permit (PDF) by WA Dept of Ecology link.pwi.org/samplingmanual



Stormwater Sampling Techniques (instructional video) by Washington Stormwater Center link.pwi.org/samplingvideo

3 REPORTING YOUR RESULTS

Submit your results online through your WQWebDMR account

- Submit a DMR every quarter, even if there was no discharge to sample.
- You may take additional samples over the quarter and report average pollutant concentrations.
- You must report results from any sample taken from your discharge point(s).
 You do not need to report samples taken from other areas as part of source tracing.
- If you report pollutant concentrations that are above your benchmark limit, you must perform a Corrective Action. See our related technical assistance document, or the WA Dept of Ecology website, for more information.
- Submit your DMR to Ecology within 45 days of the end of the quarter. See table:

QUARTER	MONTHS	DMR DUE DATE
1st	Jan - Mar	May 15
2nd	Apr - Jun	Aug 15
3rd	Jul - Sep	Nov 15
4th	Oct - Dec	Feb 15



For assistance with the Water Quality Permitting Portal, contact the WA Dept of Ecology by email or phone:

WQWebPortal@ecy.wa.gov or 800-633-6193/option 3