Command Line Interface (CLI)

Most Often Used CLI Command	What it does
setTime hrs min sec	Sets current time
scan 0 1	Sets scanning ON or OFF
scanT sec	Sets how often to scan
reset	Resets/zeros all kWh

Supplementary CLI Commands	What it does
setSimulV volts	Set simulation V
setSimulw watts	Sets scanning ON or OFF
simul 0 1	Disable/Enable Simulation
setLVthrs value	Sets LV alarm
setOPthrs value	Sets OP alarm