


# **Owner's Manual**

# Retro fitment kit for MBP 38Ton Conventional Bogie Spring assembly.

**PART No: FTW00199** 



#### Works :-

Jamna Auto Industries Limited Plot No.22~25, Sengundram Village Maraimalai Nagar Industrial Complex, Melrosapuram, Singaperumal Koil Post, Pin – 603 204. Phone: 044-27463800.

## **CONTENTS**

Pre-Installation Notes	Dage 2
	- 3 -
Field Kit Specification Chart	- Dage 3
• • • • • • • • • • • • • • • • • • •	_
Configuration & work Instruction	Page 4
	_
Components Detail	Page 5
components betain	i age 5

**LEAF SPRING IDENTIFICATION:** JAMNA AUTO leaf spring assembly & Retro fitment kit are identified by a JAI Logo, Part no stenciled on tension side of leaf spring.


#### **Pre-Installation Notes:**

- 1. Suspension is designed to operate within specific parameters. Operating the suspension outside the design parameters may result in improper performance.
- 2. Improper locating of leaves on a spring assy. can affect the supporting component. The installer is responsible for correct location.
- 3. Welding and hammering are not permitted on the Leaves.
- 4. Use fasteners (i.e. Center Bolt, Clamp Bolt, Clamps) as mentioned in the field kit.
- 5. Ensure that all fasteners including center bolt, U Bolt, clamp bolt are tightened to the proper torque values.

# Field Kit Specification Chart: - (for OEM Part No.: FTW00199)

SECTION	90 x 27 (T/2)
MATERIAL GRADE	SUP 11A
LEAF LENGTH	300mm
PAINTING	To Withstand 300Hrs SSR

# **Before Retro-fitment**



#### **Configuration & Work Instruction:**

**Scope:** To remove 2 leaves in MBP-38Ton Bogie spring & Add two Bottom pack plate on OEM Part No.: FTW00199.


**Purpose:** To reduce spring stiffness.

**Tools Required**: Spanner, Torque wrench, Tongs, Hammer etc.

#### **Steps:**

- 1. Dismantle the assembly by loosening the centre bolt nut & clamp bolt nuts.
- 2. Remove 5<sup>th</sup> and 8<sup>th</sup> leaf from the assembly.
- 3. Add two bottom packing plate (90x27x300mm-2Nos), next to 10<sup>th</sup> leaf.
- 4. Place the other leaves in the same manner.
- 6. Don't assemble the used fasteners,
  Discard the removed Center bolt, Nut & Clamp- bolt & Nut.
- 7. Assemble the spring assembly by tightening the New Center bolt & Nut (M16x290mm & Nut M16), also tight the Clamp bolt Nuts. (M10x90 & Nut M10)
- 8. Center bolt Nut "M16" Torque: 250±20Nm
- 9. Clamp bolt Nut "M10" Torque: 60Nm.

#### After Retro-fitment the spring assy.



### Use the following components,

S.No.	Components	Item Code	Details	Qty.
1	Add-On BPP		90x27x300mm	02
2	Center Bolt	(COCB06242)	M16x290mm	01
3	C/Bolt Nut	(COMT00505)	M16	01
4	Clamp bolt	(CMP00122)	M10x1.25x90mm	02
5	Hex. Nyloc Nut	(CONT00507)	M10x1.25	02

## Do's

- 1. Add the add-on pack plate to the spring assembly.
- 2. Torque the center bolt nut with specified torque.
- 3. Always use proper torque for U-bolts.

# **Dont's**

- 1. Never hammering on leafs.
- 2. Don't heat the leaves with gas welding torch or with any other means.

