GCS Main Login

Click to upload waypoints from saved file(.pln).

Click to go to settings window. for trims adjustment and gain tunning and other settings of GCS.

Click to go to Mission Planner.

Click to upload map file (.bmp).

Menu

Plan

Upload Map Upload WayPoints Settings

Mission Status

IAS:

SOG:

Heading:

Altitude:

A.O.A

Pitch Angle:

Roll Angle:

Yaw Angle:

1

GCS Login

User Name: ABC

Password: *****

Sign In

Click to SignIn to GCS.

Click to open widget setup, where you can select parameters and widgets you want to display.

Designed By: Waqas Rauf Khattak

1. MainLogin_GCS

#	Note
1	Need of login in this GCS is becuase we need to manage the list of individuals who are authorized to use GCS. GCS is a very critical part of UAV.