## Airfield Map effective June 2025 Drawn By: Creative Triangle Version: 12.0 © Heathrow Airport Limited 27R Glidepath 09R Localiser Localiser 21f 21d 17c S6 SY6 15b 09R Glidepath 27L Glidepath **VEHICLES USING UNCONTROLLED CROSSING MUST GIVE WAY TO ALL AIRCRAFT AND VEHICLES ON** THE TAXIWAY **Hot spots** 1 Concealed stand whilst travelling from west to **Airfield information** east on taxiway Bravo Aircraft Operations Unit (AOU) 020 8745 6033 2 Drivers must obey the vehicle 020 8745 6459 Airfield Operations barrier system serving taxiways Alpha / Mike and must not drive Metropolitan Police 020 8745 7555 Airfield Duty Manager (AFDM) 020 8745 7373 around lowered barrier **Key**□□ 09L/27R & 09R/27L Runways Emergency Assistance 222 (Internal Landline Phone) 3 Uncontrolled crossing for Emergency Assistance 020 8759 1212 Code D Taxiway restricted vehicles only ILS Critical Areas Code C Taxiway (All other phones) Uncontrolled Taxiway crossing Emergency Vehicle Rendezvous Point Ao Airfield Operations Tunnel **Speed restrictions** No pier service ▲ Helicopter Aiming Point Airside Roads 20/10mph 216 Pier service Control post Aircraft Stands and Interstand Clearway 5mph 20/30mph Code F Taxiway Cargo Tunnel, Links Roads 6 Crash Gate Manoeuvring area 40mph Code E Taxiway