VF Asia Footwear Laboratory Testing Manual

Test Method for Colorfastness to Water	Test method # VF- E01 REF # : TM-R- 008 Page 1 of 2
Date Issued : May 27, 2008 Revision # : Reason for revision: NOTE: Timberland aligned with VF test method on drying time from 18 hours to 6 hours and test both sides of material.	Created by : Nila Babia Erazo / Chris Adam

PURPOSE AND SCOPE: To measure the tendency of dyestuffs and other colorants to migrate from a test material, as a result of contact with water.

REFERENCE: AATCC 107

EQUIPMENT AND MATERIAL:

1. Multi-fiber fabric A
2. Immersion dish
3. Distilled water
4. Paper towel
5. Oven capable of maintaining a temperature of 38+/-1°C.
6. AATCC Chromatic Transference Scale.
7. Perspiration tester B.
8. Fabric, Leather, and synthetic leather.

SAMPLE PREPARATION:

1. Condition the sample for at least 24 hours at the standard laboratory environment at 23.0±2.0 ˚C temperature and 55 ±10 % Relative Humidity.

2. Die or hand cut a piece of the test material and a multi-fiber fabric a minimum of 2 cm in width by 5 cm in length, to a maximum of 5.7cm*5.7cm. Place the test material directly on top of the multi-fiber fabric, (If both sides of the test material are to be evaluated, test the second side separately from the first. That is, prepare a second test material /multi-fiber lay-up with the other side of the test material contacting the multi-fiber fabric, and test separately.)

REPETITIONS: Test one (1) sample per material.

Note: The following surfaces should be tested:

Fabric = Top side/finished surface only

Leather = Both sides

Synthetic = Both sides

Test Method for Colorfastness to Water	Test method # VF- E01 REF # : TM-R- 008 Page 2 of 2
Date Issued : May 27, 2008 Revision # : Reason for revision: NOTE: Timberland aligned with VF test method on drying time from 18 hours to 6 hours and test both sides of material.	Created by : Nila Babia Erazo / Chris Adam

TEST PROCEDURE:

Test should be conducted at standard laboratory conditions @ 23.0±2.0 ˚C temperature and 55 ±10 % Relative Humidity.

1. Immerse the test material and multi-fiber fabric lay-up in distilled water at 23+/-2 º C. Place a glass or plastic plate directly on top of the lay-up to insure that the test material and multi-fiber fabric remain in contact and are fully sub-merged in the water. Agitate the water occasionally to insure thorough wetting. Remove the test sample lay-up from the water after 15 minutes.
2. Remove excess water from the test sample lay-up by lightly wiping the surface with a paper towel or tissue. Whenever possible, the wet weight of the test sample should be 2.5-3 times its dry weight.
3. Immediately place the test material and multi-fiber fabric lay-up between two of the plastic plates from the perspiration tester. Insert the plastic plates into the perspiration tester, and place the metal compensating plate and a 10.0 pound (4.54kg) weight on top of the plastic plates.

Note: Multiple test materials can be tested at the same time by stacking them on top of each other in the perspiration tester, provided a plastic plate always separates each of the test material lay-ups.

4. Place the perspiration tester in an oven at 38+/-1 º C for 6 hours.
5. Separate the test material from the multi-fiber fabric and completely dry at a temperature no greater than 60 º C.
6. Evaluate colorfastness by rating the color of each of the multi-fiber test fabrics in comparison to the AATCC Chromatic Transference Scale. The evaluation must be performed under normal daylight.

Note: Chromatic Transference Scales must be replaced at least every 12 months.

REPORT: The value of the lowest rated multi-fiber fabric to the nearest 0.5, according to the AATCC Chromatic Transference Scale.