VF Asia Footwear Laboratory Testing Manual

Test Method for Hydrostatic Waterproofness	**Test method # VF- G08** **REF # : TM-R-018** **Page 1 of 2**
Date Issued : August 28, 2014 **Revision # :**	**Created by : Nila Babia Erazo / Chris Adam**

PURPOSE AND SCOPE: To determine the waterproofness of materials containing a waterproof membrane.

REFERENCE: None

EQUIPMENT AND MATERIAL:

1. Pfaff hydrostatic pressure tester
2. Timer
3. Material to be tested for waterproofness

SAMPLE PREPARATION:

Condition the sample for at least 24 hours at the standard laboratory environment at 23.0±2.0˚C Temperature and 55 ±10 % Relative Humidity to allow the cement to crosslink completely.

PROCEDURE:

1. Testing shall be conducted in a standard laboratory environment of 23 ± 2°C and 55 ± 10 % RH.
2. Cut a section of material large enough to fit over the clamping area of the hydrostatic pressure tester.
3. Fill the hydrostatic pressure tester with water such that the water level is even with the gasket on the clamping stage. In order to prevent an air pocket from becoming trapped, the release valve should be left open, and the pressure tester should be tilted while filling. Air bubbles can be seen in the plastic hose between the clamping stage and the pressure bulb, and should be eliminated prior to testing material.
4. Place the test fabric on the clamping stage, taking care not to trap air under the material.
5. Clamp the material in place.
6. Apply pressure by compressing the pressure bulb.
7. The pressure should be increased to 0.4 bar (5 psi) and held for a period of five minutes.

Test Method for Hydrostatic Waterproofness	Test method # VF- G08 REF # : TM-R-018 Page 2 of 2
Date Issued : August 28, 2014 Revision # :	Created by : Nila Babia Erazo / Chris Adam

8. Examine the material for water droplets. If water droplets appear on the material, it has failed the test.

REPORT:

1. Report the material description.
2. Applied pressure, test duration.
3. A pass/fail value.
4. Any deviations from this procedure.