# Transfer ELD Data

Transferring driver log book information through the Federal Database is easy from both OneView and from POV on the driver's tablet.

## **POV Transfer ELD Data**

If a driver is asked to transfer their log data to law enforcement during a roadside inspection, the driver has the ability to transfer their log data directly from the tablet.

### Steps to Transfer ELD Data

1. Tap on the ELD transfer button in the top menu.




2. Choose Jurisdiction if applicable



## U.S. Transfer ELD

- 1. Method: keep as Web Services unless otherwise instructed.
- 2. Duration: keep as Last 7 days and today
- Comment: add the information that the officer requests you to add (their digital ID).
- 4. Choose Transfer ELD Data


\*\*Wired tablets (Cab-Mate One or Cab-Mate Connect) must be secured in the cradle with the engine on and running so the tablet has a data connection in order to send log records to an officer.



#### Canada Transfer ELD

- 1. Method: keep as email
- Duration: choose the appropriate duration for your cycle.
- 3. Email Address: add the officer's email address. They will give that information to you.
- 4. Comment: add the requested comment as requested by the officer
- 5. Tap Transfer ELD Data

\*\*Wired tablets (Cab-Mate One or Cab-Mate Connect) must be secured in the cradle with the engine on and running so the tablet has a data connection in order to send log records to an officer.




\*\*NOTE In order for the transfer to complete, there must be a data signal to POV, either through the cell data for Cab-Mate Open tablets, or the Cab-Mate One and Cab-Mate Connect must be in the cradle with the truck ignition on or on a WiFi connection.

### OneView Transfer ELD Data

If an auditor or law enforcement official requests a driver's log data, you can transfer this data directly from OneView though the Federal Database.

## Steps to Transfer ELD Data


- 1. Click on the Compliance Tab in OneView.
- 2. Click the Transfer ELD button at the top left, directly above the Compliance Percentage pie chart.




3. Choose the driver's jurisdiction if you have that option. If not, the jurisdiction will default to United States or Canada (if you have permission to both, you can choose. Otherwise you will only see one option based on your jurisdiction).



4. From the Transfer ELD Data window choose which method – Web Services or Email (the Federal Database for US jurisdictions will default to Web Services. Leave it unless directed to choose email by the officer or auditor. If you are the Canada jurisdiction, it will default to email and not give you a choice.




5. Choose your driver. You can only Transfer ELD Data one driver at a time. If you need to send multiple drivers, repeat this process for each driver individually if they require separate timeframes, or select multiple drivers if they require the same timeframe.






6. Choose the Record Timeframe as requested by the officer or auditor.




#### Email Address: Canada Required

If you are sending to Canada jurisdiction, you will need to add the email address of the auditor/officer.



7. Enter a Comment in the Comment line. The officer will give you this information which will allow the officer to pull up the log data as they access the Federal Database.



8. When everything is entered, choose Transfer.