

## **Prerequisites**

#### **Required Information**

- Name of asset (ex: Trailer #20)
- Detailed information about the asset (year, make, model, SN/VIN, license plate, etc.)
- State, area, organization, or group the asset belongs to (ex: North Region, MN trailers, etc.)
- ESN of each device to be installed (8 digit ESN is found on the front of each unit with a barcode)

#### **Required Equipment**



GT2

# **Required Tools**

Drill and assorted drill bits (to secure Protective Mount - if ordered)

Slotted and Philips Torx bits (to secure Protective Mount - if ordered)

# **Before You Begin**

#### TURN TO THE LAST PAGE - WRITE DOWN THE REQUIRED INFORMATION!!!

- Decide where the GT2 will be located. It needs to be able to face the sky.
- Flat, horizontal mounting is best, vertical mounting can be acceptable if unobstructed.
- Determine if mounting by VHB or secured with the mount and screws.
- Do not paint, pressure wash, or otherwise obstruct the surface of the device.

**PedigreeTechnologies.com** | Support: (701)-499-0022



### **Installation**

#### **STEP ONE - DEVICE POWER**

On the front side of the telematics device, using the pull tab, remove the magnet while outdoors with a good sky view. The GT2 will flash its LED indicator green 5 seconds after magnet is pulled.

# THIS SIDE SKYWARD DO NOT PAINT OR COVER 00092007

### **To Suspend Device Operation**


To put the GT2 back into inventory storage mode, reinsert the pull tab magnet back into the device magnet slot. The GT2 will flash its LED indicator red 5 seconds after magnet insertion.

NOTE: Saving the pull tab magent is recommended.

#### **STEP TWO - MOUNT TELEMATICS DEVICE**

The telematics device should be mounted on the exterior of the asset, free from any obstructions. **THE SOLAR PANEL MUST HAVE A CLEAR VIEW TO THE SKY.** 

Clean the area and prep with the adhesion promoter\* \*recommended, but not provided.







#### **STEP THREE - OPTIONAL PROTECTIVE MOUNT**

If using the protective housing mount instead of the peel and stick VHB, place the mount bracket over the telematics device. Secure with user provided hardware.

#### Recommended hardware:

- 3/8" Socket-head cap structural screws
- 3/8" Hex-head cap structural screws
- 1/4" Self-drilling sheet metal screws

PedigreeTechnologies.com | Support: (701)-499-0022



# **Testing / Confirmation Steps**

#### **STEP FOUR**

Record the GT2 8-digit numerical serial number (ESN) in the form below.



#### **STEP FOUR**

Call Pedigree Technologies installation support to confirm and finalize the installation.

# 701-499-0022 You will be prompted for the following information during the set up process **Device ESN** Name of Asset (ex. Goosneck 51) Trailer make and model VIN# License plate # Mileage Hours