

Prerequisites

Required Information

- Name of asset (ex: Propane Truck #20)
- Detailed information about the asset (year, make, model, VIN, license plate, etc.)
- State, area, organization, or group the asset belongs to (ex: North Region, MN tankers, etc.)
- ESN of each device to be installed (ESN is found on the back of each unit with a barcode)
- Current hour reading

Required Equipment





Adhesive Tape

Required Tools

Rubbing Alcohol - to clean the mounting area

Before You Begin

TURN TO THE LAST PAGE - WRITE DOWN THE REQUIRED INFORMATION!!!

- Decide where the device will be located. It needs the ability to face the sky.
- Do not paint, pressure wash, or otherwise obstruct the surface of the device.

PedigreeTechnologies.com | Support: (701)-499-0022



Installation



STEP ONE

Record the 10 digit ESN number from the back of the device. You will need this information when activating the device.

STEP TWO- MOUNT DEVICE

Decide on a mounting location and clean the surface with rubbing alcohol. Use the provided double sided tape to secure device.



STEP THREE-

If using the device bracket, use the double sided tap on the back of the bracket to adhere it to the asset. Then snap the device into the bracket.





PedigreeTechnologies.com | Support: (701)-499-0022



Installation continued

CHECK POWER

This device arrives already powered up. If you ever want to check a device in the future to ensure it is powered up, tap a magnet in the location pictured on the right, for *less than 2 seconds* and the light will flash red twice if it is power off, or blue twice if the unit is powered on.

Red flash = off Blue flash = on



Testing / Confirmation Steps

STEP FOUR

Call Pedigree Technologies installation support to confirm and finalize the installation.

701-499-0022 You will be prompted for the following information during the set up process Device ESN Name of Asset (ex. Goosneck 51) Trailer make and model VIN # License plate # Mileage Hours