

Prerequisites

Required Information [*needed for final activation of hardware - see last page]

- Name of asset* (ex: Propane Truck #20)
- Detailed information about the asset* (year, make, model, VIN, license plate, etc.)
- State, area, organization, or group the asset belongs to (ex: North Region, MN tankers, etc.)
- ESN of each device to be installed* (ESN is found on the back of each unit with a barcode)
- Current odometer reading
- Type of diagnostics connector, if possible (6 pin, 9 pin square flange, 9 pin round threaded, J1962, Type II, etc.)

Required Equipment



Cradle/LMU



Tablet



Cradle Mount



- (5) #8 Self-tapping Screw 3/4 inch
- (5) M4 Screw 12mm
- (5) M4 Screw 8mm
- (5) M4 Steel Nut
- (11) M4 Star Lock Washer
- (2) M4 Tamper Resistant Button Head HEX Screw 20MM

Diagnostics Y Cable**

Hardware Pack

** Diagnostics Y Cables will vary depending on make, model, year of vehicle. The cable pictured may not be the exact cable shipped.

Driver Using Electronic Logs Pedigree Technologies.com 800.470.8581 CineView Pedigree Technologies

In-Cab Readiness Kit

(booklet, stickers, DOT reference card)

Required Tools

- Drill and assorted drill bits (ex. to mount cradle)
- Slotted, Philips, and/or Torx bits (you may need tamper resistant Torx bits)
- Panel removal tool or plastic pry bar (to remove dash panel(s) as needed)
- · Small socket set
- **Zip Ties** (to hold cabling in place)

PedigreeTechnologies.com | Support: (701)-499-0022





TURN TO THE LAST PAGE - WRITE DOWN THE REQUIRED INFORMATION!!!

- Decide where the hardware components will be located. If necessary remove any dash panels with removal tool.
- Must be within reach of the diagnostic cable to be installed.
- Must be protected from moisture, excessive dust/dirt, heat (away from heater vents) and unobtrusive to driver operation or field of view.
- Routing of the cable between the factory diagnostic port and the telematics device does not cause excessive bending/kinking or areas where vibration may jeopardize the integrity of the hardware.
- Cabling must not impede function of any rotating or moving parts (ex. Steering mechanisms, wiper mechanisms, or brake pedal)
- Ensure that the mounting location has enough integrity to accommodate the additional weight and vibration of the device.

Attach and Mount Cradle

STEP ONE

Attach the Cradle Mount to the back of the Cradle/LMU. Use the four short machine screws and star lockwashers.







Cradle/LMU



Cradle Placement Example

STEP TWO

Attach the Cradle Mount to the vehicle dash in a location where the driver can easily view without obstuction.

Optional: Use the (2) 20MM HEX screws to secure the tablet to the cradle. **Note:** the driver will not be able to remove the tablet from the cradle.

PedigreeTechnologies.com | Support: (701)-499-0022



Connect to Asset Diagnostics Cable

Diagnostics Y Cables will vary depending on make, model, year of vehicle. The cable pictured may not be the exact cable shipped. Be sure to verify that the Diagnostics Y Cable that you are installing is the correct cable for this asset.



STEP ONE

Remove the vehicles's factory diagnostics cable from its factory mount.

STEP TWO

Connect the factory diagnostics cable to the Female Diagnostics Connector of the Diagnostics Y Cable (rotate clockwise until it "clicks")



STEP THREE

Replace the factory diagnostics cable with the Male Diagnostics Connector of the Diagnostics Y Cable by installing it into the factory location previously occupied by the factory diagnostics cable.



JBus style factory diagnostics port

PedigreeTechnologies.com | Support: (701)-499-0022



Connect Diagnostics Cable to Cradle

STEP FOUR

Run the 16 pin Molex connector to the location of the telematics device.



STEP FIVE

Connect the 16 pin Molex connector to the bottom of the telematics device.



Bottom View of Cradle/LMU



Testing / Confirmation Steps

STEP ONE <u>Start</u> the vehicle. While the engine is running, the CabMate-One should run through its boot cycle automatically. The Comm and GPS lights will flash and then turn solid. When they are solid, move on to the next step. (The Vehicle light may flash or may go solid, depending on the vehicle type.)



Comm - Solid Yellow/Orange

GPS - Solid Green

VEH - Solid or Blinking Red (Depends on Vehicle)

AUX - Not Used

Front cradle light is ELD Malfunction Indicator - will flash red when tablet/driver not connected. Should be flashing when ignition on and running for this installation.

STEP TWO Call Pedigree Technologies support to confirm installation <u>before</u> replacing any of the dash panels you may have removed during cable installation.

Install Confirmation: 701-499-0022 You will be prompted for the following information during the set up process Device ESN Name of Asset (ex. Service Truck 51) Year, make, and model VIN # License plate # Mileage Hours