TR-064 Support - LANHostConfigManagement1

Supported by AVM

Author: AVM GmbH Date: 2015-11-20

urn:LANHostConfigManagement-com:serviceld: LANHostConfigManagement1

For details please refer the TR-064 document at https://www.broadband-forum.org/technical/download/TR-064.pdf .

History

Date	Version	Changes
2015-11-19	7	Correct duplicated parameter NewSubnetMask in action GetInfo
2015-11-20	8	Formatting, url for TR-064 specification

Action List

This chapter contains the supported actions of the service LAN host configuration management which are listed incl. arguments.

GetInfo

Argument name	Direction	Related state variable	Remarks
NewDHCPServerConfigurable	out	DHCPServerConfigurable	
NewDHCPRelay	out	DHCPRelay	
NewMinAddress	out	MinAddress	
NewMaxAddress	out	MaxAddress	
NewReservedAddresses	out	ReservedAddresses	
NewDHCPServerEnable	out	DHCPServerEnable	
NewDNSServers	out	DNSServers	
NewDomainName	out	DomainName	2009-03-06
NewIPRouters	out	IPRouters	2009-03-06
NewSubnetMask	out	SubnetMask	2009-03-06

Table 1: Argument list of action GetInfo

SetDHCPServerEnable

Argument name	Direction	Related state variable	Remarks
NewDHCPServerEnable	in	DHCPServerEnable	

Table 2: Argument list of action SetDHCPServerEnable

SetSubnetMask

Argument name	Direction	Related state variable	Remarks
NewSubnetMask	in	SubnetMask	2009-03-06

Table 3: Argument list of action SetSubnetMask

GetSubnetMask

Argument name	Direction	Related state variable	Remarks
NewSubnetMask	out	SubnetMask	2009-03-06

Table 4: Argument list of action GetSubnetMask

SetIPRouter

Argument name	Direction	Related state variable	Remarks
NewIPRouters	in	IPRouters	2009-03-06

Table 5: Argument list of action SetIPRouter

GetIPRoutersList

Argument name	Direction	Related state variable	Remarks
NewIPRouters	out	IPRouters	2009-03-06

Table 6: Argument list of action GetIPRoutersList

SetIPInterface

Argument name	Direction	Related state variable	Remarks
NewEnable	in	Enable	Only 'true' supported
NewIPAddress	in	IPAddress	
NewSubnetMask	in	SubnetMask	
NewIPAddressingType	in	IPAddressingType	Only 'Static' supported

Table 7: Argument list of action SetIPInterface

GetAddressRange

Argument name	Direction	Related state variable	Remarks
NewMinAddress	out	MinAddress	
NewMaxAddress	out	MaxAddress	

Table 8: Argument list of action GetAddressRange

SetAddressRange

Argument name	Direction	Related state variable	Remarks
NewMinAddress	in	MinAddress	
NewMaxAddress	in	MaxAddress	

Table 9: Argument list of action SetAddressRange

GetIPInterfaceNumberOfEntries

Argument name	Direction	Related state variable	Remarks
NewIPInterfaceNumberOfEntries	out	IPInterfaceNumberOfEntries	

Table 10: Argument list of action GetIPInterfaceNumberOfEntries

GetDNSServer

Argument name	Direction	Related state variable	Remarks
NewDNSServers	out	DNSServers	

Table 11: Argument list of action GetDNSServer

Service States Table

Variable name	Send events	Allowed values (* == default)	Data type
DHCPServerConfigurable	no		Boolean
DHCPRelay	no		Boolean
MinAddress	no		String
MaxAddress	no		String
ReservedAddresses	no		String
DHCPServerEnable	no		Boolean
Enable	no		Boolean
IPAddress	no		String
IPAddressingType	no		String
SubnetMask	no		String
DNSServers	no		String
DomainName	no		String
IPRouters	no		String
IPInterfaceNumberOfEntri es	no		ui2

Table 12: Variable list