GISWATER CHANGELOG 3.5 – DB MODEL TABLES & VIEWS

OLD NAME	NEW NAME	PROJECT TYPE	OLD NAME	NEW NAME	PROJECT TYPE
	audit_fid_log	utils	inp_node_type	sys_feature_epa_type	utils
	crm_typevalue	utils	v_edit_vnode	v_vnode	utils
config_form_actions	config_typevalue	utils		ve_visit_gully_singlevent	ud
	config_function	utils	config_form	deleted	utils
config_mincut_checkvalve	config_graf_checkvalve	ws	config_form_groupbox	deleted	ws
config_mincut_inlet	config_graf_inlet	ws	inp_flwreg_type	deleted	ud
config_mincut_valve	config_graf_valve	ws	inp_rules_controls_importinp	deleted	ws
	config_table	utils	om_visit_parameter_index	deleted	utils
inp_arc_type	sys_feature_epa_type	utils			

GISWATER CHANGELOG 3.5 – DB STORED PROCEDURE

OLD NAME	NEW NAME	PROJECT TYPE	OLD NAME	NEW NAME	PROJECT TYPE
	gw_fct_anl_slope_consistency	ud	gw_fct_feature_delete	gw_fct_setfeaturedelete	utils
	gw_fct_debugsql	utils	gw_fct_feature_replace	gw_fct_setfeaturereplace	utils
	gw_fct_getaddfeaturevalues	utils	gw_fct_flow_exit	gw_fct_grafanalytics_downstream	ud
gw_fct_check_delete	gw_fct_getcheckdelete	utils	gw_fct_flow_exit_recursive	gw_fct_grafanalytics_downstream_recursive	ud
	gw_fct_getgeomfield	utils	gw_fct_flow_trace	gw_fct_grafanalytics_upstream	ud
	gw_fct_getpkeyfield	utils	gw_fct_flow_trace_recursive	gw_fct_grafanalytics_upstream_recursive	ud
	gw_fct_getstyle	utils	gw_fct_connect_to_network	gw_fct_setlinktonetwork	utils
	gw_fct_json_create_return	utils		gw_fct_setmapzonestrigger	ws
gw_fct_arc_divide	gw_fct_setarcdivide	utils	gw_fct_node_builtfromarc	gw_fct_setnodefromarc	utils
gw_fct_arc_fusion	gw_fct_setarcfusion	utils		gw_fct_user_check_data	utils
	gw_fct_setchangevalvestatus	ws	gw_fct_admin_schema_copy	deleted	utils
gw_fct_audit_check_project	gw_fct_setcheckproject	utils	gw_fct_check_importdxf	deleted	utils
	gw_fct_setcsv	utils	gw_fct_edit_check_data	deleted	utils
gw_fct_update_elevation_from_dem	gw_fct_setelevfromdem	utils	gw_fct_getinsertfeature	deleted	utils
	gw_fct_setendfeature	utils	gw_fct_insert_importdxf	deleted	utils

GISWATER CHANGELOG 3.5 – DB MODEL USER VARIABLES

OLD NAME	NEW NAME	PROJECT TYPE	OLD NAME	NEW NAME	PROJECT TYPE
edit_upsert_elevation_from_dem	edit_insert_elevation_from_dem	utils	qgis_qml_pointlayer_path	deleted	utils
edit_upsert_elevation_from_dem	edit_update_elevation_from_dem	utils	qgis_qml_polygonlayer_path	deleted	utils
om_mincut_analysis_dinletsector	deleted	ws	qgis_toolbar_hidebuttons	deleted	utils
om_mincut_analysis_dminsector	deleted	ws	virtual_line_vdefault	deleted	utils
om_mincut_analysis_pipehazard	deleted	ws	virtual_point_vdefault	deleted	utils
qgis_qml_linelayer_path	deleted	utils	virtual_polygon_vdefault	deleted	utils