Voltage-to-Current Transducer

 \mathbf{vct}



 $\label{thm:continuous} \mbox{Figure 1: Voltage-to-Current Transducer element.}$

Form: $vct:\langle instance\ name \rangle\ n_1\ n_2\ n_3\ \langle parameter\ list \rangle$

 n_1 , n_2 and n_3 are the element nodes.

Parameters:

Parameter	Type	Default value	Required?
gamma: Element parameter	DOUBLE	n/a	yes
beta: Element parameter	DOUBLE	n/a	yes
kf: Element parameter	DOUBLE	n/a	yes
poly: Element parameter	DOUBLE VECTOR	See source file.	no

Example:

vct:a11 1 3 2 gamma=-2.3 beta=8 kf=0.0025 poly = <5.979287283058695e-4 -2.334033466242205e-02 6.282215276145409e-02 -4.319540162756818e-02 9.169340904889009e-03>

Notes:

There is no SPICE compatible element.

Version: 2000.09.01

Credits:

Name Affiliation Date Links
Mark Summers and Carlos E. Christofferson Cechrist@ieee.org

Affiliation Date Links
NC State University Sept 2000

www.ncsu.edu