Amplitude Modulated Current Source

iam



Figure 1: Independent Current Source Element.

Form: iam: $\langle instance name \rangle n_1 n_2 \langle parameter list \rangle$

 n_1 is the positive element node,

 n_2 is the negative element node.

Parameters:

Parameter	Type	Default value	Required?
oc: Offset Constant (Dimensionless)	DOUBLE	0	no
sa: Signal amplitude (V)	DOUBLE	0	no
fcarrier: Carrier frequency (Hz)	DOUBLE	0	no
fmod: modulation frequency(Hz)	DOUBLE	0	no
td: Time Delay (seconds)	DOUBLE	0	no

Example:

iam:isignal 8 0 oc=1 sa=10 fcarrier=1K fmod=100 td=1m

iam:i2 8 0 oc=1 sa=10 fcarrier=100 fmod=1K td=1m

Description:

The waveform for this source is

$$sourcevalue = saoc + \sin[2\pi fmod.(t-td)]sin[2\pi fcarrier.(t-td)]$$
(1)

Notes:

This is the I element in the SPICE compatible netlist.

Version:

2002.05.15

Credits:

Name Affiliation Date Links

Satish Uppathil NC State University May 2002 NC STATE UNIVERSITY syuppath@eos.ncsu.edu www.ncsu.edu