Independent Voltage Source





Figure 1: Independent Voltage Source Element.

```
Form:
VnameN_{+}N_{-}[[DC] \ [DCvalue] \ [AC[ACmagnitude[ACphase]]] \ [DIST0F1[F1magnitude[F1phase]]]
[DISTOF2[F2magnitude[F2phase]]]]
           N_{+} is the positive voltage source node.
                 is the negative voltage source node.
                 is the optional keyword for the dc value of the source.
      DCvalue
                 is the dc voltage value of the source. (Units: V; Optional; Default: 0; Symbol: V_{DC})
            AC
                 is the keyword for the ac value of the source.
 AC magnitude
                 is the ac magnitude of the source used during ac analysis. That is, it is the peak
                 ac voltage so that the ac signal is ACmagnitude \sin(\omega t + ACphase). ACmagnitude is
                 ignored for other types of analyses. (Units: V; Optional; Default: 1; Symbol:V_{AC})
      ACphase
                 is the ac phase of the source. It is used only in ac analysis.
                 (Units: Degrees; Optional; Default: 0; Symbol:\phi_{AC})
      DISTOF1
                 is the distortion keyword for distortion component 1 which has frequency F1.
  F1 magnitude
                 is the magnitude of the distortion component at F1. See .DISTOF1 keyword above.
                  (Units: V; Optional; Default: 1; Symbol: V_{F1})
      F1phase
                 is the phase of the distortion component at F1. See .DISTOF1 keyword above.
                 (Units: Degrees; Optional; Default: 0; Symbol: \phi_{F1})
      DISTOF2
                 is the distortion keyword for distortion component 2 which has frequency F2.
  F2magnitude
                 is the magnitude of the distortion component at F2. See .DISTOF2 keyword above.
                 (Units: V; Optional; Default: 1; Symbol: V_{F2})
                 is the phase of the distortion component at F2. See .DISTOF2 keyword above.
                 (Units: Degrees; Optional; Default: 0; Symbol: \phi_{F2})
Amplitude Modulation:
```

AM (sa oc fm fc td)

Parameters:

Example:

VSIGNAL 20 5 AM(10 1 100 1K 1M)

Description:

Name	Description	Units	Default
sa	signal amplitude	V	0.0
fc	carrier frequency	Hz	0.0
fm	modulation frequency	Hz	1/TSTOP
oc	offset constant	dimensionless	0.0
td	delay time before start of signal	s	0.0

The waveform for this source is

$$v = saoc + \sin[2.\pi.fm.(t - td)]sin[2.\pi.fc.(t - td)]$$
 (1)

Notes:

The actual element in TRANSIM is the ${\tt vam}$ element. See TRANSIM element ${\tt vam}$ for full documentation.

Credits:

Name Affiliation Date Logo

Satish Uppathil NC State University Sept 2000 NC STATE UNIVERSITY