

Figure 1: B — MESFET element.

```
\textit{fREEDA}^{\textit{TM}} \textit{Form:} \ \texttt{mesfetc:} \\ \langle \texttt{instance name} \rangle \ n_1 \ n_2 \ n_3 \ \langle \texttt{parameter list} \rangle
                     is the drain node
                     is the gate node
               n_2
                     is the source node
               n_3
 parameter list
                     see table 1 for parameter list
SPICE Form:
Bname n_1 n_2 n_3 ModelName [Area]
                  is the drain node
                  is the gate node
                  is the source node
 ModelName
                  is the model name
                  is the optional relative area factor. (Units: none; Default: 1; Symbol:Area)
Example:
In fREEDA^{TM}:
mesfetc:b1 2 0 3
In SPICE:
B1 3 7 4 GAAS12 0.5
```

II The Curtice-Ettemberg Model

ELEMENT Model




Figure 2: The Curtice-Ettemberg Model

Version: 2000.09.01

Credits:
Name Affiliation Date Logo

Carlos E. Christofferson NC State University Sept 2000 NC STATE UNIVERSITY www4.ncsu.edu/~ cechrist