Open circuit to be used as a voltage meter

open



0 +

V

0 -

(j)

Figure 1: open.

Form: open: $\langle instance name \rangle n_1 n_2$ n_1 and n_2 are the element nodes.

Example:

open: vout 48 0 open: 1 4 ref4

Notes:

There is no equivalent SPICE element.

Version:2000.09.01

Credits:

Name

cechrist@ieee.org

Affiliation Carlos E. Christofferson NC State University

Date Links NC STATE UNIVERSITY

Sept 2000 www.ncsu.edu