Single Frequency FM current source

isffm



Figure 1: Independent Current Source Element.

Form: isffm: $\langle instance name \rangle \ n_1 \ n_2 \ \langle parameter list \rangle$

 n_1 is the positive element node,

 n_2 is the negative element node.

Parameters:

Parameter	Type	Default value	Required?
io: Offset current(A)	DOUBLE	0	no
ia: RMS current amplitude (A)	DOUBLE	0	no
fcarrier: AC frequency (Hz)	DOUBLE	0	no
mdi: modulation index (Dimensionless)	DOUBLE	0	no
fsignal: Signal frequency (Hz)	DOUBLE	0	no

Example:

isffm:isignal 8 0 io=0.2 ia=0.7 fcarrier=4 mdi=0.9 fsignal=1

Description:

The waveform shape for this source is

$$i = i_o + i_a[\sin(2.\pi.f_{carrier}.t) + mdi\sin(2.\pi.f_{signal}.t)]$$
(1)




Figure 2: Current source single frequency frequency modulation waveform for isffm:isignal 8 0 io=0.2 ia=0.7 fcarrier=4 mdi=0.9 fsignal=1

Notes

This is the I element in the SPICE compatible netlist.

Version:

2002.05.15

Credits: Name

Satish Uppathil

svuppath@eos.ncsu.edu

Affiliation NC State University

Date May 2002 Links NC STATE UNIVERSITY

www.ncsu.edu