2-Way Thermal FSI for an Exhaust Manifold

This tutorial shows how to solve a 2-way steady-state thermal application.

1. Problem Description

This example considers the fluid and thermal solution for an exhaust manifold containing hot exhaust gas flow. The solid temperature field is solved in Mechanical using a Steady State Thermal system, which is coupled to Fluent via System Coupling. This case could be solved entirely in Fluent, but there are times when solving the solid temperature field in Mechanical is desirable. For example the mesh quality requirements are much less stringent in Mechanical, or an existing model may already be available in Mechanical.

2. Setup And Solution

The following sections describe the setup and solution steps for this tutorial:

- 2.1. Preparation
- 2.2. Starting Workbench
- 2.3. Mechanical Setup
- 2.4. Fluent Setup
- 2.5. System Coupling Setup
- 2.6. System Coupling Solution
- 2.7. Summary

2.1. Preparation

- 1. Create a working folder on your computer.
- 2. Copy the file Manifold.wbpz to the working folder.


2.2. Starting Workbench

- Start ANSYS Workbench and select File >Restore Archive... from the menu.
 - a. Select Manifold.wbpz from your working folder.
 - b. Save to your working folder.

Note

The stand-alone Fluent and Mechanical setups are complete, but no coupling settings have been completed.

2. Drag a **System Coupling** component system onto the **Project Schematic**.



 Connect the Setup cell (A5) of Steady-State Thermal system and the Setup cell (B4) of Fluid Flow (FLUENT) system to the Setup cell (C2) of System Coupling system.


2.3. Mechanical Setup

1. In the **Project Schematic** window double-click on the **Setup** cell (**A5**) of the **Steady State Thermal** system.

Note

This will launch ANSYS Mechanical.


2. Check the current setup.



Note

You will notice the following:

- The **fluid** body has been suppressed.
- Virtual Topology has been used to simplify the geometry and produce a more uniform mesh.
- A named selection is available for the region that will connect to **System Coupling**.
- Convection and Radiation conditions have been applied to the outer surfaces of the geometry.
- 3. In the tree click on **Analysis Settings**.




- a. In the **Details of Analysis Settings** panel select **Off** for **Auto Time Stepping**.
- b. Ensure that **Define By** is set to **Substeps**.
- c. Ensure that **Number of Substeps** is set to **1**.

Note

These are the standard settings for an FSI analysis. **Auto Time Stepping** or substepping should only be used in an FSI case if the Mechanical solver cannot converge it's solution when reasonable loads are provided.


 Right-click on Steady-State Thermal (A5) in the tree and click on Insert > Fluid Solid Interface from the context menu.



- a. In the **Details of Fluid Solid Interface** panel select **Named Selection** from the **Scoping Method** drop-down list.
- b. Select interface_solid from the Named Selection drop-down list.
- c. Save the project and close Mechanical.

2.4. Fluent Setup

- 1. In the **Project Schematic** double-click on **Setup** cell (**B4**).
- 2. Check the setup in Fluent.
 - If you click on Models in the tree you will see that the Energy option is On and the Standard k-e turbulence model is used.
 - Under Materials you can see that air with the ideal-gas equation of state is selected.
 - Under **Boundary Conditions** you can see that three mass flow inlet boundary conditions have been created with a flow rate of **0.15 kg/s** and a temperature of **1200 K**. The outlet is pressure specified with a relative pressure of **0 Pa**.
 - Under **Monitors** an outlet mass flow monitor has been created. The **Residual Monitors** using the local scaling option with a criterion of **5e-5**. The default criterion is 1e-5; this is a tight default convergence tolerance which cannot always be achieved. A criterion of **5e-5** still represents good convergence.
- In the Boundary Conditions task page select interface_fluid and click Edit... to open the Wall dialog box.



- a. In the **Thermal** tab select **via System Coupling** from the **Thermal Conditions** group box.
- b. Click **OK** to close the **Wall** dialog box.
- 4. Select **Run Calculation** in the tree.
 - In the Run Calculation dialog box enter 25 for Number of Iterations.

Note


For a stand-alone steady state Fluent case 500 iterations is a reasonable value. When Fluent is connected to System Coupling this represents the number of Fluent iterations per Coupling Iteration, so a smaller number of iterations is suitable. The goal is not to fully converge Fluent within each Coupling Iteration, but instead enough Fluent iterations should be performed to allow the Fluent fields to react to the new boundary conditions from Mechanical/System Coupling (new wall Temperatures in this case) and move towards sensible values.

5. Click the **Synchronize WB cell status** icon from the toolbar.

2.5. System Coupling Setup

- 1. Return to the Workbench window.
- 2. In the **Project Schematic** right-click on the **Setup** cell (**C2**) of the **System Coupling** system and select **Update** from the context menu.

- 3. Double-click on the **Setup** cell **(C2)** of the **System Coupling** system to open the **System Coupling** tab.
 - a. Click on Analysis Settings in the Outline of Schematic.



- In the **Properties of Analysis Settings** panel enter 30 for **Maximum Iterations**.
- b. In Outline of Schematic select Fluid Solid Interface under Steady State Thermal and interface_fluid under Fluid Flow (Fluent) right-click and select Create Data Transfer from the context menu.

Three **Data Transfer** objects are created.

- i. One **Data Transfer** is for the **Temperature** transfer from Mechanical to Fluent. Rename it to Temperature.
- ii. The second **Data Transfer** is for the **heat transfer coefficient** transfer from Fluent to Mechanical. Rename it to HTC.
- iii. The third **Data Transfer** is for the **near wall temperature** transfer from Fluent to Mechanical. Rename it to NWT.

Note

Renaming the **Data Transfer** objects makes is easier to create charts of these quantities during the solution.


c. Save the project.

File > Save

d. Click **Update** to start the solution.

2.6. System Coupling Solution


1. When the solution starts, check the mapping diagnostics in the **System Coupling** log file.



- Right-click on Chart Monitors and select Create Chart.
 - a. Rename the chart created to Interface Temperatures.
 - b. Right-click on **Interface Temperatures** and add the average temperature variable by:

Add Variable > Fluid Flow (Fluent) > Temperature > Value > Average and


Add Variable > Steady-State Thermal > Temperature > Value > Average



The chart shows the wall temperature values reach a steady value after 5 or 6 Coupling Iterations. You can create similar charts for the **HTC** and **NWT** data transfer values if you wish.

3. Return to the Fluent window and check the residuals plot.





Scaled Residuals
ANSYS Fluent (3d, pbns, ske)

Note

Fluent reaches convergence after about 150 iterations. Using 25 Fluent iterations per Coupling Iteration was a good choice, given how long it takes Fluent to converge and how many coupling iterations are needed to converge the Data Transfers.

To optimize solution times it is important to identify if convergence of the Data Transfers or convergence of the fields in Fluent is holding up a solution. If the flow field in Fluent takes a lot of iterations to reach convergence, then using more Fluent iterations per Coupling Iteration would help reduce the number of Coupling Iterations needed. This is particularly important if the Mechanical model is large and takes a long time to solve.

Conversely, if the Data Transfer quantities are very slow to converge, so many Coupling Iterations are required, then there is no need in using many Fluent iterations.

Save the project.

Note

Detailed post-processing instructions are not provided here. You can examine the solid temperature field in Mechanical and the fluid solution in Fluent or CFD-Post.

A thermal stress analysis could easily be performed by dropping a **Static Structural** system onto the **Solution** cell (**A6**) of **Steady-State Thermal** system and then setting some structural constraints.

5. Save and close Workbench when you have finished looking at the solution.

2.7. Summary

This workshop has demonstrated how to perform 2-way thermal coupling between Fluent and Mechanical, which as an alternative to a Fluent CHT solution. The default couplings (HTC/Temperature) worked well for this case and converged quickly. Sometimes the HTC coupling will be slow to convergence and Heat Flow/Temperature coupling should be considered instead.

Release 16.0 - © SAS IP, Inc.	All rights recorved - Conta	inc proprietary and	confidential int	ormation
neleuse 10.0 - @ SAS IF, IIIC.	Ali rigiris reserveu Coritu	ilis proprietary and	Commuentialini	omination
	FANSYS. Inc. and its subsid	: CC:1:		
O	: AINSYS. Inc. ana its subsia	iaries ana attiliates.		