## 传递函数的幅频和相频特性的计算公式

## 1. 计算公式

例如,有如下传递函数:

$$H(s) = rac{a+sb}{c+sd} = rac{a+j\omega b}{c+j\omega d}$$

那么:

• 幅频特性计算公式为:


$$|H(s)|=\sqrt{rac{a^2+(\omega b)^2}{c^2+(\omega d)^2}}$$

• 相频特性计算公式为:

$$\angle H(s) = arctan(\frac{\omega b}{a}) - arctan(\frac{\omega d}{c})$$

## 2. 示例

例如,有如下 LR电路:



其传递函数为:

$$H(s) = \frac{1}{1 + s\frac{L}{R}} = \frac{1}{1 + 0.0000625s} \tag{1}$$

那么:

• 幅值特性计算公式:

$$|H(s)| = \frac{1}{\sqrt{1 + (\frac{\omega L}{R})^2}} = \frac{1}{\sqrt{1 + (0.0000625\omega)^2}}$$
(2)


• 相频特性计算公式:

$$\angle H(s) = 0 - \arctan(\frac{\omega L}{R}) = -\arctan(0.0000625\omega) \tag{3}$$

## 2.1 使用 Scilab 画出公式 (1) 、 (2) 、 (3)

画出公式 (1) 的 Bode 图,在Scilab中输入:

```
1    s=%s;
2    H=1/(1+0.0000625*s);
3    Hs=syslin('c',H);
4    scf();bode(Hs,0.1,10^7,"$\frac{1}{1+0.0000625s}$");
```



分别画出公式(2)、(3)的幅频特性和相频特性曲线图,在Scilab中输入:

```
gda().grid=[1 1]*color("grey70");
    title(gda(), "fontsize", 3, "color", "red", "fontname", "helvetica bold");
 2
 3
 4
    f=logspace(-1,7,73);
    GHs=20*log10((sqrt(1+(0.0000625*2*%pi*f)^2))^-1);
 5
    GHs=20*log(1)-20*log10(sqrt(1+(0.0000625*2*%pi*f)^2));
    scf();clf;
    subplot(2,1,1); plot("l",f,GHs); title("$20log_{10}|H(s)|=20log_{10}(\frac\ \{1\})) = 20log_{10}(\frac\ \{1\})
    {\left(0.0000625 \neq 0.2\right)}");gca().sub_ticks(1) = 8;
 9
    PhiHs=-(180/%pi)*atan(2*%pi*f*0.0000625);
10
    subplot(2,1,2);plot("l",f,PhiHs);title("$\angle H(s)=-arctan(0.0000625)
11
    \omega; gca().sub_ticks(1) = 8;
12
13
    sda();
```

