
MAX3232
IC3
MAX3232CSE
SELECTOR2
DB9
USB
U1
FT232RLSSOP
JP1
JP3
POWER
SJ2
Default 5V
IC1
MAX3468CSA
RS485
RS422/RX-1
RS422/RX-2
RS422/RX-3
ARDUINO
UNO R3
SELECTOR
SELECTOR1
IC2
MAX3468CSA
RS485
RS485/TX-1
RS485/TX-2
RS485/TX-3
HEADER
V-ENTRADA
POWER
POWERSUPPLY_DC21MMX
S2
SWITCH_TL3220
LM2596
DR127
L1
D1
SS34
LED3
Input Voltage: 5-16V
CONECTOR-JACK
IC4
REG1117
ROBERT-BLUEarm
not saved!
Sheet: 1/1