

PJ-722/PJ-723/PJ-762/PJ-763/PJ-763MFi/PJ-773

User's Guide

English

Thank you for purchasing the Brother PJ-722/PJ-723/PJ-762/PJ-763/PJ-763MFi/PJ-773 thermal mobile printer.

We recommend that you keep this document nearby for future reference. To download the latest manuals, please visit the Brother Solutions Center (support.brother.com/) where you can also download the latest drivers and applications for your printer, read FAQs and troubleshooting tips and learn about special printing solutions.


Available Manuals


You can download the latest manuals from the Brother Solutions Center at support.brother.com

support.brother.com	
Product Safety Guide ¹	This guide provides safety information; read it before you use the printer.
User's Guide ²	This guide provides basic information about using the printer along with detailed troubleshooting tips.
Online User's Guide ³	This guide includes the contents of the <i>User's Guide</i> , and additional information about the printer settings and operations, network connection and settings, troubleshooting tips, and maintenance instructions.
AirPrint Guide ³	This guide provides information for using AirPrint to print from a Mac or iOS device.
Google Cloud Print Guide ³	This guide provides details on how to use Google Cloud Print™ services for printing over the Internet.
Mobile Print/Scan Guide for Brother iPrint&Scan ³	This guide provides useful information about printing from your mobile device when the printer and the device are connected using Bluetooth or Wi-Fi [®] .
P-touch Template Manual ³	This manual provides information on P-touch Template.
Raster Command Reference ³	This manual provides information about printer control commands for controlling the printer directly.

- Printed manual in the box.
- ² PDF manual on the included CD-ROM.
- PDF manual on the Brother Solutions Center website.

General Description







- 1 (Power) button
- 2 ↓☐ (Feed) button
- 3 (Bluetooth) button (PJ-762/PJ-763/PJ-763MFi only) (Wi-Fi) button (PJ-773 only)
- 4 POWER indicator
- 5 DATA indicator
- 6 STATUS indicator
- 7 (Bluetooth) indicator (PJ-762/PJ-763/PJ-763MFi only)
- 8 Release cover
- 9 Paper outlet slot
- 10 Tear bar
- 11 Paper input slot
- 12 USB port
- 13 DC connector
- 14 Battery latches
- 15 Charging terminal protection case (Battery cavity mounting block)

LED Indicators


PJ-722/PJ-723



PJ-762/PJ-763/PJ-763MFi



PJ-773



The indicators light and flash to indicate the printer's status. Each indicator may light or flash in green, red, orange or blue.