**C425 Remote Command List** 

Description	Com	mand	Full RS232 Command	
	Hex	Dec	Hex	Dec
AM	82	130	01,16,82,02,67	1,22,130,2,103
Blend	35	53	01,16,35,02,B4	1,22,53,2,180
Digit 0	C7	199	01,16,C7,02,22	1,22,199,2,34
Digit 1	8A	138	01,16,8A,02,5F	1,22,138,2,95
Digit 2	8E	142	01,16,8E,02,5B	1,22,142,2,91
Digit 3	92	146	01,16,92,02,57	1,22,146,2,87
Digit 4	96	150	01,16,96,02,53	1,22,150,2,83
Digit 5	8B	139	01,16,8B,02,5E,5E	1,22,139,2,94,94
Digit 6	8F	143	01,16,8F,02,5A	1,22,143,2,90
Digit 7	93	147	01,16,93,02,56	1,22,147,2,86
Digit 8	97	151	01,16,97,02,52	1,22,151,2,82
Digit 9	98	152	01,16,98,02,51	1,22,152,2,81
Dimmer	F2	242	01,16,F2,02,F7	1,22,242,2,247
Display	26	38	01,16,26,02,C3	1,22,38,2,195
Enter	C5	197	01,16,C5,02,24	1,22,197,2,36
FM	81	129	01,16,81,02,68	1,22,129,2,104
FM Mute/Mode	37	55	01,16,37,02,B2	1,22,55,2,178
Power Off	F1	241	01,16,F1,02,F8	1,22,241,2,248
Power On	F0	240	01,16,F0,02,F9	1,22,240,2,249
Preset Down	D1	209	01,16,D1,02,18	1,22,209,2,24
Preset Up	D2	210	01,16,D2,02,17	1,22,210,2,23
Sleep	F3	243	01,16,F3,02,F6	1,22,243,2,246
Tune Down	D3	211	01,16,D3,02,16	1,22,211,2,22
Tune Up	D4	212	01,16,D4,02,15	1,22,212,2,21

Note: IR commands use NEC encoding with customer code 877C (34684)