
Connecting the TEC to a: Parts: \$24.80 PC board: \$3.80

PRINTER/PLOTTER



Printer/Plotter circuit

Buy a Dick Smith VZ 200 Printer-Plotter.

This project explains how to directly access (talk to) a PRINTER/ PLOTTER. We have used the most readily available printer/plotter as it is not only the cheapest, but can be obtained from a number of suppliers.

Talking to one of these clever little performers is not very involved when you know how. But without the correct information it will remain completely DEAD. When you know how to supply it with the right stuff, it will do practically anything bar talk to

Actually you only have to send it the necessary codes to produce the character, all the creation of the shape of the symbol is done by the chip within the printer.

Not only do these printer/plotters accept instructions to produce numbers letters and symbols, but they can also be told to rotate, plot, vary the size of the characters and move in almost any direction.

There is a two-way interaction between printer and computer. Data is sent to the printer faster than it can be executed and to save holding up the computer, it is deposited in a FIFO register in blocks of about 4 bytes (in our case). Larger computers can be instructed to go away and execute other work while the FIFO register empties.

Bursts of data are transmitted like this until the whole program is executed.

As we have used a standard printer, it is obvious that it has been designed to connect to any computer which has a normal, full-size, key-board so that each key will produce the corresponding letter on the paper.

But this luxury is not absolutely necessary as the computer merely produces a code number which is sent to the printer.

The code number (or value) is called an ASCII number or ASCII CODE and fortunately is identical for all types and models of personal computers.

The secret to getting the printer to work on the TEC is the latch chip. It holds the data long enough for the printer to read it.

PARTS LIST

- 1 100n mono block
- 4049
- 74LS273
- 2716 (programmed)
- 14 pin IC socket 20 pin IC socket
- 24 pin IC socket
- 24 pin wire-wrap socket
- 24 pin DIP HEADER
- 36 pin Centronics type plug.

tinned copper wire hook-up flex

3 - 'quick connect' pins and sockets

PRINTER INTERFACE PC BOARD

This means all we have to do is produce the same set of ASCII numbers (or codes) and the printer will produce the correct set of shapes on the paper.

Thus we don't need a full-size computer at all.

It may be a bit slow pressing the keys on the TEC, but all the printing capabilities will be possible, and that's all we want.


In this series of articles, we will explore the functions of the printer/plotter and create some amazing effects.

The most important aspect of this is realizing you can create a CONTROL PROGRAM with machine code listings and thus fill the minimum amount of memory for any given effect.

In this way you can produce you own system and expand it as much as you like without having to resort to buying a ready-made console. This will produce a cheaper and more compact system and will gain you much more respect from your boss or customer.

The first part of this project requires assembly of the printer interface board. This board contains a latch and EPROM (filled with a number of handy programs). This will give you a run-up program to test the interface board and provide instant transfer of data from computer to paper to reduce the amount of button-pushing.

The other chip on the board provides an inverted WAIT signal to halt the Z80. This basically keeps the two units in synchronisation.



The printer/plotter interface board complete and ready for plugging into the TEC & printer.

Set out all the parts on your bench and check everything. Solder the sockets, cap and 6 jumper links to the board. Mount the wire-wrap socket through the board so that the long pins act as 'stand-offs' for the component header plug. See the RELAY DRIVER BOARD article and photos for details of how this is done.


The final task involves connecting the board to the 36 pin Centronics plug.

WIRING THE PLUG

Wiring the Centronics-types plug to the printer interface is very easy. On the printer interface PC board there are 24 holes. Twelve of these are numbered. These numbers correspond to the numbers on the Centronics plug. Solder a length of

We used a VZ 200 printer/plotter but there are other units with the same internal workings on the market. But they may not have the same input instruction set

The pens use water-based ink and tend to dry-out fairly easily. If they fail to start: open them up, add a drop of water, heat them up and fit them back into the printer.



A close-up of the 4-pen print head.

hook-up wire between each hole and a corresponding hole on the connector plug. Pin 10 is not used, so no lead is needed. It is not necessary to use special connecting flex such as twisted pairs or screened lead. Our prototype worked perfectly with ordinary hook-up flex. It's best to use different coloured flex for each line to make tracing easier. These leads can be about 50 cm long and kept together with ties or tape at regular intervals.



The only remaining wires left are the 3 control lines. These are:

Memory select 03. I/O select 06, and WAIT.

These are fitted with 'quick connect' terminals which push onto matrix pins on the main PC board. Heatshrink tubing can be placed over the terminals to strengthen the solder joint and make them easier to handle.


When the printer is first turned on it runs through an initial program (from its internal memory) which feeds the paper, sets the pen colours and starts the ink flowing by producing a box with each pen.

After this, there is very little else you can do via the buttons on the unit, except forward feed, change the colour of the pens and/or remove them.

All the rest of the action must come in the form of data from an outside


This is why we need the TEC. It supplies data at high speed to get the print-head moving.

Connect the centronics plug into the rear of the printer and fit the PRINTER INTERFACE PC BOARD to the computer. Connect the 3 flying leads as shown in the diagram:




All the parts shown are included in the kit.

74LS 273



Pin-out for 74LS273



To get something interesting out of the printer you will need to send it a program. The first of these is:

KEN's START-UP PROGRAM:

Make sure the print-head is to the left of the printer as when the printer has been switched on.

Push ADdress 18A0 GO GO.

Watch the result.

This type of program is beyond us at the moment but you will be capable of similar effects after reading this article.

For now, the next step is to be able to get letters and characters onto the paper.

PRODUCING LETTERS etc. . .

All information is fed to the printer in ASCII code. If you want a particular character, the correct code must be sent to the printer. Even if you want to send a number to the printer, such as 150, you must send it in the form of ASCII. This means 150 translates to 31 35 30, as you will see later from the table.

A small program is required to interpret your button pushing and send it to an output port. This is similar to making a segment on the display illuminate and the program for this is contained in the PRINTER/ PLOTTER EPROM at 1980.

To use this program:

Press ADdress 1980 GO GO

The display will go blank and the TEC will be ready for conveying your keyboard instructions directly to the printer.

Each of the letters, numbers and symbols is shown in the table below and the corresponding hex value must be used for the symbol to appear on the paper.

Try obtaining all the letters, numbers and characters by following through the table.

PRINTER/PLOTTER ASCII VALUES:												
s	PAĈE	20	0	30	0	40	P	50	•	60	ρ	70
BACK SPACE 08	04	21	. 1	31	A	41	Q	51	a	61	q	71
LINE OA	ù	22	2	32	B	42	R	52	Δ	62	۲	72
CR OD	#	23	.3	33	\cup	43	S	53	С	63	S	73
DC1 11	\$	24	4	34		44	T	54	d	64	t	74
DC2 12	%	25	5	35	Ε	45	U	55	ω	65	ב	75
NEW COLOUR 1 D	&	26	6	36	LT.	46	V	56	f	66	>	76
	,	27	7	37	G	47	3	57	9	67	3	77
	(28	8	38	Н	48	X	58	h	68	Х	78
		29	9	39	I	49	Y	59	· .	69	У	79
	*	2A	• o	3 A	7)	4A	3	5A	.)	6A	Z	7A
LINE BEFORE OB	+	2B	9	3B	Κ	4B	[5B	k	6B	{	7B
	9	2 C	<	3C	ļ.,	4C	\	5C	l	6C		7C
		2D	=	3D	Μ	4 D]	5D	m	6D	}	7D
	a	2E	>	3E	7	4E	^	5E	n	6E	~	7E
	/	2F	ک	3F _.	0	4F		5F	0	6F	Ø	7F

Try the following sequence and you will see a word appear: 49 4E 43 52 45 44 49 42 4C 45

For the hex value 49, the letter I will be printed. Press each number only ONCE. The first press will appear to have no effect, but as soon as the second button is pressed, the letter I will be printed.

Be very careful not to press buttonsequence 11 or 12 as this will cause the mode to change and everything will appear to 'lock-out'.

Try writing a sentence using the hex key pad. It's slow but eventually gets you there. A space between words is created by typing 20.

Any sentence you send to the printer via the keyboard can be re-presented again and again if placed into memory before-hand. It can also be corrected and adjusted (within limits). To do this, place the data at 0800 and call a program at 1880.

Insert the following at 0800:

49 4E 43 52 45 44 49 42 4C 45 20 20 48 55 4C 4B 0D 0A 1D FF.


Push ADdress 1880 GO GO.


Recall it again by pressing: **AD**dress **1880 GO GO.**

THE LIST PROGRAM

This program lists any part of the EPROM, RAM or any additional memory you add to your TEC. In fact the first thing you can do is get a print-out of your MONitor ROM. Many readers have written requesting a listing of the MONitor and now they can produce it themselves.

But before you can get a listing, you must make a modification to the operation to the printer. This involves setting the two switches under the printer:





The PC layout for the Printer/Plotter. The overlay and parts positioning can be gained from the photo on P 31.

This is how to do it.

On the bottom of the printer is a small plate. Undo the screws and remove the plate. Inside you will find a bank of 4 switches. Switch 1 should be in the OFF position and switch 2 in the ON position. Don't worry about switch 3 and 4.

When the switches are set like this, CR (carriage Return) will set the print-head to the left of the paper without feeding the paper forward. The paper can then be fed forward by using LF (Line Feed). The switches should be set like this because the program in ROM automatically line feeds after each carriage return. If the switches are not set like this, the typing will be double line spaced.

Enter the following into the TEC: **AD**dress **1800 GO GO:**

The display will go blank and the printer will CR and LF. Now enter **0000** and the printer will start printing out characters in pairs. This is a listing of the contents of your monitor ROM.

If you want a listing of any of the programs you have typed into memory, start at **0800** or where your program starts, and enter a 4-digit number into the keyboard. It must be 4 digits, so don't forget the leading 0.

The text mode is not very interesting. After all, we have seen electric/ electronic typewriters for years, But for a print-head to produce GRAPHICS! That's different!

GRAPHICS MODE


The program at **1880** can also be used to generate graphics on the printer.

Remember, all information must be programmed into the printer in ASCII.

Type the program below into the TEC's memory at **0800.** An **FF** is placed after the last piece of data to signify the end of a program. Now run the program at **1880** by pressing **AD**dress **1880 GO GO.**

at 0800: 0A 0D 12 49 2C 44 38 30 2C 30 2C 38 30 2C 2D 38 30 2C 2D 38 30 2C 30 2C 3D 38 30 2C 30 2C 30 0D FF.

The printer will draw a square.




Look at the listing. It may look complex but can be easily decoded using the table. It will decode to this:


OA = LF = Line Feed.
OD = CR = Carriage Return
12 = DC2 = Graphic Mode
49 = I = sets the pen's location as
co-ordinates 0,0.
2C = , = Separates I from D
44 = D = draw from present location
to the co-ordinate given by the
next byte(s) of data.
38 = 8

30 = 02C = .30 = 02C = .38 = 830 = 02C =2D = -38 = 830 = 0 2C =30 = 02C = ,2D = -38 = 830 = 02C = 30 = 02C = .30 = 0OD = CR = carriage return FF = signifies end of program.

The printer uses a co-ordinate system exactly like the x,y axis used to draw graphs. The origin is 0,0 (or 00,00) and the positive direction of x and y is shown on the diagram.



The co-ordinates of the corners of the box are shown in this diagram. This clearly shows how the values are obtained.



The program can be separated into 4 sections, each drawing one side of the box. This will show how the program goes together.

The following program produces the top of the square:

at 0800 type: **0A 0D 12 49 2C 44 38 30 0D FF.**

ADdress 1880 GO GO.

The result will be:

Let us produce a line the full width of the paper. For this you will need a 3digit value. The printer is capable of accepting a value as high as 999 (also -999) but this will be too high for our width of paper. Try 300.

The ASCII value is 33 30 30.

at 0800: 0A 0D 12 49 2C 44 33 30 30 2C 30 0D FF. Press ADdress 1880 GO GO.

The final **0D** is important to get the printer to execute the graphics command.

The value 300 will not quite reach the far side of the paper. Try 450. This will be about the longest line possible and don't forget to use the ASCII values in the program.

Shorten the side of the box to 80 and continue with the experiment.

The second side of the box will be produced at an angle other than 90° by inserting the following coordinates: 50, -80

at 0800: 0A 0D 12 49 2C 44 38 30 2C 30 2C 35 30 2C 2D 38 30 0D FF.

Run the program. Does it produce two sides of an irregular figure?

The next side will be produced as follows:

0A 0D 12 49 2C 44 38 30 2C 30 2C 35 30 2C 2D 38 30 2C 31 35 30 2C 2D 38 30 0D FF.

Run the program and see the result.


Finally: 0A 0D 12 49 2C 44 38 30 2C 30 2C 35 30 2C 2D 38 30 2C 31 35 30 2C 2D 38 30 2C 0A 0D 11 1D 0D FF.

Produce other shapes and you will understand how to plot co-ordinates.

HEX

The second shape we will investigate is a HEXAGON.

To produce this shape you need to know the value of the internal angle and produce a 30° 60° 90° triangle as shown. This will give you the length of the sides of the triangle and from this the first set of co-ordinates can be obtained (25,43) These values are 1/4 of 100, 173, which are the lengths of the sides of the triangle.



The second co-ordinate, 75,43 is found by adding 50 to the value 25. Continue around the hex shape until the figure is closed.

This is the listing for the printer:

at 0800:

12 49 0D 44 32 35 2C 34 33 2C 37 35 2C 34 33 2C 31 30 30 2C 30 2C 37 35 2C 2D 34 33 2C 32 35 2C 2D 34 33 2C 30 0D FF.




o's and X's


The new instruction with this shape is the MOVE command.—4-D

This instructs the pen to lift from the page and move to a specified location without drawing on the paper.

Here is the listing and the shape which will be drawn:




This is a decoding of the first part of the listing. This will be sufficient to understand how the program is written.



This diagram shows the value of the co-ordinates required to draw the shape.

Copy out the complete listing and decode it to prove that the path taken by the print-head is as shown in the diagram.

ADdress 1880 to use.



WAR GAMER'S DELIGHT

The full impact of this effect is shown on the next page.

The first thing you notice about the program is a set of values at the beginning which the printer does not recognise. This means they must be Machine Code values for an 'operations' program for the Z80. And they are.

The program produces a honey-comb nattern.

Anyone into war games will soon recognise the possibilities of the honey-comb as a playing board. The reason is each block has 6 borders, increasing the possible moves and thus the strategy, over a regular field of squares.

This shape is created using a picture element of a hexagon attached to a straight line thus:



This pattern is repeated 4 times across the paper and then a move to a new starting point -450,-86 down the paper.

The co-ordinates of the new starting point can be explained as follows:

After each picture element is drawn, the printer is initialized. This means that the present co-ordinate of the pen is taken as 00,00.

This gives us a value of 450,00 for the commencement of the 4th picture element with reference to the origin.

The next row of hexagons commence at the left-hand edge, which is -450 with reference to the above X coordinate and a y value of -86, with reference to the y value above.

The only way to understand how the honey-comb has been produced is to decode the listing. It contains two loops, one to draw the picture element and the other to count-to-4 across the screen.

Write each of the ASCII codes in a single file and alongside it place the printer value it represents.

You can experiment further by making the hexagons smaller. This will use a 2-digit ASCII value for the length of the sides. In the program, the original 3-digit ASCII values have been converted to 2-digit by using 00 for the 3rd value.

The first 18H bytes (31 bytes is the MAIN program and this contains the instructions to fetch one byte of data from the printer program and send it to the printer.

Data for the printer is stored in the form of a BYTE TABLE and starts at **0820.**

The main program is divided into two separate parts. **0800 - 080F** is a loop which loads the printer program and runs it 4 times.


811 • 81D loads the data for the MOVE commands and each piece of data is sent to the printer until **FF** is detected.


The count-to-4 operation is performed by **DJNZ** (at **80F**) which automatically decrements register B by ONE on each pass of the loop until it becomes zero.

The program then advances to loading HL register-pair with the contents of memory location **0860** and this instruct the print-head to move to the left-hand edge and down the paper to a new starting point. The main program then jumps to the start **(0800)** via instruction **JR Z E7** (at **817**).


800		LD B,04
801 802 803	04 21 20	LD HL,0820
804 805 806	<u> 7E</u>	LD A.(HL) CP FF
807 808 809		JR Z 05
80A 80B	D3 06	OUT (06),A
80C 80D	23 18	INC HL JR F6 (to 805)
80E 80F 810	F6 10	DJNZ F1 (to 802)
811 812	21	LD HL 0860
813	08 7E FE	LD A,(HL) CP FF
817 818	28 E7 D3	JR Z E7 (to start)
819 81A	D3 06	OUT (06),A
81B 81C	23 18	INC HL JR F6 (to 814)
81D 81E 81F	FF FF	NOT USED NOT USED


WAR GAMER'S DELIGHT






0800 06 04 21 20 08 7E FE 23 0808 28 05 D3 06 18 F6 10 2E 0810 F1 21 60 08 FE D3 06 23 18 F6 FF FF **08**18 E7 **0820** 12 49 ØD 44 32 35 2C 34 0828 33 2C 32 35 20 34 20 30 2C 30 2C 37 35 0830 31 30 **0838** 20 20 34 33 2C 32 35 20 33 2C 20 30 00 0840 2D 34 30 30 30 2C 30 00 44 **0848 40 31** FF FF 30 2C 0850 31 35 30 ØD. FF FF FF 0858 FF FF FF FF 0860 4D 2D 34 35 30 2C 2D 38





0868 36 0D FF



negative direction.

Being able to draw some of the basic shapes (as we have shown), opens up a whole new world of computer graphics.

If we take the box-shape, we can produce a very effective pattern simply by re-defining the start coordinates and repeating the shape many times. The result can be anything from a 'check-tie' to an irregular octogon.

The colourful patterns which can be obtained (of which we can only see the result in black and white) is produced by a combination of drawing, shifting and colourchanging. The first of these to be investigated will be an irregular octogon or DIAMOND.

We have already outlined the structure of the program and briefly it is a set of instructions which are loops. Each sets a particular condition and then decrements on each pass.

For the diamond shape, a square is generated at the origin, 00,00 via the program at 0880. The lengths of the sides of the square are 80. When the 4 sides have been drawn, the pen lifts off the paper and moves to a new origin with co-ordinates 04,04. The program is now up to location **083C.** It then jumps to **0842.** The contents of the accumulator (which is the value at location 0860 i.e. 00) is loaded into 089A. Register pair DE is incremented and now looks at location 0861. The value 34 is loaded into the accumulator. At 0847 the contents of the accumulator is loaded into location 089B.

So far, the program at **0880** has not been altered but the next two sets of

Complete decoding of the above listing, with explanations.

LD B,06 800 06 LD A,0A OUT (06),A DJNZ 0804 802 0A Ď3 06 804 FC 806 10 3E 808 12 LD A,12 OUT (06),A LD DE,0860 80A **D**3 06 80C 60 08 11 08 LD B,08 80F 811 PUSH BC 06 812 LD B,04 80 08 LD HL,0880 814 21 A,(HL) 817 LD FF FE CP FF **818** 23 08 CA JP Z,0823 81A OUT (06),A INC HL D₃ 06 81 D 81F 23 820 17 08 JP 0817 EF **DJNZ 0814** 10 823 11 825 LD A,11 D₃ 06 OUT (06),A 827 829 LD A,1D 3Ē 1D OUT (06),A XOR A 82B D₃ AF D3 82D 82E OUT (06),A LD A,12 OUT (06),A POP BC 12 830 06 832 D3 834 C1 DA **DJNZ 0811** 835 10 LD A,(DE) CP FF 837 838 FF FE **C**2 42 08 JP NZ,0842 83*A* 3Ē LD A,11 83D 11 OUT (06),A 06 83F D3 C7 32 RST ò 841 9A 08 LD (089A),A 842 13 1A INC DE 845 LD A,(DE) LD (089B),A INC DE 846 9B 847 32 84A 84B 13 1Å LD A,(DE) 9D 08 LD (089D),A INC DE 32 84C 13 1A 84D LD A,(DE) 84E 9E 08 LD (089E),A INC DE 84F 32 13 850

OF 08 JP 080F

C3

851

produce the DIAMOND.
of the above listing,

Load B with 6 Load A with the Forward Feed instruction OUT to the printer port create 6 loops of forward feed Select the Graphics Mode OUT to the printer Load DE with start of Direction Change TABLE Sets number of colour changes before a direction change Save B. B must be paired with C to be saved Sets number of squares for each colour Load HL with start of DRAWING TABLE Load the data at 880 into A detects end of TABLE At end of table, jump to 823 OUT data value at 880 to printer Increment to 881, 882 etc Jump to 817 to increment through Drawing Table Loop DRAWING TABLE 4 times Change to TEXT MODE **OUT** to printer NEXT COLOUR **OUT** to printer Clear A OUT to printer Select GRAPHICS MODE **OUT** to printer Get B from STACK Actually BC Decrement B and jump to 811 for 6 loops Load A with data at 860 etc Detects end of DIRECTION CHANGE program If not zero, jumps to 842 If zero, change to TEXT MODE OUT to printer END OF PROGRAM. * * * * * * * * * * * Load first byte of Dircetion Change table into location 089A Increment DIRECTION CHANGE table Load next byte of Direction Change table into A Load this byte into location 089B Increment the DIRECTION CHANGE table Load the third byte into the accumulator Load this third byte into loaction 089D Increment the DIRECTION CHANGE TABLE Load the fourth byte of the direction change table into A Load this fourth byte into location 089E Increment the DIRECTION CHANGE table ready for next

Jump to 80F to commence the next direction


The program will then jump to 80F and draw the second side of the diamond


On the next pass, the register pair DE will be looking at locations 0864, 0865, 0866, and 0867. This will change locations 089A, 089B, 089D and 089E to 2D 34 2D 34 and thus the third side of the diamond will be drawn.

Via the same reasoning, the 4th side of the diamond will be completed.


examples on the right and will be continuing with these and more 'add-ons' in the next issue. of COMPUTER The aim GRAPHICS is to be able to produce 'forms' and ruled work for invoices etc. and place

information in correct locations. It also gives you an understanding of ROBOT movement, an area we all would like to investigate.





The Direction Change table and Drawing table with decoded values.



MON-1B

LOOKING AT THE REGISTERS

The MONITOR ROM for the TEC-1A (it can also be fitted to the TEC-1) is a MON-1B. This ROM has the facility for looking at the registers.

This ROM is the result of a number of requests from readers who needed to look at the contents of the various registers during the running of a program.

If you would like one of these updated ROMs, send your MON-1 or MON-1A plus \$3.00 postage and we will re-burn your EPROM to include the additional instructions.

There is a limit to when and where you can use the register facility but it can help enormously with debugging programs.

For instance, it can let you know the progress of a program or delay routine simply by interrupting it part way through.

The way this facility works is as follows:

If you reset the computer while it is executing a program, by pressing the reset button ONCE, the contents of each of the registers is pushed onto a stack.

This stack starts at OFFO and increases downwards to **0FD8**.

To look at any of the registers, press reset once and key the address of the register you want to look at.

The following list identifies the location of each register:

Mem ADD:	Reg:
oFFo	
ofef	A
OFEE	F
oFED	B
OFEC	<u>C</u>
ofeb	ភ្ជ
OFEA OFE9	F B C D E H
of E9	n i
oFE7	L IX MSB
oFE6	IX LSB
0FE5	IY MSR
OFE4	IY LSB
0FE3	A'
oFE2	F'
OFE1	B '
o <u>f</u> Eo_	<u>C'</u>
oFDF	F' B' C' D' E' H'
oFDE oFDD	E'
of DC	II'
oFDB	ľ, ľ
oFDA	-
oFD9	Stack MSB
oFD\$	Pointer LSB

Note: Reset clears the I register and thus it will always equal 00.

Use JP 0000 if you wish to look at I.

An alternate method of saving the registers is to insert a JP 00 00 instruction in the program at the position you wish to investigate. This will cause a JUMP to the beginning of the MONITOR ROM where it will find a jump to the register-save routine.

This will enable you to exit a program at a pre-determined point and look at the registers. The contents will be shown in the data displays.

Pushing Reset twice will destroy the information.

This is the program at 05F0 which performs the 'REGISTER-SAVE' operation. Don't forget the Monitor ROM has an instruction at 0000 to Jump to 05F0.

05F0 05F4 05F7 05F8 05F9 05FA 05FD 05FF 0600 0601 0602 0603 0604 0605 0607	ED 31 F5 C5 ED FD 08 P5 C5 ED F5 C3	LD (0FD8),SP LD SP,0FF0 PUSH AF PUSH BC PUSH HL PUSH IX PUSH IY EX AF,AF' EXX PUSH AF PUSH BC PUSH DE PUSH DE PUSH HL LD A,I PUSH AF JP 0580
0608 060B	C3 FF	JP 0580 RST:38H

0760	0F			RRCA
0761	0F			RRCA
0762	0F			RRCA
0763	E6	0F		AND 0F
0765	21	B0	07	LD HL,07B0
0768	85	_		ADD A,L
0769	6F			LD L,A
076A	7E			LD A,(HL)
076B	02			LD (BC),Á
076C	03			INC BC
076D	C9			RET
076E	21	F0	0F	LD HL,0FF0
0771	06	06		LD B,06
0773	0E	01		LD C,01
0775	7E			LD A,(HL)
0776	D3	02		OUT (02),A
0778	79			LD A,C
0779	D3	01		OUT (01),A
077B	0E	40		LD C,40
077D	0D	. •		DEC C
077E	20	FD		JR NZ,077D
0780	07			RLCA
0781	4F			LD C,A
0782	AF			XOR A
0783	D3	01		OUT (01),A
0785	23	٠.		INC HL
0786	10	ED		DJNZ,0775
0788	C9			RET
0789	FF			RST 38
078A	FF			RST 38
078B	FF			RST 38 RST 38
078C	FF			RST 38
078D	FF			RST 38
078E	FF			RST 38
078F	FF			RST 38
0790	D5			PUSH DE
0791	C5			PUSH BC
0792	CB	9A		RES 3,D
0794	1A	,		LD A,(DE)
0795	FE	FF		CP FF
0797	20	09		JR NZ,07A2
0799	13	0,		INC DE
079A	0B			DECBC
079B	78			LD A,B
079C	B1			OR C
079D	20	F5		JR NZ,0794
079F	CI	13		POP BC
07A0	D1			POP DE
07A1	C9			RET
07A1	3E	47		LD A,47
07A2	D3			OUT (02),A
07A6	3E	01		LD A,01
07A8	D3	01		OUT (01),A
07AA	76	O I		HALT
07AB	18	F2		JR 079F
0,710	-0			0174

07B0 EB 28 CD AD 2E A7 E7 29 EF 2F 6F E6 C3 EC C7 47

PRINT-2 AND PRINT-3 SOFTWARE

With the changes to the keyboard handler routines in both MON-2 and JMON, an up-dated printer ROM has been produced.

The new software is burnt into the same ROM at higher locations. When MON-2 was released, an up-dated ROM called print-2 was included in the printer interface kits. This gave you the same routines with an altered keyboard section. It was also a little more fancy as it showed the start address on the LED display as you typed it in. Unfortunately, Print-2 did not include a "dump string at 0900" routine to replace the dump from 0800 which is now unusable as MON-2 uses 0800 for its variable storage.

With the advent of JMON, the same arrangement has been used. The JMON printer routines are located higher again, so in the one ROM you have the printer software for all three MONitors. The list routine for JMON is an improvement on both earlier software packages, as JMON's routine uses the perimeter handler to allow you to enter both a START and END address. Print-3 includes a "dump from 0900" routine which can be used with MON-2.

The ROM with the JMON routines in it is called PRINT-3 and is supplied with the printer interface as standard.

JMON's hex dump routine is at 1A20, the typing routine at 1AA0 and the "dump string at 0900" routine is at 1AC0.

Below is a dump of PRINT-3. Burn the additional section(s) in PRINT-1/2 ROM.

The graphic demonstration routines in PRINT-1 will work with all MONitors.

```
1800 3E OD D3 06 3E OA D3 06
     76 ED 57 17 17 17 17 57
1810 CD 5D 18 76 ED 57 82 57
     CD
        61 18
              76 ED 57
                        17 17
1820
    17
        17
           5F
               CD
                  5D
                     18
                        76
                           ED
     57
        83
           5F
              CD 61
                     18
                        C3 49
1830 18
        3E OD D3 06
                     3E 0A D3
     06
        7A CD 5D 18
                     7A CD
                           61
1840 18 7B CD 5D 18 7B CD 61
     18
        06 08
              3E 20 D3 06
                           1 A
1850
    CD
        5D
           18
               1A CD
                     61
                        18
                            13
     10
        F1 C3
              31 18
                     1F
                        1F
                           1F
1860 1F
        21 6C 18 E6 0F 85
                           6F
     7E D3 06 C9 30 31 32
                           33
1870 34 35 36
              37 38 39
                        41 42
     43
        44
           45
               46
                  FF
                     FF
                        FF
                           FF
1880 21 00 08
               7E
                 FE
                     FF
                        20
                           0.5
              06 C7 D3 06 23
     3E 11 D3
1890 18 F1 FF FF FF
                     FF
                        FF FF
     FF
        FF FF FF FF FF
                        पप
                           \mathbf{F}\mathbf{F}
18A0
    21
        СЗ
           18
               7E
                 FE FF
                        28
                            0.5
     D3
        06
           23
               18
                  F6
                     06
                        0A
                           21
18B0 CF
        18
           7E FE FF
                     28 05 D3
     06
        23 18 F6 10 F1 3E 11
18C0 D3 06 C7 OD OA OA OA OA
     OA OA 12
              43 30 OD FF
                           49
18D0
    2C
        44
           33
              32
                  30
                     2C
                        30 OD
        31 32 30 2C 30 0D 44
     4D
18E0
    38 30 2C 2D 31 36 30 0D
     4D 32 32 30 2C 2D 38 30
18F0
    OD 44 31 36 30 2C 2D 38
     30 2C 31 34 30 2C 2D 31
```

```
1900 36 30 2C 32 30 30 2C 2D
     31 36 30 0D 4D 31 35 30
1910 2C 2D 31 32
                  30 OD 44 32
     30 30 2C 2D 31 32 30 0D
1920 4D 33 32
               30 2C 2D
                        38
                            30
     OD
        44
               36
                  30
            32
                     2C
                         2D
1930 30 2C 32 34 30 2C
                        2 D
                            31
     36 30
           2C 33
                  30
                     30
                         2C
                            2D
1940 31 36
           30 OD
                  4D 33
                        36
                            30
     2C
        2D
            31
               32
                  30
                     ΩD
                         44
1950 30
        30
            2C
               2D
                  31 32
                         30
                            OD
        34 36
               30 2C 2D
     4D
                         38
                            30
1960 OD 44
           34 34 30 2C 2D
     36 30 0D 4D 32 2C 2D 32
1970 OD
        43
           33
               OD
                  FF
                     FF
                         FF
                            FF
     \mathbf{F}\mathbf{F}
        FF
           FF
               FF FF
                     FF
                         FF
                            FF
1980 76 ED
           57 E6 OF
                     17
                         17 17
     17 57 76 ED
                  57 E6 OF 82
1990 D3 O6 18 EC FF FF FF FF
     FF FF FF FF FF
                     FF FF FF
```

The next block is the PRINT-2 additions:

```
19A0 76
       3A E0 08 E6 0F 17 17
     17 17 57 76 3A EO 08 E6
19B0 OF 82 D3 O6 18 EA FF FF
     FF FF FF FF FF FF FF
19C0 3E 0D D3 06 3E 0A D3 06
     3F
        29
           21
              DΒ
                 0.8
                    06
                       06
                           77
1900 23
       10 FC CD 00
                    1A
                       32
                          D8
     08 CD 00
              1A 32 D9 08 CD
19E0 00 1A 32 DA 08 CD 00
     32 DR 08 CD D8 01 CD 89
19F0 02
        50
           59
              C3
                 31 18
                       FF
                          नप
     FF
       FF FF
              FF FF
                    FF
                       FF
                          FF
1A00 3E FF
          32 EO 08 CD AO 02
     3A E0 08 FE FF 28 F6 E6
1A10 OF C6 FF CD 70 01 D6 01
     C9 FF FF FF FF FF FF
```

Below is PRINT-3 additions:

```
1A20 21 34 1A 11 80 08 01 0A
     00 ED B0 21 00 00 22 9C
1A30 08 C3 44 00 00 00 3E 1A
     99 08 00 01 50 1A 04 A7
1A40 04
        C7
           04
              EB
                 FF
                    FF
                        FF
                           FF
     FF
       FF
           FF
              FF
                 FF
                    FF
                        FF
1A50 3E 0D D3
              06 2A 98 08
                           7C
     CD 82 1A
              7D CD 82
                        1A 06
1A60 08 C5 3E 20 D3 06
                        7E CD
     82 1A 23 C1 10 F3
                        3E OD
1A70 D3
        06
           ЗE
              0A
                 D3
                     06
                        ED
                           5B
     9A 08 E5 B7 ED 52 E1
                           38
1A80 D6
        C9 F5
              OF FF
                     OF
                        OF
                           CD
     8B 1A F1 E6 OF
                    C6
                        90
1A90 CE
        40
                 06
           27
              D.3
                    C9
                        FF
     FF
        FF
           FF
              FF
                 FF
                     FF
1AA0 CF
        E6
           OF
              07
                 07
                    07
                        07
                           57
     CF E6 OF
              82 D3 06
                        18
1AB0 D3 06 18 EC FF FF FF
     यय यय यय यय यय यय यय
                           FF
1AC0 21
        00 09
              7E FE
                    FF
                        20
                           05
     3E 11 D3 06 C7 D3 06
                           23
1ADO 18 F1 FF FF FF
                        FF FF
     FF FF FF FF FF FF FF
```

TE