Table d'adressage																						
Composant	Adresse 32-bit du composant en hexadécimal	Unused	Sélection de composant						Adresses EEPROM et mémoire (RAM) – 8Ko													
		A31 – A18	A17	A16	A15	A14	A13	A12	A11	A10	A9	A8	A7	A6	A5	A4	А3	A2	A1	A0		
EEPROM	0x00000000		0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0		
\downarrow	\		,	1		1		1		1		1		1		1		1		1		
EEPROM	0x00001FFF		0	0	0	0	0	1	1	1	1	1	1	1	1	1	1	1	1	1		
RAM	0x00002000		0	0	0	0	1	0	0	0	0	0	0	0	0	0	0	0	0	0		
\downarrow	\		,	1		1		1		1		1		1		1		1		1		
RAM	0x00003FFF		0	0	0	0	1	1	1	1	1	1	1	1	1	1	1	1	1	1		
Moteur 1	0x00004000		0	0	0	1	0															
Moteur 2	0x00006000		0	0	0	1	1															
Moteur 3	0x00008000		0	0	1	0	0															
Moteur 4	0x0000A000		0	0	1	0	1															
Moteur 5	0x0000C000		0	0	1	1	0	Composants sélectionnés														
Moteur 6	0x0000E000		0	0	1	1	1															
Bras robotisé 1	0x00010000		0	1	0	0	0	Microcontroller: PIC32MX registres 32 bits									oits					
Bras robotisé 2	0x00012000		0	1	0	0	1		_													
MastCam	0x00014000		0	1	0	1	0	LE	EEPROM: Atmel AT28HC64B adresse 13 bi								ts					
Mahli	0x00016000		0	1	0	1	1	R	RAM: Renesas 7164L adresse 13								13 bi	ts				
APXS	0x00018000		0	1	1	0	0															
Chemcam	0x0001A000		0	1	1	0	1															
CheMin	0x0001C000		0	1	1	1	0															
Sam	0x0001E000		0	1	1	1	1															
Rad	0x00020000		1	0	0	0	0															
Dan	0x00022000		1	0	0	0	1															
Rem	0x00024000		1	0	0	1	0															