Always:

- · Run a rinse cycle before and after every batch
- Run a cleaning cycle after every third brewing session with Zymatic cleaning tablets or if more than 3
 weeks have gone by since your first brew in this cycle
- · Check that the in-line filter has been cleaned and filter bowl is firmly in place
- Make sure that the 4 plugs are seated in the dividing wall of the step filter
- Disassemble and clean keg posts and poppets between batches
- Disassemble and clean ball locks between batches
- Operate machine on a sturdy and level surface
- · Check that adjunct compartment insert tabs are facing towards mash compartment
- Measure water volume accurately
- · Check that hoses are attached to machine tightly
- Place a large keg lid O-ring on top of the upper screen (between it and the lid) if your grain bill is ≥ 8
 lbs.

Never:

- . Use Reverse Osmosis or Distilled Water without adjusting mineral content
- Add ingredients directly to the keg unless completely dissolved
- . Use PBW, StarSan, Iodophor, OneStep, B-Brite etc. to for anything other than kegs
- · Operate machine with a metal lid on the keg
- Lift the machine from inside
- · Remove step filter while full of liquid
- · Operate without a keg cozy on the keg
- · Operate without screens in step filter
- Run a chill cycle for longer than 45 minutes
- · Operate with USB cable plugged into machine
- Connect hoses to machine without white nylon flare washers in place

Max Grain Capacity: 9 lbs

Max Hop Capacity: 1.5 oz pellets per cage

Optimal grind: .042-.048" (Med/Coarse)

For support, parts, maintenance, or if you receive a "Fatal Error" while operating this Zymatic please contact:

info@picobrew.com

Retain all original packaging for return shipping.