



Choose which item(s) will get Tax Applied.

Choose which columns are shown.

Drag items up or down in the list.

Drag items into your template from the list.

Note. You can drag the same pricing items in multiple times and give them a different description.

Show Cost only. Removes all Markup % and Add-Ons.

Units:
☐ mm
☒ in

Pricing Templates

Template: Job Costing

Include	Tax	Item	Description	QTY	Units	Amount	Markup	Total
☒	☐	Materials	{list of m...				0	
☒	☐	Banding	{list of b...				0	
☐	☐							
☒	☐	Doors	{list of d...				0	
☒	☐	Applied Panels	{list of a...				0	
☐	☐							
☒	☐	Inserts	{list of in...				0	
☒	☐	Drawer Boxes	{list of d...				0	
☐	☐							
☒	☐	Guides	{list of g...				0	
☒	☐	Hinges	{list of hi...				0	
☒	☐	Pulls	{list of p...				0	
☒	☐	Drawer Front Fasteners	{list of c...				0	
☒	☐	Shelf Pins	{list of s...				0	
☒	☐	Spacers	{list of s...				0	
☐	☐							
☒	☐	Fasteners	{list of fa...				0	
☒	☐	Closet Rods	{list of cl...				0	
☐	☐							
☒	☐	Total						-

Onscreen View

- ☐ Taxable
- ☒ Item
- ☒ Description
- ☒ QTY
- ☒ Units
- ☒ Amount
- ☐ Markup
- ☒ Total

☒ Show My Cost

Use Pricing Templates to choose which items you will want to use to calculate your job's price. Setting up a Pricing Template that works for your company will be your first and most important step in order to price projects with Mozaik.

Cabinets	Price by Cabinet. Price options are set in each Cabinets’ “Price Tab” in the Product Editor.
Materials	Price by Materials. Enter your prices in the Stock Material Library. Libraries>Materials.
Inserts	Price Inserts. Set the price of each Insert in the Inserts Library. Libraries>Inserts.
Appliances	Price Appliances. Price options are set in each Appliances’ “Price Tab” in the Product Editor.
Banding	Price Edgebanding. Set the lineal costs of your banding in the banding tab of the Stock Material Library. Libraries>Materials. Amount is determined by your Edgebanding Assignments.
Doors	Price Doors. Door pricing options are set in the Door Library. Libraries>Doors.
Drawer Boxes	Price Drawer Boxes. Drawer Box prices are set in the Drawer Box Library. Libraries>Drawer Boxes.
Applied Panels	Price Applied Doors. Door pricing options are set in the Door Library. Libraries>Doors.
Hinges	Price Hinges. Hinge prices are set in the Hardware Library. Libraries>Hardware>Hinge Tab.
Guides	Price Guides. Guide prices are set in the Hardware Library. Libraries>Hardware>Guides Tab.
Pulls	Price Pulls. Pull prices are set in the Hardware Library. Libraries>Hardware>Pulls Tab.
Closet Rods	Price Closet Rods. Closet Rod pricing options are set in the Hardware Library. Libraries>Hardware>Closet Rod Tab.
Shelf Pins	Price Shelf Pins. Guide prices are set in the Hardware Library. Libraries>Hardware>Shelf Pins Tab. Qty is determined by Boring Parameters.
Drawer Front Fasteners	Price Drawer Front Fasteners. Prices are set in the Hardware Library. Libraries>Hardware>Drawer Fasteners Tab.
Spacers	Price Drawer/Tray Spacers. Prices are set in the “Spacers” menu in the Guides Tab. Libraries>Hardware>Guides Tab>Spacers.
Fasteners	Price Joint Fasteners. Prices are set in the Hardware Library. Libraries>Hardware>Fasteners Tab>Joint Templates. Qty is determined by fastener locations.
Panel Fasteners	Price Panel Fasteners. Prices are set in the Hardware Library. Libraries>Hardware>Fasteners Tab>Panel Fastener Templates.
Base Cabinets (Ft)	Price each linear foot (or meter) or Base Cabinets. Price is set in the Pricing Template. Ensure “Include in Linear Calculations” is Checked.
Wall Cabinets (Ft)	Price each linear foot (or meter) or Wall Cabinets. Price is set in the Pricing Template. Ensure “Include in Linear Calculations” is Checked.
Tall Cabinets (Ft)	Price each linear foot (or meter) or Tall Cabinets. Price is set in the Pricing Template. Ensure “Include in Linear Calculations” is Checked.
# Base Finished Ends	Price each Base Finished Ends. Qty is determined in your design. Price is set in the Pricing Template.
# Wall Finished Ends	Price each Wall Finished Ends. Qty is determined in your design. Price is set in the Pricing Template.
# Tall Finished Ends	Price each Tall Finished Ends. Qty is determined in your design. Price is set in the Pricing Template.
Finished Area	Price Finished Area. Choose what is included in the Finished Area in the Settings Menu in the Pricing Tab. Price is set in the Pricing Template.
Toe Skin	Price the lineal foot of Toe Skin. Price is set in the Pricing Template.
# Base Doors	Price the Qty of Base Doors. This is a fixed price added to each door, regardless of type. Price is set in the Pricing Template.
# Wall Doors	Price the Qty of Wall Doors. This is a fixed price added to each door, regardless of type. Price is set in the Pricing Template.
# Drawer Fronts	Price the Qty of Drawer Fronts. This is a fixed price added to each drawer front, regardless of type. Price is set in the Pricing Template.

# Drawer Boxes	Price the number of Drawer Boxes. This is a fixed price added to each Drawer Box, regardless of type. Price is set in the Pricing Template .
# Tray Boxes	Price the number of Tray Boxes. This is a fixed price added to each Tray, regardless of type. Price is set in the Pricing Template .
# Rollout Shelves	Price the number of Rollout Shelves. This is a fixed price added to each Roll Out Shelf, regardless of type. Price is set in the Pricing Template .
# Shelves	Price the number of Shelves in your design. Price is set in the Pricing Template .
# Openings	Price the number of cabinet Openings in your design. Price is set in the Pricing Template .
Counter Tops (Ft)	Price the Linear Feet (or meters) of Countertops. Price is set in the Pricing Template .
Counter Tops (SqFt)	Price the Area (square feet or meters) of Countertops. Price is set in the Pricing Template .
# Counter Joints	Add a price to each Countertop joint. Price is set in the Pricing Template .
# Counter Radius'	Add a price to each Countertop radius. Price is set in the Pricing Template .
Counter Cutouts	Add a price to each Countertop cutout. Price is set in the Pricing Template .
# Hinges	Price the number of Hinges. This is a fixed price added to each hinge, regardless of type. Price is set in the Pricing Template .
# Guides	Price the number of Guides. This is a fixed price added to each guide, regardless of type or length. Price is set in the Pricing Template .
# Pulls	Price the number of Pulls. This is a fixed price added to each pull, regardless of type. Price is set in the Pricing Template .
# Closet Rods	Price the number of Closet Rods. This is a fixed price added to each closet rod, regardless of type. Price is set in the Pricing Template .
# Shelf Pins	Price the number of Shelf Pins. This is a fixed price added to each pin, regardless of type. Price is set in the Pricing Template .
# Dwr. Front Fasteners	Price the number of Drawer Front Fasteners. This is a fixed price added to each hinge, regardless of type. Price is set in the Pricing Template .
# Spacers	Price the number of Spacers. This is a fixed price added to each Spacer, regardless of type. Price is set in the Pricing Template .
# Fasteners	Price the number of Joint Fasteners. This is a fixed price added to each Joint Fastener, regardless of type. Price is set in the Pricing Template .
# Panel Fasteners	Price the number of Pnl Fasteners. This is a fixed price added to each Pnl. Fastener, regardless of type. Price is set in the Pricing Template .
Molding	Price the lineal feet of Molding. Molding prices are setup in the Pricing menu in the Shapes Library. Libraries>Shapes .
Storage	Price the volume (cubic foot/meter) of each cabinet. Calculated by WxHxD. Price is set in the Pricing Template .
Shelf Frontage	Price the lineal feet of Shelf Frontage. Price is set in the Pricing Template .
Weight	Price the Weight of your products. Weight is set in each Cabinets' "Price Tab" in the Product Editor. Price per lb is set in the Pricing Template .
Labor	Price Labor. Labor and Labor Costs (Shop Rate+Overhead) are set in the Settings Menu in the Pricing Tab .
Part Labor	Price Part Labor. Part labor time is set in the Parts Library. Labor Costs (Shop Rate+Overhead) are set in the Settings Menu in the Pricing Tab .
Machining	Price Machining time. Machine time is calculated (in hours) as the sum of 3 things: 1) The sum of the rectangular perimeter of all cutlist parts (width x height, ignoring shape), divided by the Speed column from the Materials Library 2) The total count of all material sheets multiplied by "Handling Time per Sheet" from Pricing Settings 3) The total count of all non-door parts multiplied by "Handling Time per Part" from Pricing Settings. Price is set in the Settings Menu in the Pricing Tab .
Door Assembly Labor	Price Door Assembly Labor. Assembly time is set in the Door Library. Labor Costs (Shop Rate+Overhead) are set in the Settings Menu in the Pricing Tab .

Drawer Part Labor	Price Drawer Part Labor. Part labor is set in the Parts Library. Labor Costs (Shop Rate+Overhead) are set in the Settings Menu in the Pricing Tab.
Drawer Assembly Labor	Price Drawer Assembly Labor. Assembly time is set in the Drawer Box Library. Labor Costs (Shop Rate+Overhead) are set in the Settings Menu in the Pricing Tab.
Add On (#)	Add an Add-On amount per cabinet qty.
Add-On (% Subtotal)	Add an Add-On based on a percentage of the Job's Subtotal.
Add-On (% Total)	Add an Add-On based on a percentage of the Job's Total.
Tax	Add your local tax.
Subtotal	Add the subtotal of your job. Multiple subtotals may be added.
Total	Add the total of your job. This will add the tax, as well as any non-taxable items.
Deposit	Enter a Deposit percentage to be taken from the Total.
Balance Due	Show the balance remaining after the Deposit is deducted from the Total.
Blank	Add a blank line to your template.