

<- put solder joint here for polarity inversion (motor valves)

Section Control V1.1

Sect 0 or Speed Sensor


NPN OV PNP +12V Sect 1

Sect 2


Sect 3 AgopenGPS Sect 6


Sect 7


Main Valve











Copyright Gorm Rose 2022.

This documentation describes Open Hardware and is licensed under the CERN-OHL-S-2.0.

You may redistribute and modify this documentation under the terms of the CERN-OHL-S-2.0. (http://ohwr.org/cernohl). This documentation is distributed WITHOUT ANY EXPRESS OR IMPLIED WARRANTY, INCLUDING OF MERCHANTABILITY, SATISFACTORY QUALITY AND FITNESS FOR A PARTICULAR PURPOSE. Please see the CERN-OHL-S-2.0 for applicable conditions.

0

0

• •