INSTALLATION INSTRUCTIONS

NI TB-2640

4 × 128 1-Wire Matrix Terminal Block for the NI PXI-2532

このドキュメントには、日本語ページも含まれています。

Introduction

The NI TB-2640 terminal block configures the NI PXI-2532 as a 4×128 1-wire matrix. The NI TB-2640 has ribbon cable headers to connect signals to the switch, and it provides optional isolation resistors to protect the reed relays from capacitive loads.

Refer to the *NI Switches Getting Started Guide* to determine when to install the NI TB-2640.

Make sure you have the following:

- NI TB-2640 terminal block
- 1/8 in. flathead and #1 Phillips screwdrivers
- Four 2 mm jumpers
- Four 34 conductor, 28 AWG, .050 in. pitch ribbon cable assemblies (not included)
- One 16 conductor, 28 AWG, .050 in. pitch ribbon cable assembly (not included)



Note Refer to the *Accessories* section for information about ordering the appropriate cable assemblies.

Connecting Ribbon Cables

To connect ribbon cables to the terminal block, refer to Figures 1 and 2 while completing the following steps:


- 1. Remove the top cover screw.
- 2. Gently remove the top cover from the terminal block.



- 3. Loosen the two screws on the strain-relief assembly and remove the strain-relief bar.
- 4. Remove the two screws from the upper and lower column connection boards.
- 5. Disconnect the column connection boards from the module interface board by sliding them toward the front of the terminal block housing.
- 6. Connect each ribbon cable to the appropriate headers on the column connection boards and the module interface board.
- 7. Reassemble the terminal block.



Note For information about protection resistance and matrix expansion, refer to the NI Switches Help.



- Top Cover Screw
- 2 Top Cover3 Strain-relief Screws
- 4 Strain-relief Bar
- 5 Column Connection Board Screws
- 6 Lower Column Connection Board

- Upper Column Connection Board
- Module Interface Board
- Column Headers
- 10 Row Headers
- 11 Housing

Figure 1. NI TB-2640 Terminal Block




Figure 2. NI TB-2640 Terminal Block Signal Connections

Accessories

Table 1. Accessories for the NI TB-2640

Accessory	Manufacturer	Part Number
NI SCB-264X screw terminal block	National Instruments	779341-01
Row and column cable kit for the NI SCB-264X terminal blocks	National Instruments	779346-01
Row connection cable for column expansion	National Instruments	779325-01
16 Conductor, .05 in. pitch ribbon cable assemblies	Samtec	FFSD-08-01-N
34 Conductor, .05 in. pitch ribbon cable assemblies	Samtec	FFSD-17-01-N



Note For information about using shielded cabling, refer to the NI PXI-2532 Declaration of Conformity (DoC). To obtain the DoC, visit ni.com/certification, search by model number or product line, and click the appropriate link in the Certification column.

Specifications

This section lists additional specifications for the NI TB-2640 used with the NI PXI-2532. All specifications are subject to change without notice. Visit ni.com/manuals for the most current specifications.

Input Characteristics

All input characteristics are DC, AC_{pk} , or a combination unless otherwise specified.

Maximum switching voltage

Channel-to-channel	100 V
Channel-to-ground	100 V, CAT I



Caution This module is rated for Measurement Category I and intended to carry signal voltages no greater than 100 V. This module can withstand up to 500 V impulse voltage. Do *not* use this module for connections to signals or for measurements within Categories II, III, or IV. Do *not* connect to MAINs supply circuits (for example, wall outlets) of 115 or 230 VAC. Refer to the *Read Me First: Safety and Electromagnetic Compatibility* document for more information on measurement categories.

When hazardous voltages (>42.4 V_{pk} /60 VDC) are present on any relay terminal, safety low-voltage (<42.4 V_{pk} /60 VDC) cannot be connected to any other relay terminal.

Maximum current (per channel)0.5 A
DC path resistance<1.5 Ω
Row and column protection resistors (when used)100 Ω
Bandwidth (-3 dB, 50Ω termination)
Typical≥10 MHz
Crosstalk (50 Ω termination)
Channel-to-channel
10 kHz<-75 dB
100 kHz<-55 dB
1 MHz<-35 dB

National Instruments, NI, ni.com, and LabVIEW are trademarks of National Instruments Corporation. Refer to the *Terms of Use* section on ni.com/legal for more information about National Instruments trademarks. Other product and company names mentioned herein are trademarks or trade names of their respective companies. For patents covering National Instruments products/technology, refer to the appropriate location: Help»Patents in your software, the patents.txt file on your media, or the *National Instruments Patent Notice* at ni.com/patents.

取り付け手順

NI TB-2640

NI PXI-2532 用単線式 4×128 マトリクス端子台

はじめに

NI TB-2640 端子台は、NI PXI-2532 を単線式 4×128 マトリクスとして構成します。NI TB-2640 には信号をスイッチに接続するリボンケーブルヘッダが装備されており、リードリレーを容量性負荷から保護するオプションの絶縁抵抗を提供します。

NI TB-2640 を取り付ける順番については、『NI スイッチスタートアップガイド』を参照してください。

下記の部品があることを確認します。

- NI TB-2640 端子台
- 1/8 in. マイナスドライバーおよびプラスドライバー(No. 1)
- 2 mm ジャンパ×4
- 34 コンダクタ、28 AWG、0.050 in. ピッチリボンケーブルアセンブリ×4(非同梱)
- 16 コンダクタ、28 AWG、0.050 in. ピッチリボンケーブルアセンブリ×1 (非同梱)



メモ ケーブルアセンブリの注文に関する情報は「アクセサリ」セクションを参照してください。

リボンケーブルを接続する

リボンケーブルを端子台に接続するには、図 1 および図 2 を参考に次の 手順に従います。


- 1. 上部カバーのネジを外します。
- 2. 端子台から上部カバーを注意して取り外します。
- 3. 抜け防止バーの2つのネジを緩めてバーを取り外します。
- 4. 列接続ボードの上部と底部にある2つのネジを取り外します。



- 5. 列接続ボードを端子台ケースの前方へスライドさせてモジュールイン タフェースから外します。
- 6. 各リボンケーブルを列接続ボードおよびモジュールインタフェース ボードの対応するヘッダに接続します。
- 7. 端子台を再度組み立てます。



メモ 保護抵抗およびマトリクス拡張についての詳細は、『NI スイッチ ヘルプ』を参照してください。



- 1 上部カバーのネジ
- 2 上部カバー
- 3 抜け防止バー用ネジ
- 4 抜け防止バー
- 5 列接続ボードネジ
- 6 列接続ボード (底部)

- 7 列接続ボード (上部)
- 8 モジュールインタフェースボード
- 9 列ヘッダ
- 10 行ヘッダ
- 11 ケース

図 1 NI TB-2640 端子台




図2 NI TB-2640 端子台の信号接続

アクセサリ

表 1 NI TB-2640 対応のアクセサリ

アクセサリ	製造元	製品番号
NI SCB-264X ネジ留め式端子台	National Instruments	779341-01
NI SCB-264X 端子台用行 / 列ケーブルキット	National Instruments	779346-01
列拡張用行接続ケーブル	National Instruments	779325-01
16 コンダクタ、0.05 in. ピッチリボンケーブル アセンブリ	Samtec	FFSD-08-01-N
34 コンダクタ、0.05 in. ピッチリボンケーブル アセンブリ	Samtec	FFSD-17-01-N



メモ

シールドケーブルの使用に関する詳細は、NI PXI-2532 の適合宣言(DoC)を参照してください。適合宣言を入手するには、ni.com/certification(英語)にアクセスして型番または製品ラインで検索し、保証の欄の該当するリンクをクリックしてください。

このセクションでは、NI PXI-2532 との併用における NI TB-2640 の追加仕様を記載しています。すべての仕様は事前の通知なしに変更されることがあります。最新の仕様については、ni.com/manuals を参照してください。

入力特性

全ての入力特性は特に注釈のない限り、DC、AC $_{\rm pk}$ 、もしくはその組み合わせです。

最大スイッチ電圧

チャンネル間	100 V	
チャンネル / グランド間	100 V、	CATI



注意

このモジュールは、Measurement Category I に定格されているため、使用できる信号電圧は 100 V 以下です。また、最大 500 V までのインパルス電圧に耐性があります。Category II、III、または IV の信号を、このモジュールに接続したり測定しないでください。115 または 230 VAC のコンセントを使用する電源回路(例: 壁コンセント)に接続しないでください。測定カテゴリの詳細については、『はじめにお読みください:安全対策と電磁両立性について』を参照してください。

危険電圧(>42.4 $V_{pk}/60$ VDC)がリレー端子に接続されている場合、安全低電圧(<42.4 $V_{pk}/60$ VDC)をその他のリレー端子に接続することができません。

最大電流(チャンネルあたり)0.5 A
DC パス抵抗<1.5 Ω
行および列保護抵抗 (使用時)100 Ω
帯域幅(−3 dB、50 Ω 終端)標準 ≥10 MHz
クロストーク(50 Ω 終端) チャンネル間
10 kHz<-75 dB
100 kHz<-55 dB
1 MHz <-35 dB

National Instruments、NI、ni.com、およびLabVIEW は National Instruments Corporation (米国ナショナルインスツルメンツ社) の商標です。National Instruments の商標の詳細については、 ni.com/legal の Tierms of Use J セクションを参照してください。本文書中に記載されたその他の 製品名および企業名は、それぞれの企業の商標または商号です。National Instruments の製品を保護する 特許については、ソフトウェアに合まれている特所情報(ペ**ルブー特所情報**)、メディフでまれている patents.txtファイル、または ni.com/patentsのうち、該当するリソースから参照してください。