

COURSE

OVERVIEW


FALLPROTEC SECURE RAIL

The Fallprotec Securail User course provides learners with the knowledge and practical understanding required to safely use permanent Fallprotec Securail systems in work-at-height environments. The course focuses on system components, pre-use checks, limitations, safe connection, and correct movement on vertical and horizontal rail systems. Learners are introduced to system requirements, inspection status, and safe work practices.

Emphasis is placed on hazard identification, correct equipment use, and adherence to manufacturer requirements to prevent falls and ensure safe operation.

BY COMPLETING THIS COURSE, LEARNERS WILL BE ABLE TO:

- Explain Fallprotec Securail system requirements and limitations
- Identify system components and compatible equipment
- Conduct pre-use checks and verify system safety
- Identify hazards associated with Securail use
- Apply correct connection and movement techniques on rail systems
- Follow safe work procedures in accordance with manufacturer requirements



INTRODUCTION

I COURSE OVERVIEW

IV GRAVITY VALUES

V TO THE LEARNER

VI GENERAL SITE SAFETY

VIII SITE ESTABLISHMENT

INDEX



Introduction	1
Purpose	2
Scope	2
Before Work Starts.....	3
Requirements	4
Fallprotec Secuirail	
Vertical	
• Equipment	6
• Pre-use checks.....	7
• Limitations	8
• Warnings	9
Horizontal	
• Equipment	11
• Pre-use checks.....	13
• Limitations	14
• Warnings	15
Safe Accessrail	
• Equipment	17
• Pre-use checks.....	18
• Limitations	19
• Warnings	20



FALLPROTEC



Height Safety Products

GRAVITY

VALUES



R

RELATIONSHIPS

Creating and maintaining meaningful relationships with all stakeholders of Gravity.

I

INTEGRITY

Conducting day-to-day business with integrity at all times.

S

SOLUTIONS **DRIVEN**

Being solution driven.

Q

QUALITY & **EXCELLENCE**

Striving for excellence and constant improvement.

WELCOME, LEARNER!

Working at height is inherently risky — and this includes training exercises. The best way to stay safe is by learning and practising the correct techniques. This manual will help you:

- Understand the basics of fall arrest and basic rescue
- Learn how to identify and manage height-related hazards
- Build the skills needed to work safely and confidently

Working at height means doing any job where you could fall from one level to another. This includes tasks done:

- Above the ground or floor
- Near open edges
- Near fragile surfaces
- Next to holes or gaps in the ground or floor
- Close to excavations

Note: Work at height does not include slipping or tripping hazards on the same level.

HOW TO USE THIS MANUAL?

This guide supports the Fall Arrest and Basic Rescue Course and is meant to be used with the help of a trained instructor.

At Gravity Training, all facilitators are highly trained to deliver top-quality learning experiences. The content has been designed to be clear, easy to remember, and practical for real worksites.

Before any work begins, the site must be safe.

Use this simple checklist

Follow the Rules:

Make sure you follow all client rules.

Example: If night work is not allowed, do not work at night.

01



02



Rescue Plan

Have a rescue plan ready. A rescue kit and first aid kit must be on site.

Work in Pairs

There must be at least two workers on site.
If something goes wrong, one can help or call for help.

03



05

Safe Site

Check the building or structure.

Make sure it is strong and safe to work on.



Check Equipment

All tools and gear must be safe and working before use.

04



06 Manage Traffic

If there are cars or trucks nearby, there must be a traffic safety plan.

06




07 Do a Risk Assessment

Check what dangers there are.

All workers must understand the risks before starting work.


07



08

08 Use the Right Safety Gear

Make sure the fall protection fits the job and the site.



EXCLUSION ZONES & BARRICADES

Exclusion Zone: An area where no one is allowed to walk or work.

Example: A 2-metre space around a hole in the roof.

Barricade: A physical barrier to block people from danger.

Example: A fence or tape to stop people from falling.

SITE SAFETY



Be healthy and ready before starting work.



Only do jobs you are trained and allowed to do.



Never work under the influence of alcohol or drugs.




Always wear your safety gear (PPE, harness if working at height).



Use harnesses correctly and stay connected at heights.



Never work alone and always follow safety steps.



SITE SAFETY

Keep people away from areas below when working above.



Don't walk under lifted loads or stand in dangerous areas.



Only trained people can do electrical, underground, or confined space work.



Follow road rules. Wear helmets. No passengers on open trucks..



Don't drive tired or distracted.



Stop unsafe work! Everyone has the right to speak up.



PURPOSE

This booklet is a training aid that allows the learner, with the guidance of a competent facilitator, to understand the requirements, limitations and safe use of Fallprotec systems.

SCOPE

Only the safe use of horizontal and vertical Fallprotec Securope systems will be discussed in this document.

It does NOT extend to installations or detailed inspections of any Fallprotec systems nor does this include the use of Fallprotec Securail products.

Should you encounter Fallprotec Securail systems, ensure that you receive the relevant training and ensure you follow the manufacturer's requirements.

BEFORE WORK STARTS

- At least 2 technicians on site
- Conduct full risk assessment
- Ensure all workers are medically fit
- All equipment must be inspected before work starts
- Have a rescue plan in place



REQUIREMENTS

Before any Fallprotec systems may be used the Site Supervisor must ensure that the following is in place:

Must be installed by a competent person

Must be inspected once a year

Must be signed off

User must be trained and practiced in use thereof as well as fall arrest

ALL OF THE INFORMATION MUST BE ENGRAVED ON THE CERTIFICATE PLATE.

FALLPROTEC
Height Safety Products
Tel: (352) 26 55 09 30
www.fallprotec.com

WARNING
FALL PROTECTION MUST BE USED
REFER TO USER MANUAL BEFORE USE

GRAVITY ACCESS & RIGGING
Installed by Gravity Access
www.gravityaccess.co.za
0861 10 12 13

The lifeline must be inspected by a competent person once a year and after stopping a fall

Project Number	Installation date	Number of users	Securape Horizontal EN795-C:2012 TS 16415:2013	Securall/Safeaccess EN795-D:2012 TS 16415:2013
	Inspection	Inspection	Inspection	Inspection

Installation date

Inspection dates

Maximum number of users on line

Type of system


FALLPROTEC SECURAIL - VERTICAL (FALL ARREST)

The vertical Securail is constructed with anodized aluminium rails which allows for a variety of “trolleys” to travel on various configurations to allow quick and efficient fall arrest work.

ADVANTAGES AND DISADVANTAGES

The SecuRail is a rigid fall arrest rail which reduces the influence the environment can have on the system compared to Securope systems.


However, apart from being more expensive than other systems, the system does restrain the worker to the line and should the worker be required to move away from the installed system, shock absorbing lanyards must be taken up as well.



EQUIPMENT



EN361 - Full
Body Harness



EN795 -Type D Trolley



EN355 - Shock
Absorber




EN358 - Workbelt



EN12492 - Helmet
GTFPULM02_Rev 1

PRE-USE CHECKS

Before a user connects to a Fallprotec vertical Securope, the following elements of the system must be inspected and determined to be safe for use.



LIMITATIONS

- Amount of users allowed on line are given on the certificate plate
- The user must weigh between 60-100kg
- Only use the Fallprotec trolley
- The rail may not be used as a work positioning system, a separate work positioning system must be taken up
- Do not use in inclement weather



WARNINGS

- Never remove the trolley from the rail before additional fall protection has been added
- Do not manipulate the fall trolley directly
- Do not use the trolley fall arrestor if it's shock absorber if it is longer than 10cm
- Do not use if line is slack
- Do not ground welding machine on line
- Never use line outside of its limits
- Do not use if the inspection is not current
- Do not adjust, alter or tamper with the system in any way.
- Do not extend the trolley fall arrestor's shock absorber.





FALLPROTEC SECURAIL - HORIZONTAL

The horizontal Securail is constructed with anodized aluminium rails which allows for a variety of “trolleys” to travel on various configurations to allow quick and efficient fall arrest and rope access work.

ADVANTAGES AND DISADVANTAGES

Rigid lines are stronger and less susceptible to environmental changes and can withstand larger forces than traditional steel wire rope systems.

However, apart from being more expensive than other systems, the system does restrain the worker to the line and should the worker be required to move away from the installed system, shock absorbing lanyards must be taken up as well.



EQUIPMENT (FALL ARREST)



EN361 - Full
Body Harness



EN 795- Type D -
Trolley



EN355 - Shock
Absorber*



EN12492 - Helmet

*An EN 360 certified retractable lanyards may also be used

EQUIPMENT (ROPE ACCESS)



EN361/358/813 - Full
Body Harness



EN892 - Cowtail



EN12492 - Helmet



EN567 - Ascenders



EN362 - Karabiner



EN341 - Descender




Etrier



EN 795- Type D - Trolley


PRE-USE CHECKS

Before a user connects to a horizontal Fallprotec Securope, the following elements of the system must be inspected and determined to be safe for use.



LIMITATIONS

- 15° maximum inclined angle
- Maximum number of users given on certificate plate
- All components must be of compatible material
- During rope access work, DO NOT rig ropes with double loop figure 8s as this may interfere with the movement of the trolleys



Two figure 8s on a bight to prevent the trolleys colliding during movement.

WARNINGS

- Never remove the trolley from the line before additional fall protection has been added
- Only one person allowed per trolley for fall arrest
- Only one person allowed on two trolleys during rope access work
- Do not ground welding machine on line
- Never use line outside of its limits
- Do not use if the inspection is not current





FALLPROTEC SAFE ACCESS RAIL

The Safe Access Rail is constructed with anodized aluminium rails which allows for a variety of "trolleys" to travel on various configurations to allow quick and efficient fall arrest and rope access work.

ADVANTAGES AND DISADVANTAGES

Rigid lines are stronger and less susceptible to environmental changes and can withstand larger forces than traditional steel wire rope systems. The Safe Access Rail is stronger than the Securail and allows for the users to be on on trolley instead of two.

However, apart from being more expensive than other systems, the system does restrain the worker to the line and should the worker be required to move away from the installed system, shock absorbing lanyards must be taken up as well.



EQUIPMENT (ROPE ACCESS)



EN361/358/813 - Full
Body Harness



EN892 - Cowtail



EN12492 - Helmet



EN567 - Ascenders




EN362 - Karabiner



EN341 - Descender



Etrier



NAV 7 Trolley

PRE-USE CHECKS


Before a user connects to a horizontal Fallprotec Safe Access Rail, the following elements of the system must be inspected and determined to be safe for use.

Ensure the rail is secured,
inspected and within date.

The fixing bolts of the rollers must
be locked.


The trolley should move easily when rolling
on the rail.

The anchor eye should turn freely.



LIMITATIONS

- 15° maximum inclined angle
- Maximum number of users given on certificate plate
- All components must be of compatible material
- Since the worker is suspended from one trolley, the knots do not matter as long as the worker is connected to two points. For consistency we will rig work ropes in the same way Securail as well as Safe Access Rails



WARNINGS

- Never remove the trolley from the line before additional fall protection has been added
- Only one person allowed on two trolleys during rope access work
- Do not ground welding machine on line
- Never use line outside of its limits
- Do not use if the inspection is not current



THE WAY FORWARD



Congratulations on completing Gravity Training's climbing Equipment Inspection & Management course.

If found not yet competent (NYC), you will need more training before you can be reassessed. Please do not be discouraged. Not everyone passes on their first attempt. Some learners need a bit more experience to obtain the required knowledge and skills. You will receive comprehensive feedback on your performance and be informed on how to proceed.

At Gravity, we care about the professional development of our clients. Should you wish to take the next step, consider enrolling for some of our other courses. See The Way Forward and the Gravity Skills and Development Map or consult your facilitator/assessor.

GRAVITY COURSES

